



Before beginning installation, read these instructions carefully. This will simplify installation and ensure that the product is installed correctly and safely. Leave these instructions near the product after installation for future reference.

TD-H901MW



MFL68721085 Rev.02_082217

www.lg.com

TABLE OF CONTENTS

This manual may contain images or content different from the model you purchased.

This manual is subject to revision by the manufacturer.

SAFETY INSTRUCTIONS	3
IMPORTANT SAFETY INSTRUCTIONS	
INSTALLATION	10
Specifications	
Accessories	
Installation Place Requirements	11
Stacking Installation Instructions	
OPERATION	15
Using the Appliance	15
Sorting Laundry	16
Control Panel	17
Programme Table	18
Appliance Settings	21
Option Programme	22
Rack Dry (Optional)	25
SMART FUNCTIONS	26
Using LG SmartThinQ Application	
Using Smart Diagnosis™	
MAINTENANCE	30
Cleaning the Lint Filter	
Emptying the Water Container	
Cleaning the Cool Air Inlet Grill	
Wiping the Moisture Sensor	
TROUBLESHOOTING	32
Diagnosing Problems	
Error Codes	

SAFETY INSTRUCTIONS

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance.

The guidelines are separated into 'WARNING' and 'CAUTION' as described below.



This symbol is displayed to indicate matters and operations that can cause risk. Read the part with this symbol carefully and follow the instructions in order to avoid risk



WARNING

This indicates that the failure to follow the instructions can cause serious injury or death.



▲ CAUTION

This indicates that the failure to follow the instructions can cause the minor injury or damage to the product.

IMPORTANT SAFETY INSTRUCTIONS



WARNING

To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

Children in the Household

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.



WARNING - To avoid a fire

Do not wash or dry clothes or items that have any contaminants of flammable solvents or substances. Do not clean the product or expose it to flammable substances.

Installation

- Make sure the appliance is properly installed, grounded, and adjusted by qualified service personnel according to the installation instructions.
- •Never attempt to operate the appliance if it is damaged, malfunctioning, partially disassembled, or has missing or broken parts, including a damaged cord or plug.
- •This appliance should only be transported by two or more people holding the appliance securely.
- •Do not install the appliance in a damp and dusty place. Do not install or store the appliance in any outdoor area, or any area that is subject to weathering conditions such as direct sunlight, wind, or rain or temperatures below freezing.
- •Tighten the drain hose at connecting ends to avoid separation.
- •If the power cord is damaged or the hole of the socket outlet is loose, do not use the power cord and contact an authorized service centre.
- •Do not plug multiple socket outlets, an extension power cable or adapter with this appliance.

- •This appliance must not be installed behind a lockable door, a sliding door or a door with a hinge on the opposite side to that of the appliance, in such a way that a full opening of the appliance door is restricted.
- •This appliance must be grounded (earthed via the power cord). In the event of malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current.
- •This appliance is equipped with a power cord having an equipment-grounding conductor (earthing pin) and a grounding power plug. The power plug must be plugged into an appropriate socket outlet that is installed and grounded in accordance with all local codes and ordinances.
- •Improper connection of the equipment-grounding conductor can result in risk of electric shock. Check with a qualified electrician or service personnel if you are in doubt as to whether the appliance is properly grounded.
- •Do not modify the power plug provided with the appliance. If it does not fit the outlet, have a proper outlet installed by a qualified electrician.

Operation

- •Do not attempt to separate any panels or disassemble the appliance. Do not apply any sharp objects to the control panel in order to operate the appliance.
- Do not repair or replace any part of the appliance. All repairs and servicing must be performed by qualified service personnel unless specifically recommended in this Owner's Manual. Use only authorized factory parts.

- •Keep the area underneath and around the appliance free of combustible materials such as lint, paper, rags, chemicals, etc.
- •Do not put animals, such as pets into the appliance.
- •Do not leave the appliance door open. Children may hang on the door or crawl inside the appliance, causing damage or injury.
- •Never reach into the appliance while it is operating. Wait until the drum has completely stopped.
- •Do not put in, wash or dry articles that have been cleaned in, washed in, soaked in, or spotted with combustible or explosive substances (such as wax, oil, paint, gasoline, degreasers, drycleaning solvents, kerosene, vegetable oil, cooking oil, etc.). Improper use can cause a fire or explosion.
- •In case of flood, disconnect the power plug and contact the LG Electronics customer information centre.
- •Do not push down the door excessively, when the appliance door is open.
- •Use a new hose or hose-set supplied with the appliance. Reusing old hoses can cause a water leak and subsequent property damage.
- •Do not touch the door during a high temperature programme.
- •Do not use flammable gas and combustible substances (benzene, gasoline, thinner, petroleum, alcohol, etc.) near the appliance.

- •If the drain hose or inlet hose is frozen during winter, use it only after thawing.
- •Keep all washing detergents, softener and bleach away from children.
- •Do not touch the power plug or the appliance controls with wet hands.
- Do not bend the power cable excessively or place a heavy object on it.

Maintenance

- •Securely plug the power plug in the socket outlet after completely removing any moisture and dust.
- •Disconnect the appliance from the power supply before cleaning the appliance. Setting the controls to the OFF or stand by position does not disconnect this appliance from the power supply.
- •Do not spray water inside or outside the appliance to clean it.
- Never unplug the appliance by pulling on the power cable. Always grip the power plug firmly and pull straight out from the socket outlet.

Technical Safety for Using the Dryer


- •Do not dry unwashed items in the appliance.
- Fabric softeners, or similar products, should be used as specified by the fabric softener instructions.
- •Remove all objects from pockets such as lighters and matches.
- •Never stop the appliance before the end of the drying cycle unless all items are quickly removed and spread out so that the heat is dissipated.
- •The appliance is not to be used if industrial chemicals have been used for cleaning.
- •Items such as foam rubber (latex foam), shower caps, waterproof textiles, rubber backed articles and clothes or pillows fitted with foam rubber pads should not be dried in the appliance.
- •Do not drink the condensed water. Failure to do so may result in food-borne illnesses.
- •The lint trap has to be cleaned frequently.
- •Lint must not to be allowed to accumulate around the appliance.
- •Do not spray dry cleaning detergent directly onto the appliance or use the appliance to dry clothes left with dry cleaning detergent.
- •Do not dry clothes stained with oil substances. Oil substances (including edible oils) stained on clothes cannot be completely removed even after washing with water.


- •The appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by a utility.
- •Remove clothes from the product immediately when drying is complete or the power is turned off during the drying process. Leaving clothes that has been dried in the appliance unattended could result in fire. Clothes removed from the appliance after drying could result in fire. Remove clothes immediately after drying, and then hang or lay the clothes flat to cool.
- •Oil-affected items can ignite spontaneously, especially when exposed to heat sources such as in a tumble dryer. The items become warm, causing an oxidation reaction in the oil. Oxidation create heat. If the heat cannot escape, the items can become hot enough to catch fire. Piling, stacking or storing oil-affected items can prevent heat from escaping and so create a fire hazard.
- •If it is unavoidable that fabrics that contain vegetable or cooking oil or have been contaminated by hair care products be placed in a tumble dryer they should first be washed in hot water with extra detergent this will reduce, but not eliminate, the hazard.

Disposal

- •Before discarding an old appliance, unplug it. Cut off the cable directly behind the appliance to prevent misuse.
- •Dispose of all packaging materials (such as plastic bags and styrofoam) away from children. The packaging materials can cause suffocation.
- •Remove the door before disposing of or discarding this appliance to avoid the danger of children or small animals getting trapped inside.

Specifications





- 1 Water container
- 2 Control panel
- 3 Glass door
- 4 Opaque door
- 5 Air ventilation grill

Model	TD-H901MW
Power supply	220 - 240 V, 50 Hz
Size	600 mm (W) X 690 mm (D) X 850 mm(H)
Product weight	54 - 57 kg
Allowable temperature	5 - 35 °C
Max. capacity	9 kg

[•] Appearance and specifications may vary without notice to improve the quality of the appliance.

Accessories

Please contact the LG Electronics Customer Information Centre for purchase.



Condensing Drain Hose and Hose Holder



Dry Rack



Stacking Kit

Installation Place Requirements

Location

Level floor: Allowable slope under the entire appliance is 1°.

Power outlet: Must be within 1.5 meters of either side of the location of the appliance.

- Do not overload the outlet with more than one appliance.
- Do not place or store laundry products on top of the appliance at any time. These products may damage the finish or controls.

NOTE

- For better drying performance, please keep the rear of the appliance away from wall.
- Do not install the appliance where there is a risk of frost or dust.
- The appliance may not be able to operate properly or may be damaged by freezing of condensed water in the pump and drain hose.
- Do not install the appliance next to a high-temperature appliance like refrigerator, oven or stove etc, which can cause poor drying performance and programme duration, and adversely affect the proper functioning of the compressor. The appliance performs best at a room temperature of 23 °C.

Positioning

- Install the appliance on a flat hard floor.
- Make sure that air circulation around the appliance is not impeded by carpets, rugs, etc.
- Never try to correct any unevenness in the floor with pieces of wood, cardboard or similar materials under the appliance.
- Do not install the appliance in rooms where freezing temperatures may occur. Frozen hoses may burst under pressure. The reliability of the electronic control unit may be impaired at temperatures below freezing point.
- If the appliance is delivered in winter and temperatures are below freezing, place the appliance at room temperature for a few hours before putting it into operation.
- Please ensure that when the appliance is installed, it is easily accessible for an engineer in the event of a breakdown.
- With the appliance installed, adjust all four feet using a transit bolt spanner to ensure the appliance is stable, and a clearance of approximately 20 mm is left between the top of the appliance and the underside of any work-top.

Ventilation Requirement

- · Alcove or under counter
 - Ensure air flow of 3.17 m³/min through the appliance
- Closet
 - Closet door must have 2 (louvered) openings, each having a minimum area of 387 cm², located 8 cm from bottom and top of door

WARNING

- Avoid installing the appliance around a heat source. The rear side of the appliance must be well ventilated. Failure to follow these instructions may result in problems.
- The appliance should not be installed next to a refrigeration appliance.
- The appliance is not designed for maritime use or for use in mobile installations such as caravans, aircraft etc.

Electrical Connection

- Do not use an extension cord or double adapter.
- · Always unplug the appliance after use.
- Connect the appliance to an earthed socket in accordance with current wiring regulations.
- The appliance must be positioned so that the plug is easily accessible.


Stacking Installation Instructions

Your dryer can be placed on top of an LG front load washing machine and securely fixed with a stacking kit. This installation must be conducted by qualified service personnel to ensure it has been installed correctly.

The qualified service personnel will ensure you have the correct stacking kit for your model of washing machine and will ensure it is firmly fixed. For these reasons, expert fitting is essential.

Stacking Kit

In order to stack this dryer an LG stacking kit is required.




This dryer may only be stacked on top of an LG front load washing machine. Do not attempt to stack this dryer on any other washing machine, as damage, injury or property damage could result.


		hine Top plate ze
	550 mm	600 mm
Shape and assembly direction		

Installation Procedure


- 1 Place the LG dryer on the LG washing machine.
- 2 Remove the two screws from the bottom of the rear cover on each side as illustrated below.



- 3 Align the stacking kit holes and the rear cover holes.
 - 3-1) 600 mm



• 3-2) 550 mm



- 4 Fasten the two screws that were removed earlier from the dryer to the stacking kit.
- Use the four screws in the accessory box (16 mm) to assemble the washing machine rear cover and stacking kit.
- 6 The procedure for the opposite side will be the same.


WARNING

- Incorrect installation can cause serious accidents
- The weight of the appliance and the height of installation make the stacking procedure too risky for one person. This procedure should be performed by two or more qualified service personnel.
- The appliance is not suitable for a built-in installation. Please do not install as a built-in appliance.
- Do not operate if the appliance is not properly stacked.


Condensed Water Drain-out

Normally, condensed water is pumped up to the water container where water is collected until manually emptied. Water can also be drained out directly to a mains drain, especially when the dryer is stacked on top of a washing machine. With a connecting kit for the mains drain hose, simply change the water path and re-route to the drainage facility as below:

Separate the anti-backflow lid(1) and the water container hose(2) from the connecting kit.



2 Attach the anti-backflow lid(1) to the head of the connecting kit and then connect the drain hose(3) to the opposite side of the connecting kit.



A CAUTION


 If the hose is installed in a way that leaves it bent or pinched, drainage may not function properly.

Leveling the appliance

Leveling the appliance prevents unnecessary noise and vibration. Place the appliance on a solid, level floor.

If the appliance is not properly level, adjust the front leveling feet as necessary.

Turn them clockwise to raise and counterclockwise to lower until the appliance no longer wobbles, both front-to-back and side-to-side and corner-to-corner.



Diagonal Check

 When pushing down the edges of the top plate diagonally, the appliance should not move up and down at all (Check both directions). If the appliance rocks when pushing the top plate diagonally, adjust the feet again.

Using the Appliance

Before the first cycle, set the appliance to dry for five minutes to warm up the drum. Open the door between loads the first few times you use the appliance to allow any odours from the interior of the appliance to disperse.

- 1 Ensure the lint filter and water container are clean
 - The lint filter is inside the door rim. It needs to be cleaned before each drying cycle.
 - Open the door and ensure the lint filter is clean. If it is not, please clean the lint filter.





 Also check if the water container needs to be emptied for optimum drying results.



WARNING

Do not drink the condensed water.

NOTE

- In some instances, the appliance may stop and display an error message indicating that the condensed water tank is full. Empty the water tank before restarting the appliance.
- 2 Place laundry into the drum after sorting.
 - The clothes should be sorted by fabric type and dryness level and all the strings and belts of clothes should be well tied and fixed before being put into the drum.
 Push the laundry to the back to keep it away from the door seal. Otherwise, the door seal and clothes may be damaged.
 Close the door.

A CAUTION

- Be careful not to trap laundry between the door and rubber seal.
- 3 Turn the power on.
 - Press the Power button. The indicator icon above the button will become illuminated, indicating that the appliance is all set to run.



- 4 Select the drying programme you want.
 - You can choose a programme by turning the programme selector knob until the required programme is indicated.
 - If you press the Start/Pause button without choosing a programme, the appliance will proceed with the Cotton programme. Please refer to the programme table for the detailed information.



5 Press the Start/Pause button.



- 6 After the cycle has finished, open the door and remove the laundry.
- 7 Turn off the appliance.
 - Press the Power button.

A CAUTION

- Be careful! The drum inside may still be hot.
- The appliance must not be used for purposes other than those for which it was designed.

NOTE

- The final part of a tumble dryer cycle occurs without heat (cool down cycle) to ensure that laundry is left at a temperature that ensures the laundry will not be damaged.
- A high atmospheric temperature and a small room may both increase drying time as well as energy consumption.

Sorting Laundry

Clothes have their own wash care labels, so drying according to the wash care label is recommended

Not only that, the laundry must be sorted according to size and type of fabric.

For the best drying performance and most efficient energy usage, do not overload the appliance.

Woollens

 Dry woollens on the Wool programme. Be sure to follow fabric care label symbols first.
 Wool may not be completely dried from the cycle, so do not repeat drying. Pull woollens to their original shape and dry them flat.

Woven and Loopknit Materials

 Some woven and loopknit materials may shrink, depending on quality.

Permanent Press and Synthetics

 Do not overload the appliance. Take out permanent press items as soon as the appliance stops to reduce creases.

Baby Clothes and Night Gowns

· Always check fabric care labels.

Rubber and Plastics


- Do not dry any items made from or containing rubber or plastics such as:
 - Aprons, Bibs and Chair Covers
 - Curtains and Table Clothes
 - Bathmats

Fiberglass

 Do not dry fiberglass items in the appliance. Glass particles left in the appliance may be subsequently picked up by your clothes in later cycles.

Icon	Description
	Dry
	Tumble dry
	Permanent Press / Crease resistant
	Gentle / Delicate
Ø	Do not tumble dry
×	Do not dry
\Box	High heating
\Box	Medium heating
	Low heating
	No Heating / Air
	Line dry / Hang to dry
III	Drip dry
	Dry flat
	In the shade

Control Panel



1 Power Button

- Press the **Power** button to turn power on and off
- Press the **Power** button to cancel the Delay End function.

2 Programme Selector

- Programmes are available according to the laundry type.
- The lamp will light up to indicate the selected programme.

3 Start/Pause Button

- This Start/Pause button is used to start or pause a dry cycle.
- When in Pause, the power is turned off automatically after 14 minutes for safety reasons.

4 Additional Programme Buttons

- Use these buttons to select the desired options for the selected programme. For more information about the options for the each programme, please refer to Extra Options.
- In order to use the Remote Start function, refer to SMART FUNCTIONS.

5 Display

• The display shows the estimated time remaining.

Programme Table

Drying Programme

Sensor Dry Programmes				
Programme	Laundry Type	Detail	Drying Level	Max. Load Capacity
	Towels, dressing gowns and bed linen	For thick and quilted fabrics	Extra	9 kg
Cotton	Bath towels, tea towels, underwear and cotton socks	For fabrics that do not need to be ironed	Cupboard	9 kg
	Bed linen, table linen, towels, T-shirts, polo shirts and work clothes	For fabrics that need to be ironed	Iron	9 kg
Mixed Fabric	Bed linen, table linen, tracksuits, anoraks and blankets	For thick and quilted fabrics that do not need to be ironed	Extra	4.5 kg
Fabric	Shirts and blouses	For fabrics that do not need to be ironed	Cupboard	4.5 kg
Facy Care	Shirts, T-shirts, trousers, under-wear and socks	For polyamide, acrylic, and polyester that do not need to be ironed	Cupboard	4.5 kg
Easy Care	Shirts, T-shirts, under- wear, anoraks and socks	For polyamide, acrylic, polyester that do need to be ironed	Iron	4.5 kg
Bulky Item	Bed clothes, sheets	For bulky items	-	2 kg
Jeans	Jeans and colour fading garments.	For jeans which do not need to be ironed	-	3 kg
Towel	T-shirts, pillowcase, and towels	For cotton fabrics which do not need to be ironed	-	4.5 kg
Quick Dry	Linen and towels (excluding delicate fabrics) sports wear, bulky Item cycle.	For small loads of suitable fabrics with short drying times	-	1.5 kg

Sensor Dry Programmes					
Programme	Laundry Type	Detail	Drying Level	Max. Load Capacity	
Sports Wear	Soccer kit and training wear	For polyester material	-	2 kg	
Delicate	Silk, fine fabrics and lingerie	For fabrics that are heat-sensitive, such as synthetic fabrics	-	1.5 kg	
Wool	Wool	For wool fabrics	-	1 kg	
	Manual Dry Programmes				
Programme	Laundry Type	Detail	Drying Level	Max. Load Capacity	
Rack Dry	Silk, wool, delicate lingerie	Refreshes clothes without tumble drying	-	-	
Cool Air	All fabrics that need refreshing	Tumbles without heat	-	-	
Warm Air	Bath towels, bath robes, dishclothes and acrylic quilted fabrics	Small Items & damp clothing, Everyday items suitable for heat drying	-	-	



CAUTION

• If the load is less than 1 kg, please use the Warm Air programme or the Manual Dry programme (More Time / Less Time). Wool items should be dried using the Wool programme and heatsensitive fabrics including silk, underwear and lingerie should be dried using the Delicate programme. Please comply with the recommended laundry load when you select your desired programme. Otherwise, your clothes may be damaged and the drying results will be poor.

NOTE

- Set program at "Cotton, Normal, Cupboard " option for test in accordance or in conformity with AS/ NZS 2442.1.
- The test results depend on room temperature, type and amount of load, water hardness.
- If the appliance is installed as built under, it may cause performance degradation.
- If the laundry is not spun at a high speed during washing, energy consumption and drying time will increase

Extra Options

= Default

Progr	amme		Dry Mode		Opt	tion
Programme	Dry Level	Off	Normal	Turbo	Hand Iron	Damp Dry Beep
	Extra		•	•		•
Cotton	Cupboard		•	•		•
	Iron		•	•	•	
	Extra		•	•		•
Mixed Fabric	Cupboard		•	•		•
- T GDITO	Iron		•	•	•	
Easy Care	Cupboard		•	•		•
Lasy Care	Iron		•	•	•	
Bulky	/ Item			•		
Jea	ans			•		
To	wel			•		
Quic	k Dry			•		
Sports	s Wear		•			
Deli	cate		•			
Wo	ool	•				
Rack	Dry		•			
Coo	l Air	•				
Warr	n Air		•	•		

Appliance Settings

Setting

Wi-Fi, Beeper, and Brightness settings can be changed.



Wi-Fi (🛜)

Refer to 'SMART FUNCTIONS' for detailed information

Beeper (➪)))

Once the Beeper function is set, the setting is memorized even after the power is turned off.


Brightness (-)

The brightness can be adjusted in 20 % intervals from 0 % to 100 %.

To Set up the Setting


- 1 Turn the appliance on.
- Press the Option button to select the Setting menu.

(1: Up, 2: Down, 3: OK, 4: Back)



3 Select On or Off.

(Set the desired function and press the 3 button to complete the setting.)



4 Press the 4 button to return to the selected drying programme screen.
(If additional settings are necessary, repeat Step 2.)



Option Programme

Favourite

The Favourite option allows you to store a customized dry programme for future use.

- 1 Turn the appliance on.
- 2 Select a programme.
- 3 Select the option or additional programme. (Anti Crease, Dry Mode etc.)
- 4 Press and hold the Favourite option button for three seconds.

The Favourite option is now stored for future use. To reuse the stored programme, select the **Favourite** option and press the **Start/Pause** button.

Delay End

You can use the Delay End option to delay the finishing time of the drying cycle. Maximum Delay End is 19 hours. Minimum Delay End is 3 hours.

- 1 Turn the appliance on.
- Select a programme.
- 3 Press the Delay End button.
- 4 Set time delay hour(s) by pressing the Dry Mode and Dry Level buttons.
- 5 Press the **More Time** button to save the desired finishing time of the drying cycle.
- 6 Press the Start/Pause button.

Drum Light

Whilst the appliance is running it is possible to see inside the drum if you select the Drum Light function.

- Press and hold the Drum Light button for three seconds to turn on or off the Drum Light function.
- The light will be turned off after four minutes.

Child Lock

Use this option to disable the controls. This feature can prevent children from changing cycles or operating the appliance.

Locking the Control Panel

- 1 Press and hold the Child Lock button for three seconds.
- A beeper will sound, and a message will appear on the display.

When the Child Lock is set, all buttons are locked except the Power button.

NOTE

 Turning off the power or completing all cycles will not reset the child lock function. You must deactivate child lock before you can access any other functions.

Unlocking the Control Panel

Press and hold the **Child Lock** button for three seconds.

Dry Mode

This additional program offers the option of saving energy or time.

- Normal: Energy saving option.
- Turbo: Time saving option.

More Time / Less Time

Use these buttons with the Manual Dry programmes to manually increase or reduce the drying time.

Press the **More Time** button to increase the selected programme time by five minutes.

Press the **Less Time** button to decrease the selected programme time by five minutes.

Anti Crease

The Anti Crease option prevents creases that are formed when the laundry is not unloaded promptly at the end of the drying cycle. When **Anti Crease** is selected, the appliance repeatedly runs and pauses, giving you two hours to unload the laundry. If the door is opened during the Anti Crease option, the option is cancelled.

- 1 Turn the appliance on.
- Select a programme.
- 3 Press the Option button and select Anti-Crease.
- 4 Press the Start/Pause button.

Option

Hand Iron

This function keeps the garments more moist than the standard Iron dry level.

- 1 Turn the appliance on.
- **2** Select a programme.
- 3 Press the Dry Level button until Iron is selected.
- 4 Press the Option button and select Hand Iron.
- 5 Press the Start/Pause button.

Damp Dry Beep

With this option, the appliance will beep when the load is ready for ironing.

This allows you to remove faster-drying lightweight items or items that you would like to iron or hang while still slightly damp.

- 1 Turn the appliance on.
- 2 Select a programme.
- 3 Press the Dry level button and select a level.
- 4 Press the Option button and select **Damp Dry Beep**.
- 5 Press the Start/Pause button.
- 6 When the laundry is ready for ironing, the chime will sound for approximately one minute.
- 7 Press the Start/Pause button and open the door.
- 8 Take out laundry which you wish to iron. (Leave the other laundry in the appliance.)
- 9 Close the door and press the Start/Pause button to finish off drying the other items.

Rack Dry (Optional)

The dryer rack is placed inside the appliance, as in the picture below. Remove and discard packing material before use.

The Rack Dry is designed for use with laundry that must be dried flat, without tumbling, including sweaters and delicate fabrics.

- 1 Open the door.
- 2 Insert the hook to the drum centre.



3 Place the dryer rack on the structure above the lint filter and press it to complete assembly.



- 4 Place wet items on top of the rack. Allow space around items for air to circulate.
 - The rack does not move, but the drum will rotate.



- 5 Close the door.
- 6 Turn power on and rotate the knob to select Rack Dry.
- 7 Press the More Time or Less Time button to set the desired time.
- 8 Press the Start/Pause button.

NOTE


 Check the lint filter and remove any lint accumulated from items dried on the rack.

SMART FUNCTIONS

Using LG SmartThinQ Application

Things to check before using LG SmartThinQ

- For appliances with the same or appliances with the
- 1 Check the distance between the appliance and the wireless router (Wi-Fi network).
 - If the distance between the appliance and the wireless router is too far, the signal strength becomes weak. It may take a long time to register or installation may fail
- Turn off the Mobile data or Cellular Data on your smartphone.
 - For iPhones, turn data off by going to Settings → Cellular → Cellular Data.



3 Connect your smartphone to the wireless router.



NOTE

- To verify the Wi-Fi connection, check that Wi-Fi ricon on the control panel is lit.
- The appliance supports 2.4 GHz Wi-Fi networks only. To check your network frequency, contact your Internet service provider or refer to your wireless router manual.
- LG SmartThinQ is not responsible for any network connection problems or any faults, malfunctions, or errors caused by network connection.
- If the appliance is having trouble connecting to the Wi-Fi network, it may be too far from the router. Purchase a Wi-Fi repeater (range extender) to improve the Wi-Fi signal strength.
- The Wi-Fi connection may not connect or may be interrupted because of the home network environment.
- The network connection may not work properly depending on the Internet service provider.
- The surrounding wireless environment can make the wireless network service run slowly.
- The appliance cannot be registered due to problems with the wireless signal transmission. Unplug the appliance and wait about a minute before trying again.
- If the firewall on your wireless router is enabled, disable the firewall or add an exception to it.
- The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.)
- Smartphone user interface (UI) may vary depending on the mobile operating system (OS) and the manufacturer.
- If the security protocol of the router is set to WEP, you may fail to set up the network.
 Please change it to other security protocols (WPA2 is recommended) and register the product again.

Installing LG SmartThinQ

Search for the LG SmartThinQ application from the Google Play Store or Apple App Store on a smart phone. Follow instructions to download and install the application.

NOTE

 If you choose the simple login to access the LG SmartThinQ application, you must go through the appliance registration process each time you change your smartphone or reinstall the application.

Wi-Fi Function

• For appliances with the one or one logo Communicate with the appliance from a smart phone using the convenient smart features.

Dryer Cycle (Remote Start, Download Cycle)

Set or download any preferred cycle and operate by remote control.

Energy Monitoring

The dryer energy usage is affected by the cycle and options so you may see some changes in energy usage from one cycle to another.

Smart Diagnosis™

This function provides useful information for diagnosing and solving issues with the appliance based on the pattern of use.

Push Alert

When the cycle is complete or the appliance has problems, you have the option of receiving push notifications on a smart phone.

Settings

Set the product nickname or delete the registered appliance.

NOTE

- If you change your wireless router, your Internet service provider or your password after registering the appliance, please delete it from the LG SmartThinQ Settings → Edit Product and register again.
- The application is subject to change for appliance improvement purposes without notice to users.
- · Functions may vary by model.

Using Dryer Cycle

Remote Start

Use a smart phone to control your appliance remotely. You can also monitor your cycle operation so you know how much time is left in the cycle.

To Use Remote Start:

- 1 Press the **Power** button.
- 2 Put the laundry into the drum.
- 3 Press and hold the Remote Start button for 3 seconds to enable the Remote Start function
- 4 Start a cycle from the LG SmartThinQ application on your smartphone.

NOTE

- Once the Remote Start mode is enabled, you can start a cycle from the LG SmartThinQ smartphone application. The Dryer cannot be used manually in the home until the Remote Start option is turned off remotely from the application or from the Dryer itself.
- If the door is open, Remote Start is disabled.

To Disable Remote Start:

When the Remote Start is activated, press and hold the **Remote Start** button for 3 seconds.

Download Cycle

Download new and special cycles that are not included in the basic cycles on the appliance.

Appliances that have been successfully registered can download a variety of specialty cycles specific to the appliance.

Only one cycle can be stored on the appliance at a time.

Once cycle download is completed in the appliance, the product keeps the downloaded cycle until a new cycle is downloaded.

RF Radiation Exposure Statement

This equipment shall be installed and used at a minimum distance of 20 cm from the human body.

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit http://opensource.lge.com.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com. This offer is valid for three (3) years from the date on which you purchased the product.

Smart Diagnosis™ Using a Smart Phone

• For appliances with the 🚭 or 🐑 logo Use this function if you need an accurate diagnosis by an LG Electronics customer information centre when the appliance malfunctions or fails


Smart DiagnosisTM can not be activated unless the appliance is connected to power. If the appliance is unable to turn on, then troubleshooting must be done without using Smart DiagnosisTM.

Using Smart Diagnosis™

Smart Diagnosis™ Through the Customer Information Centre

Use this function if you need an accurate diagnosis by an LG Electronics customer information centre when the appliance malfunctions or fails. Use this function only to contact the service representative, not during normal operation.

- 1 Press the **Power** button to turn on the appliance. Do not press any other buttons or turn the programme selector knob.
- When instructed to do so by the call centre, place the mouthpiece of your phone close to the Smart Diagnosis™ icon.



3 Press and hold the More Time button for three seconds, while holding the phone mouthpiece to the icon and Power button.

- **4** Keep the phone in place until the tone transmission has finished. Time remaining for data transfer is displayed.
 - For best results, do not move the phone while the tones are being transmitted.
 - If the call centre agent is not able to get an accurate recording of the data, you may be asked to try again.
- Once the countdown is over and the tones have stopped, resume your conversation with the call centre agent, who will then be able to assist you using the information transmitted for analysis.

NOTE

- The Smart Diagnosis™ function depends on the local call quality.
- The communication performance will improve and you can receive better service if you use the home phone.
- If the Smart Diagnosis[™] data transfer is poor due to poor call quality, you may not receive the best Smart Diagnosis[™] service.

MAINTENANCE

WARNING

 Remove the power plug when you clean the appliance. Not removing the plug may result in electric shock

Cleaning the Lint Filter

Clean the lint filter before each drying cycle. Cleaning the lint filter will reduce drying time and energy consumption.

- 1 Open the door.
- ? Remove the first lint filter.



3 Remove the second lint filter.



- 4 Open both lint filters and remove all the lint with a soft cloth, soft brush or a vacuum cleaner. Do not tap the filter repeatedly as the built in magnet may dislodge and cause a malfunction.
 - Open the first lint filter.



• Open the second lint filter.



5 Rinse away any residual lint under warm, running water.



Dry the lint filters completely, close them and reinsert both lint filters.





NOTE

- Remove moisture from the mesh. Otherwise, the lint filter may be clogged due to water film and the appliance may not operate.
- If the lint filter is not in the appliance, you can not operate the appliance.

Emptying the Water Container

Condensed water is collected in the water container.


Empty the water container after every use. Not doing so will affect the drying performance.

If the water container is full, an error massage appears and a chime will sound while the appliance is in operation. If this should occur, the water container needs to be emptied within the next 30 minutes.

1 Pull out the water container.



2 Empty the water container in the sink.



- 3 Push it back into the appliance.
- 4 Press the Start/Pause button.

Cleaning the Cool Air Inlet Grill

Vacuum the Cool Air Inlet grill 3 – 4 times a year to make sure there is no build up of lint or dirt that may cause improper air flow.




NOTE

- Warm air is expelled through the ventilation grill.
- Adequate room ventilation should be provided to avoid the back flow of gases into the room from units burning other fuels, such as open fires.

Wiping the Moisture Sensor

This device senses the moisture level of the laundry during operation, which means it must be cleaned regularly to remove any build up of lime scale on the surface of the sensor.

Wipe the sensors inside the drum.



A CAUTION

 Do not wipe the moisture sensor with abrasive materials. Always clean the sensor with a dry rough sponge.

TROUBLESHOOTING

The appliance is equipped with an automatic error-monitoring system to detect and diagnose problems at an early stage. If the appliance does not function properly or does not function at all, check the following before you call for service:

Diagnosing Problems

Symptoms	Reason	Solution
Appliance will not turn on.	Power cord is not properly plugged in.	Make sure that the plug is securely plugged into a grounded outlet matching the appliance's rating plate.
	House fuse is blown, circuit breaker has tripped, or power outage has occurred.	Reset circuit breaker or replace fuse. Do not increase fuse capacity. If the problem is a circuit overload, have it corrected by a qualified electrician.
Appliance does not heat.	House fuse is blown, circuit breaker has tripped, or power outage has occurred.	Reset circuit breaker or replace fuse. Do not increase fuse capacity. If the problem is a circuit overload, have it corrected by a qualified electrician.
	Load is not properly sorted.	Separate heavy items from lightweight items. Larger and heavier items take longer to dry. Light items in a load with heavy items can fool the sensor because the light items dry faster.
Clothes take too long to dry.	Large load of heavy fabrics.	Heavy fabrics take longer to dry because they tend to retain more moisture. To help reduce and maintain more consistent drying times for large and heavy fabrics, separate these items into smaller loads of a consistent size.
	Appliance controls are not set properly.	Use the appropriate control settings for the type of load you are drying. Some loads may require an adjustment of the dry level setting for proper drying.
	Lint filter needs to be cleaned.	Remove the lint from the lint filter before every cycle. With the lint removed, hold the lint filter up to a light to see if it is dirty or clogged. With some loads that produce high amounts of lint, such as new bath towels, it may be necessary to pause the cycle and clean the filter during the cycle.

Symptoms	Reason	Solution
	House fuse is blown, circuit breaker has tripped, or power outage has occurred.	Reset circuit breaker or replace fuse. Do not increase fuse capacity. If the problem is a circuit overload, have it corrected by a qualified electrician.
	Appliance is overloaded.	Divide extra large loads into smaller loads for better drying performance and efficiency.
Clothes take too long to dry.	Appliance is underloaded.	If you are drying a very small load, add a few extra items to ensure proper tumbling action. If the load is very small and you are using Sensor Dry programmes, the electronic control cannot properly sense the dryness of the load and may shut off too soon. Use Manual Dry programmes or add some extra wet clothes to the load.
Drying time is not consistent.	Heat settings, load size, or dampness of clothing is not consistent.	The drying time for a load will vary depending on the type of heat used (electric), the size of the load, the type of fabrics, the wetness of the clothes, and lint filter. Even an unbalanced load in the appliance can cause poor spinning, resulting in wetter clothes which will take longer to dry.
	Fabric softener is used incorrectly.	When washing laundry that is to be dried in the appliance, use the correct amount of fabric softener as recommended by the manufacturer of the fabric softener.
Greasy or dirty spots	Clean and dirty clothes are being dried together.	Use the appliance to dry only clean items. Soil from dirty clothes can transfer to the clean clothes in the same or later loads.
	Clothes were not properly cleaned or rinsed before being placed in the appliance.	Stains on dried clothes could be stains that were not removed during the washing process. Make sure that clothes are being completely cleaned or rinsed according to the instructions for your washing machine and detergent. Some difficult soils may require pre-treating prior to washing.

Symptoms	Reason	Solution
Clothes are wrinkled.	Clothes have dried too long (overdried).	Over drying a load of laundry can lead to wrinkled clothes. Try a shorter drying time.
Ciotiles are writikled.	Clothes have been left in the appliance for too long after cycle ends.	Use the Anti crease option.
Clothes are shrinking.	Garment care instructions are not being followed.	To avoid shrinking your clothes, always consult and follow fabric care instructions. Some fabrics will naturally shrink when washed. Other fabrics can be washed but will shrink when dried in the appliance. Use a low or no heat setting.
	Lint filter has not been cleaned properly.	Remove the lint from the lint filter before every cycle. With the lint removed, hold the lint filter up to a light to see if it is dirty or clogged. If it looks dirty, follow the cleaning instructions. With some loads that produce high amounts of lint, it may be necessary to clean the lint filter during the cycle.
Lint is left on clothes.	Laundry has not been sorted properly.	Some fabrics are lint producers (i.e., a fuzzy white cotton towel) and should be dried separately from clothes that are lint trappers (i.e., a pair of black linen pants).
	Appliance is overloaded.	Divide extra large loads into smaller loads for drying.
	Tissue, paper, etc., has been left in pockets.	Check pockets thoroughly before drying clothes.
Excess static in clothes after drying.	Clothes have dried for too long (overdried).	Overdrying a load of laundry can cause a buildup of static electricity. Adjust settings and use a shorter drying time, or use Sensor Dry programmes.
districts after drying.	Drying synthetics, permanent press, or synthetic blends.	These fabrics are naturally more prone to static buildup. Try using fabric softener, or use shorter Manual Dry time settings.

Symptoms	Reason	Solution
	The water container hose or the drain hose is not connected correctly.	Connect the water container hose or the drain hose correctly.
Water leaks.	The door is closed while laundry or foreign substance is caught in the door.	Check if laundry or foreign substance is caught in the door before using the appliance. If water leaks continuously, contact the LG Electronics Customer Information Centre.
Clothes have damp spots after a Sensor Dry programme.	Very large load or very small load. Single large item such as a blanket or comforter.	If items are too tightly packed or too sparse the sensor may have trouble reading the dryness level of the load. Use a Manual Dry programme for very small loads. Large, bulky items such as blankets or comforters can sometimes wrap themselves into a tight ball of fabric. The outside layers will dry and register on the sensors, while the inner core remains damp. When drying a single bulky item, it may help to pause the cycle once or twice and rearrange the item to unwrap and expose any damp areas. To dry a few remaining damp items from a very large load or a few damp spots on a large item after a Sensor Dry programme has completed, empty the lint trap, then set a Manual Dry programme to finish drying the item(s).
	The password for the Wi-Fi that you are trying to connect to is incorrect.	Find the Wi-Fi network connected to your smartphone and remove it, then register your appliance on LG SmartThinQ.
Your home appliance and smartphone is not connected to the Wi-Fi network.	Mobile data for your smartphone is turned on.	Turn off the Mobile data of your smartphone and register the appliance using the Wi-Fi network.
	The wireless network name (SSID) is set incorrectly.	The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.)
	The router frequency is not 2.4 GHz.	Only a 2.4 GHz router frequency is supported. Set the wireless router to 2.4 GHz and connect the appliance to the wireless router. To check the router frequency, check with your Internet service provider or the router manufacturer.
	The distance between the appliance and the router is too far.	If the distance between the appliance and the router is too far, the signal may be weak and the connection may not be configured correctly. Move the location of the router so that it is closer to the appliance.

Error Codes

Symptoms	Reason	Solution
	The door has been opened while the appliance is in operation or the appliance is being operated without the door being closed properly.	Close the door completely. If the icon is not released, call for service.
dE4	Door switch detection is not working properly.	Unplug the power plug and call for service.
	The drum does not have lint filters or the lint filters are not in position inside the drum.	Assemble the lint filters in properly position. If the icon keeps appearing on the screen, call for service.
tE1 tE2 tE4 tE5	Temperature Sensor has malfunctioned.	Unplug the power plug and call for service.
F1	The temperature inside the drum has risen suddenly.	Unplug the power plug and call for service.
LE1	The motor has stopped suddenly.	Check if the amount of laundry exceeds the maximum load capacity. Unplug the power plug and call for service.
LE2 AE	The compressor has stopped suddenly.	Unplug the power plug and call for service.
OE	The drain pump motor has malfunctioned. The surrounding temperature for installation is below zero.	 Unplug the power plug and call for service. The recommended surrounding temperature for installation is 5 – 35 °C.

