


PART NAMES AND LOCATIONS



| No | Description |
|----|----------------------------------|
| 1 | Light |
| 2 | Lighting switch |
| 3 | Cooling room shelves |
| 4 | Vegetable and fruit crispercover |
| 5 | Vegetable and fruit crisper |
| 6 | Freezing drawers |
| 7 | Door balcony |

IN ACCESSORY BAG: USER MANUAL, WARRANTY CARD & Door reversal parts (top hinge and hinge cover)

As the manufacturer holds the authority to redesign or modify its products without notice: Any modifications or upgrades of our products will result in this refrigerator varying slightly from this manual but the functionality will remain the same to that as set out within this manual.

IMPORTANT SAFETY INSTRUCTIONS

⚡ WARNING ⚡

Follow these basic precautions to reduce the risk of fire, electrical shock hazards or injury when operating the refrigerator:

- **This product has been designed for using in a normal domestic environment. It is not intended for commercial use which will void warranty, such as supermarket, food shop, pharmacy, commercial kitchen & etc.**
- Persons with lack of experience and knowledge, reduced physical or mental capabilities, need to be given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- It is critical use this appliance safely. Read all instructions before operating the refrigerator and do not attempt to repair or modify this unit in any way as it can cause harm or void the warranty.
- Please ensure all persons using this appliance are also informed and comply with the details set out within this manual and the product Terms and Conditions.
- When unpacking the appliance for the first time, keep all cardboard and plastic packaging out of reach from children.
- Report any notable defects with the appliance to Chiq or retailer as soon as it is noted. Failure to do so can result in a non-warranty claim. Keep all packaging materials in a safe location until the unit has been installed properly.
- If the power cable is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. It is recommended the power cord is situated in a safe location when operating or transporting the appliance to prevent any damage that may cause electrical shock or fire hazards.
- **DANGER or WARNING:**

This unit is not designed for outdoor installation.

Service of this unit

The installation or any service of the appliance is recommended by a qualified technician or service company.

Ventilation Hazards

Never clean the refrigerator or refrigerator parts with flammable fluids, or store gasoline or any other flammable vapors and liquids in the vicinity of this or any other refrigerator as the gas and/or vapour can cause a fire hazard, explosion or inhalation.

Electrical Connection

Make certain, when installing or moving the unit that the power outlet has been connected to, has been fitted by a qualified electrician and the ground wire has been connected properly to meet the Australian Electrical Standards.

- WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.

- WARNING: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

R600a WARNINGS

NOTE: This model uses R600a flammable refrigerant in its sealed system. The following must be observed for your safety:

R600a Refrigerant Warning

- This appliance contains **0.058kg** R600a refrigerant which is environmentally friendly, but flammable. It does not damage the ozone layer, nor does it increase the greenhouse effect.
 - During transportation and installation, ensure that the tubing of the refrigerant circuit is not damaged.
 - Leaking refrigerant can ignite and may damage the eyes.
 - In the event any damage does occur, avoid exposure to open fires and any device which creates a spark. Disconnect the appliance from the mains power.
 - Thoroughly ventilate the room in which the appliance is located for several minutes.
 - Notify Customer Service for necessary action and advice.
 - The room for installing the appliance must be at least 1 cubic metre per 8 grams of refrigerant. The refrigerant quantity contained in this appliance is listed above in grams; it is also noted on the Rating Plate of the appliance.
- * Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

It is hazardous for anyone other than an Authorised Service Person to carry out servicing or repairs to this appliance. In Queensland the authorized person must hold a Gas Work Authorisation for hydrocarbon refrigerants, before carrying out servicing or repairs which involve the removal of covers.



Warning: Risk of fire/flammable materials

1. Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
2. Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
3. Do not damage the refrigerant circuit.
4. Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
5. Do not store explosive substances such as aerosol cans with a flammable propellant in the appliance.

Disposal

The environment and personal safety must be considered when disposing of this appliance. Please ensure the appliance is taken to a recycle center for safe recycling. DO NOT dispose of the appliance in land fill as the insulation and refrigerant gas contained in these appliances are flammable.

INSTALLATION INSTRUCTIONS

Before Using the Refrigerator

- Remove the exterior and interior packing.
- Before connecting the refrigerator to a power source, let the unit stand upright for approximately 4 hours to mitigate the possibility of a malfunction in the cooling system from improper handling during transportation.
- Clean the interior surface with warm water using a soft cloth.

Installing the Refrigerator

- This appliance is designed to be free standing only, and should not be recessed or built-in.

| W | D | H | A | B | C(°) | E | F |
|-----|-----|------|------|------|-------|----|-----|
| 703 | 703 | 1720 | 1165 | 1360 | 125±5 | 50 | 100 |




Fig. 1




Fig. 2

- **Allow at least 5cm of space between the back and sides of the refrigerator to allow proper air ventilation.** Insufficient space will result in cooling and working life issue and voiding warranty.
- Place the refrigerator on a **leveled/even** floor surface that is strong enough to support the weight of the refrigerator when it is fully loaded to prevent vibrations.
- **Place the refrigerator on a concrete, tile floor or waterproof floor is recommended. The fridge will produce defrost water or condensation moisture, it might cause water damage in some extreme circumstances.**
- **The front feet can be adjusted to level the appliance properly.** Adjust the two front feet to keep the refrigerator leveled or elevated.
- Situate the refrigerator away from direct sunlight and sources of direct heat (stove, heater, radiator, etc.). Direct sunlight may also affect the acrylic coating and heat sources may cause an increase power consumption.
- This unit is not designed for outside installation.
- Avoid situating the refrigerator in moist OR **pest infestation** areas.
- Plug the refrigerator into dedicated, properly installed-grounded wall outlet. Do not under any circumstances cut or remove the third (ground) prong from the power cord. Any questions concerning power and/or grounding should be directed toward a certified electrician or an authorized service center.
- After plugging the appliance into a wall outlet, turn the unit on and allow the unit to


cool down for 4-6 hours before placing food in the refrigerator.

- Do not place heavy items on the top of this appliance.

ENERGY SAVING TIPS

- Allow hot foods to cool to room temperature before placing in the refrigerator. Overloading the refrigerator forces the compressor to work harder. Foods that freeze too slowly may lose quality, or spoil.
- Be sure to wrap foods properly, and wipe containers dry before placing them in the refrigerator. This cuts down on frost build-up inside the refrigerator.
- Organize and label food to reduce door openings and extended searches. Remove as many items as needed at one time, and close the door as soon as possible.

OPERATING INSTRUCTIONS



START

When the refrigerator system is connected to the power supply for the first time, all icons on the display panel will be on for 2s, when all the doors are close, the display will turn off automatically if no key operation within 3 minutes.

It will light up if the refrigerator door is opened or any key is pressed.

❖ Temperature setting

The number only shows the setting temperature which might vary to the exact temperature inside the unit.

Fridge compartment temperature setting

Press the 'Fridge' button, with the fridge temperature digits flickering, and then press the 'Fridge' key to adjust the temperature, finally press the OK to validate the above

temperature setting.

Keep pressing the **fridge** key to set temperature setting cycles as following: 5°C→6°C→7°C→8°C→**OF**→2°C→3°C→4°C→5°C. Stop pressing the key when it reaches the desired temp. After 5 seconds, the set temperature will be active.

OF indicates the fridge compartment is switched off, and when the OF function takes effect, the fridge compartment will stop cooling.

Be sure to take all food out of the fridge compartment before setting this function.

Freezer compartment temperature setting

Press the 'Freezer' button, with the freezer temperature digits flickering, and then press the 'Freezer' key to adjust the temperature, finally press the OK to validate the above temperature setting

Keep pressing the **freezer** key to set temperature setting cycles as following:

-18°C→-17°C→-16°C→-24°C→-23°C→-22°C→-21°C→-20°C→-19°C→-18°C.

Stop pressing the key when it reaches the desired temp. After 5 seconds, the set temperature will be active.

❖ Fast cooling mode

When the Fast-cooling function is enabled, the fridge temperature will be set at 2°C,

Turn on Fast cooling mode

Press the Function key till the Fast cooling is flashing, then quickly press the OK key to confirm. If the OK key is not pressed within 5s, the setting won't be changed. The Fast cooling symbol will stay on when it is active properly.

Turn off Fast cooling mode

Press the Function key till the Fast cooling is flashing, then quickly press the OK key to confirm. The fast cooling symbol will disappear when it is turned off.

❖ Fast Freezing mode

When the Fast Freeze function is enabled, the freezer temperature will be set at -32°C, and after 26 hours of running, the Fast Freeze function will be turned off automatically. Cooling down the freezer temperature in a rapid manner is beneficial to the prevention of food nutrition against lost and the preservation of freshness.

Turn on Fast Freeze mode

Press the Function key till the Fast Freeze is flashing, then quickly press the OK key to confirm. If the OK key is not pressed within 5s, the setting won't be changed. The Fast Freeze symbol will stay on when it is active properly.

Turn off Fast Freeze mode

After a cumulative running period of 26 hours, the Fast Freeze function will be turned off automatically.

Or press the Function key till the Fast Freeze is flashing, then quickly press the OK key to confirm. The smart symbol will disappear when it is turned off.

❖ Vacation Mode

Under vacation mode, fridge compartment is set to 14°C and the temperatures setting cannot be changed.

Be sure to take all food out of the fridge compartment before setting this function.

Turn on vacation mode

Press function key until vacation symbol is flashing and then click "OK" to enter this function.

Turn off vacation mode

Press function key until vacation symbol is flashing and then click "OK" to quit this function.

❖ Smart mode

When smart mode is on, the temperature of the fridge compartment is set at 4°C, and freezer compartment at -18°C.

Under the Smart mode, the refrigerator is running more efficiently and with better performance.

The fridge and freezer temperature setting can't be changed when smart mode is active.

Turn on Smart function

Press the Function key till the Smart symbol is flashing, then quickly press the OK key to confirm. If the OK key is not pressed within 5s, the setting won't be changed. The smart symbol will stay on when it is active properly.

Turn off Smart function

Under the Smart mode, press the Function key till the Smart symbol is flashing, then quickly press the OK key to confirm. The smart symbol will disappear when it is turned off.

❖ Door open alarm

If the refrigerator door is opened for more than 3 minutes, buzzer alarm will be continuously beeping. It can be stopped by pressing any key button but will be restored after 3 minutes if the door keeps opening.

The alarm will stop when the door is closed properly.

❖ Power cut memory

In the case of power failure, the refrigerator will maintain the previous setting when the power supply is restored.

❖ Power-on delay

In order to protect the compressor from being damaged in the case of short-time power failure (i.e., less than 5 minutes), the compressor will not be started immediately after it is powered on. But it will restart after power comes back on for more than 5 minutes.

❖ Over-temperature alarm (only after power outage)

When the refrigerator system is powered on, if the freezer sensor temperature is higher than -10°C, digits of the freezer zone get flickering on the display. The freezer

temperature can be displayed when any key is pressed, and the normal display will be restored when any key is pressed again or after 10s.

❖ **Fault alarm**

In case E0, E1, E2, EH, or EC is displayed on the display panel, it indicates fault with the refrigerator. Please contact CHIQ service centre for a service call.

Notes

Large quantities of food stored in the appliance or directly in front of the air vent will hinder the cooling efficiency of the appliance as this can affect the airflow.

Change the thermostat settings in the fridge or freezer compartment, allow 6 hours for temperature to stabilize between adjustments.

Do not keep opening and closing the door which will increase the temperature in the unit.

Please note different sections of refrigerator compartment may be warmer or cooler than others – typically the back wall and bottom lowest shelf will be the coolest, the top door rack will be the warmest. To avoid frost bite, please don't put raw vegetables too close to the coolest area.

GENERAL CARE AND MAINTENANCE

Cleaning the Refrigerator

- Upon installation of your new appliance, it is recommended that it be cleaned thoroughly and properly maintained thereafter.
- Turn off the refrigerator and then unplug the unit from the wall outlet.
- Remove all food content before washing the inside with a damp cloth soaked in lukewarm water and dishwasher liquid. **Don't use any chemical detergent which might damage coating of the fridge.**
- Be sure to keep the door gasket (seal) clean to keep the unit running efficiently as improper cleaning can cause the seal to dislodge and tear.
- Dry the interior and exterior with a soft cloth.

Vacation Time

- Turn off the refrigerator first and then unplug the unit from the power point.
- Remove all food.
- Clean the refrigerator.
- Leave the lid open slightly to avoid possible formation of condensation, mold, or odors.
- Use extreme caution in the case of children. The unit should not be accessible to child's play.
- **Short vacations:** Leave the refrigerator operating during vacations of less than three weeks.
- **Long vacations:** If the appliance will not be used for several months, remove all food and unplug the power cord. Clean and dry the interior thoroughly. To prevent odour and mold growth, leave the door open slightly: blocking it open if necessary.

Repositioning and Relocating the Refrigerator

- Unplug the power cord from the wall outlet.
- Remove all the food and drinks.
- Securely tape down all loose items inside your refrigerator.
- Tape the doors to be closed securely.
- It is recommended that the refrigerator stays in the upright position during transportation. But if it is laid down for transport purpose, please lift it up immediately after the job is done. Please wait for at least 24 hours before putting the power.


Door reversal instruction

Door reversal job requests some spare parts which are in the accessory bag, top hinge and hinge cover.


The following tool is required, flat screwdriver, phillips screwdriver, adjustable spanner, socket wrench and 8mm socket.

Reversing the Door


- How to disassemble the fridge/freezer door.
- 1. a. Screw off the hinge cover screw, remove the hinge cover, and insert the communication wire into the hole on the cabinet top.




- b. Remove the 4 screws of the upper hinge cover, remove the hinge cover, and pry up the door bushing and small end cap cover on the door.




- c. Insert the door bushing and door communication wire into the hole on the door, and then put on the small end cap cover.




- d. Screw off the 2 screws as shown below to remove the hole cover on the cabinet top, get the cabinet communication wire out of the hole; Pry up the small end cap cover on the door, and get out the door bush and door communication wire.




- e. Insert the door bush into the round hole on the door, and put on the small end cap cover.



- f. Move the fridge door upward by over 50mm to remove the door.




- 2. a. Screw off the 3 screws of the middle hinge cover, and then remove the middle hinge.




- b. Move the freezer door upward by over 50mm to remove the door.



c. Remove the adjustable front feet under the lower hinge, and screw off the 4 screws of the lower hinge to disassemble the lower hinge.




In this way, the door disassembly is finished.



- How to assemble the door and lower hinge accessories correspondingly on the opposite side.


a. Take the door bushing out as shown below, and assemble it to the corresponding position on the opposite side.



b. Screw off the screws of the stopper as shown below, and assemble them to the other side of the door.




c. Remove the axle and two stoppers on the lower hinge, and assemble them to the position as shown below.




- How to assemble the fridge door and freezer doors to the opposite side.


1. a. Remove the adjustable front foot as shown below by hand, assemble the lower hinge to the other side of the cabinet, and fix the screws.



b. Assemble the shorter adjustable front foot to the lower hinge side, and adjust the height of the foot to make the refrigerator level.




2. Install the freezer door, turn the middle hinge by 180 °, assemble it to the other side of the cabinet, and screw up the 3 screws to fix the middle hinge.




3. Install the fridge door, assemble the left upper hinge to the other side of the cabinet, and use a tool to screw up the 4 screws to fix the upper hinge. Then, connect the door communication wire and the cabinet communication wire, install the left upper hinge cover, and fix it using a screw.
4. Assemble the hole cover to the other side of the cabinet, and screw up the hole cover.



The door disassembly is finished.



The doors are opened from the left side.



The doors are opened from the right side.



Double check that the door is aligned correctly and all the seals are closed on all sides. If necessary, re-adjust the levelling feet.

NOTE: If you want to have the door swing reversed, we recommend you to contact a qualified technician. You should only try to reverse the door yourself if you believe that you are qualified to do so. All parts removed must be saved to do the reinstallation of the door. You should rest the fridge freezer on something solid so that it will not slip during the door change process. Do not lay the fridge freezer flat as this may damage the coolant system. Ensure the fridge-freezer is unplugged and empty. We recommend that 2 people handle the fridge-freezer during assembly.

TROUBLESHOOTING GUIDE

| Problem | Solution |
|---|---|
| The fridge has no power | <ul style="list-style-type: none"> ➤ Power cord isn't plugged in properly. ➤ The circuit breaker tripped or a blown fuse. ➤ Try a different power point. |
| The light is not working. | <ul style="list-style-type: none"> ➤ There is no light in freezer compartment, only fridge compartment has light. ➤ Make sure the power is connected to the unit. |
| Compressor runs all the time | <ul style="list-style-type: none"> ➤ The room temperature is hotter than normal. ➤ A large amount of food has been added to the refrigerator. ➤ The door is opened too often. ➤ The door is not closed completely. ➤ The temperature control is not set correctly. ➤ The door gasket does not seal properly. ➤ The refrigerator does not have the correct clearances. ➤ The refrigerator has recently been disconnected for a period of time. 6+ hours are required for the refrigerator to cool down completely pending on operating conditions. |
| Freezer is too cold and refrigerator is too warm | <ul style="list-style-type: none"> ➤ Change freezer air flow setting to min position ➤ The fridge might need a manual defrost due to too much moisture went into the freezer part and blocked the air channel. To do so, Keep food in a container with ice bag or another fridge if it is available. Keep both doors opening and unplug the power cord for 24 hours. Then turn on the unit and it will work properly again. |
| Temperature inside the refrigerator is too warm. | <ul style="list-style-type: none"> ➤ Temperature control is set incorrectly. Turn the control to a cooler setting and allow several hours for the temperature to stabilize. ➤ Change freezer air flow setting to min position. ➤ Door is kept open too long or is opened too frequently. Warm air enters the refrigerator every time the door is opened). Open the door less often. ➤ The door is not closed completely. ➤ The door gasket does not seal properly. |

| | |
|--|--|
| Temperature inside the refrigerator is too cold. | <ul style="list-style-type: none"> ➤ Freezer control incorrectly set. Set back to mid position. ➤ Temperature control is set too cold. Turn the control to a warmer setting and allow several hours for the temperature to stabilize. For example , change the setting to No. 1. |
| Temperature of external refrigerator side walls are warm. | <ul style="list-style-type: none"> ➤ The exterior refrigerator walls can be as much as 15-20 degrees warmer than room temperature. This is normal while the compressor works to transfer heat from inside the refrigerator cabinet to the condenser behind the refrigerator side walls. |
| Popping or cracking sound when compressor comes on. | <ul style="list-style-type: none"> ➤ Metal parts undergo expansion and contraction, as in hot water pipes. This is normal. Sound will level off or disappear as refrigerator continues to run. |
| Bubbling or gurgling sound, like water boiling. | <ul style="list-style-type: none"> ➤ Refrigerant (used to cool refrigerator) is circulating throughout the system. This is normal operation. |
| Vibrations. | <ul style="list-style-type: none"> ➤ Check the refrigerator is on a level/even surface. ➤ Refrigerator rocks on the floor when it is moved slightly. Be sure floor can adequately support refrigerator. ➤ Level the refrigerator by putting wood or metal shims under part of the refrigerator. ➤ The refrigerator is touching the wall. Re-level the refrigerator and move it from the wall. See “Installation Instructions”. |
| Moisture forms on inside refrigerator walls. | <ul style="list-style-type: none"> ➤ Weather is hot and humid, which increases internal rate of frost build-up. This is normal. ➤ Door is slightly open. ➤ Door is kept open too long, or is opened too frequently. Open the door less often. ➤ The door is not sealed properly. |
| Moisture forms on outside of refrigerator. | <ul style="list-style-type: none"> ➤ Door is slightly open, causing cold air from inside the refrigerator to meet warm moist air from the outside. |
| The doors will not close properly. | <ul style="list-style-type: none"> ➤ The refrigerator is not on a level surface. ➤ The gasket/s may be dirty or not properly maintained. Clean the seals and make sure they are dry before closing the door/s. ➤ The storage basket and/or shelves are out of position. |

For any enquiries, please call the CHiQ Customer care on: 1300 796 688