




 **The appliance should be installed by qualified personnel only. Each step must be carried out and checked in full in the order specified.**

Validity


These installation instructions apply to the following models:

Model designation	Model number	Type	Frameless, for surface-mounted installation	Frameless, for flush installation
GK11TIFK FullFlex	31062	GK11TIFKZ	GK11TIFKZ	GK11TIFKZ
GK11TIFK FullFlex	31062	GK11TIFKZS	GK11TIFKZS	GK11TIFKZS
CookTopInduction V6000 FullFlex	31134	CTI6T-31134	CTI6T96FKTFHD	CTI6T96FKTFHD
CookTop V6000 I906 FullFlex				

General notes

 **If installing into a combustible material, the guidelines and standards for low-voltage installations and fire protection must be strictly observed.**

Identification plate



1 Identification plate with serial number (SN)

► Affix the second identification plate (supplied) in an accessible position behind the front of the fitted cabinet beneath the appliance.

Installation accessories supplied

Flush installation:

Designation	Art. no.
Cementing-in instructions	J004130
Sealing strip set	H63283
Spacer set	H60330

Accessories

Flush installation:

Designation	Art. no.
Ventilation protective plate set for niche width 900 mm	H61085
Steel angle set, installation dimension 90	H63775
Intermediate support kit for the flush-mounted combination of several hobs (contains two intermediate supports)	H63789
Instant adhesive for installation of the steel angle (50 ml)	B11657
Straight mixing nozzle	B11656
TREMCLEAN isopropyl alcohol (1000 ml)	1056609
Black silicone FA880 (310 ml)	B11555
Anthracite silicone FA880 (310 ml)	B11556
White silicone FA880 (310 ml)	1031313
Stone grey silicone FA880 (310 ml)	1031314
Marble smoothing agent AA320 (1000 ml)	B11557
Fugenboy (silicone finishing tool)	B75158



Electrical connection




Electrical connections must be carried out by qualified personnel in accordance with the guidelines and standards for low-voltage installations and the specifications of the local electricity supply companies. Refer to the identification plate for information on the required mains voltage and current type.


A plug-in appliance may only be connected to a socket outlet with earthing contact, installed according to specifications. An all-pole mains isolating device with 3 mm contact opening should be provided in the house wiring system. Switches, plug and socket devices, circuit breakers and fusible cut-outs which are accessible after installation and which have all-poles switching are permissible as isolating devices. Effective earthing and separately installed neutral and earth conductors ensure safe and fault-free operation. After installation, live parts and cables with basic insulation must not be accessible. Check old installations.

- If the appliance is installed any other way, the results will also vary with the changed power output.
- If the hobs are used at an altitude of over 2,000 metres, a reduced performance must be expected.


The appliance is equipped with a connection cable which must be connected to an on-site junction box.



CH/EU/TR/IL/LB/RU/UA/AU/NZ



GB/HK/SG/CN/TH/VN



E35/U0 error message



**Incorrect connection:
Pole conductor connected to connection terminal for neutral conductor.**

Quickly disconnect the appliance from the mains!




Ventilation



For models 31062 and 31134, the installation of a ventilation protective plate with seal is strongly recommended.


For installation of a V-ZUG induction hob, the following minimum requirements apply:

1. The hot air exhaust should be provided by a ventilation slit of $\geq 2 \text{ mm}$ at the front.
2. A space of $\geq 10 \text{ mm}$ in height is required beneath the appliance.
3. Not only exhaust air but also replacement air in the cabinet should be taken into account. There are different ways to do this, including:
 - a) The rear panel of the base unit must be open around the work surface cut-out to guarantee continuous air circulation through the ventilation slits. The air must be drawn in from outside the cabinet and be able to circulate freely from inside the cabinet to the hob. The lower plinth must not be hermetically sealed. This can be achieved through a shadow gap at the plinth panel or through the use of a ventilation grille.
 - b) Alternatively, a concealed fresh air supply can ensure air circulation inside the cabinet. In order that enough cold air can be drawn in, there must be a continuous circulation of fresh air that extends outside the cabinet. The lower drawer panel should therefore not hermetically seal the cabinet.



Recommendation

If the hob is being used at the power limit, a reduction in power after a certain amount of time is normal. All induction hobs available on the market can be observed to work in the same way. Should, through cooking behaviour, such an instance occur more often, performance can be improved by optimizing ventilation. To this end, the installation of a ventilation protective plate with seal is generally recommended.



Ventilation protective plates only achieve the desired effect with the seal in place. The foam seals are available separately so that ventilation plates from other manufacturers can be retrofitted.

General information about installation



The distance from the appliance cut-out to flammable walls (left, right and rear) must be $\geq 50 \text{ mm}$. Parts such as side walls and reinforcing strips which protrude into the installation space under the cooking zone must be made of non-combustible materials.

It is recommended that a distance of 20 mm be maintained between the underside of the appliance tray and any part of the cabinet beneath that is made of combustible material. If a drawer is installed directly underneath – and if the tray can be reached from below without the aid of tools – touch protection must be used. The ventilation protective plate set (see Accessories) is recommended for this purpose.

- The worktop must be flat so that it is sufficiently sealed against the ingress of liquids.
- In order to guarantee good ventilation, a space of at least 10 mm in height is necessary beneath the appliance.
- A cabinet element with a width of 900 mm is recommended for the base element.




Surface-mounted installation with DualDesign

The layout of the hob to be fitted may differ from the hob illustrated!



For surface-mounted installation, use adjusting brace set H61548. The adjusting brace set is not included in the scope of delivery.



* The required clearance must be observed!

- 2** Front and rear struts are reinforced on the underside. The strut width is determined by the producer of the stone worktop. The minimum strut width can vary according to the property of the stone.

Type designation	A Depends on producer	B	H	Corner radius Ra/Ri
GK11TIFKZ, GK11TIFKZS CTI6T96FKTFHD	≥40 mm	≥82 mm	72 mm	5/2 mm

- A** Worktop depth
B Required clearance for service replacement over the entire cut-out area.
H Dimension from the top of the work surface to the underside of the hob
Ra Outer corner radii of cut-out
Ri Corner radii of appliance
S Drawer/Cabinet
T Ventilation protective plate
U Air inlet


Installation

1. Create an accurate installation cut-out.
2. Stick the sealing tape to the underside of the glass.
3. Carefully put the appliance in the installation cut-out and press against the worktop with sufficient overlap.



Flush installation with DualDesign

The layout of the hob to be fitted may differ from the hob illustrated!



* The required clearance must be observed!

- Front and rear struts are reinforced on the underside. The strut width is determined by the producer of the stone worktop. The minimum strut width can vary according to the property of the stone.

Type designation	A Depends on producer	B	H	Corner radius Ra/Ri
GK11TIFKZ, GK11TIFKZS CTI6T96FKTFHD	≥40 mm	≥150 mm	76 mm	5/2 mm

- A** Worktop depth
B Required clearance for service replacement over the entire cut-out area.
H Dimension from the top of the work surface to the underside of the hob
Ra Outer corner radii of cut-out
Ri Corner radii of appliance
S Drawer/Cabinet
T Ventilation protective plate
U Air inlet

Installation

- Create an accurate installation cut-out.
 - The mounting surface can be reamed out or created by installing wood/stone supports or using the steel angle set (see Accessories).



Access to the appliance from below via the entire cut-out area must be guaranteed. For servicing purposes, the induction generator can be removed from below with the mounting plate. It must be possible to unscrew the contact-proof covers from below.


- Prepare the cut-out and appliance in accordance with the specifications in the enclosed cementing-in instructions.
- Carefully cement the appliance in and leave the silicone sealant to dry for at least 24 hours.
- Connect to the electrical mains connection before inserting the appliance, if necessary.



Installing with ventilation protective plate with a 2 mm ventilation gap at the front



A protective plate with seal is necessary for the adequate ventilation of the hob.
The distance X between the underside of the appliance and the protective plate must be ≥ 10 mm.



Type designation	X	H	Remarks
GK11TIFKZ, GK11TIFKZS, CTI6T96FKTFHD	14 mm	72 mm	Surface-mounted installation
GK11TIFKZ, GK11TIFKZS, CTI6T96FKTFHD	10 mm	76 mm	Flush installation

H Dimension from the top of the work surface to the underside of the hob (ventilation opening).