



# OWNER'S MANUAL

# DISHWASHER CHINE

Please read this manual carefully before operating your dishwasher. Retain it for future reference.

LD-1419W(L,M,T,B,C,D)2



|                                 |    |
|---------------------------------|----|
| SAFETY AND CAUTION              | 3  |
| INSTALLATION INSTRUCTIONS       | 5  |
| PARTS NAME                      | 9  |
| FUNCTION OF CONTROL BUTTON      | 10 |
| BEFORE USING FOR THE FIRST TIME | 12 |
| HOW TO USE AND OPERATE          | 13 |
| OPERATING SEQUENCE              | 20 |
| PROGRAM                         | 20 |
| USER MAINTENANCE INSTRUCTIONS   | 21 |
| TROUBLE SHOOTING GUIDE          | 22 |
| SPECIFICATION                   | 25 |

# S **AFETY AND CAUTION**

## **IMPORTANT SAFETY INSTRUCTIONS**

**⚠ WARNING** - When using your dishwasher, follow basic precautions, including the following:

- Please read this manual carefully before using the dishwasher for the first time.
- This manual contains very important notes regarding the installation, use and maintenance of your dishwasher.
- The manufacturer can not be responsible for problems caused by ignoring these safety and caution instructions.
- This dishwasher is designed for normal household use.
- Do not use the dishwasher for industrial and commercial use, or other purpose.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Check packaging and dishwasher immediately for signs of transport damage. If the appliance is damaged, do not put it into use but contact your supplier without delay.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

### **■ During installation**

- Electrical connection must be in accordance with the rating label.
  - Electrical safety is only guaranteed when the earth system of your house is in accordance with the related local regulations. (Do not use an extension cable or cord.)
  - If the hot water exceeds 65°C, adjust the water heater setting. If the hot water temperature can not be maintained below 65°C, the dishwasher must be connected to cold water.
  - If power supply cord is damaged, it must only be replaced by the manufacturer or its service agent or a similar qualified person in order to avoid a hazard.
  - This appliance must be positioned so that the plug is accessible.
- The appliance is to be connected to the water mains using new hose-sets and that old hose-sets should not be reused.
  - The door should not be left in the open position since this could present a tripping hazard

### **■ During use**

- Only suitable household utensils should be placed in the dishwasher. (Please avoid utensils; that are non-heatresistant, metal decorated, etc.)
- Do not use any kinds of solvent in your dishwasher. They may cause an explosion or fire.
- Do not spray water on the appliance. It may cause the failure of electric parts or electric shock.
- Do not push down or sit on the inner door when the door opened. It may cause the deformation or failure of your dishwasher.
- Do not use the detergent for hand washing. The detergent for dishwasher should be used for normal operation.
- This appliance is fitted with a safety function that automatically stops the operation of the dishwasher when it is exposed to heavy disturbance on its mains.
- Dishwasher detergents are strongly alkaline. They can be extremely dangerous if swallowed. Avoid contact with skin and eyes and keep children away from the dishwasher when the door is open. Check that the detergent receptacle is empty after completion of the wash cycle.

### **■ Child Safety**

- Controls may be locked using “Child Lock” mode to prevent from all the setting from being changed by a child.
- Keep children away from detergents and rinse-aids.
- Do not allow children to operate the dishwasher.
- Young children should be supervised to ensure that they do not play with the appliance.

# **S**AFETY AND CAUTION

## **CAUTION** concerning the Power Cord

Most appliances recommend they be placed upon a dedicated circuit; that is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to be certain.

Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized servicer.

Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance.

## **CAUTION** The instructions shall state the substance of the following :

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

## **SAVE THESE INSTRUCTIONS**

### **GROUNDING INSTRUCTIONS**

This appliance must be grounded. In the event of a malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current. This appliance is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is installed and grounded in accordance with all local codes and ordinances.

**WARNING** - Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service representative if you are in doubt whether the appliance is properly grounded. Do not modify the plug provided with the appliance; if it will not fit the outlet have a proper outlet installed by a qualified electrician.


# INSTALLATION INSTRUCTIONS

## ⚠ WARNING

A qualified electrician/plumber or competent person should carry out any electrical/plumbing work required to install this appliance.

### Step 1 : PREPARE CUPBOARD OPENING

- 1 This dishwasher is designed to fit the size shown as below.
- 2 Select a location as close to sink as possible for ease of connection to the water and drain pipes.
- 3 To ensure good drainage, the dishwasher should not be installed more than 3 meters away from the sink.
- 4 If dishwasher is installed in a corner, a minimum of 5cm of space is required between the washer and an adjacent cabinet or wall.



Any bare wood surrounding the dishwasher should be sealed with a waterproof paint or sealant to prevent swelling.

### Step 2 : PREPARATION FOR ELECTRICAL WIRING

## ⚠ CAUTION

For personal safety, remove house fuse or open circuit breaker before installation. Do not use an extension cord or adapter plug with this appliance. Electrical and earthing connections must comply with the national electrical code/provincial and municipal code and/or other local codes.

- 1 This appliance must be supplied with correct rating voltage and hertz as shown on instruction manual, and connected to an individual, properly earthed branch circuit, protected by a minimum 15 amp circuit breaker or time delay fuse. Wiring must be 2 wire with Earth.
- 2 The power plug must be in a accessible location adjacent to and not behind the dishwasher and within 1.2 meters of the dishwasher side.(See page 7 Fig.A)
- 3 The power plug must be correctly earthed, if in doubt, have it checked by a qualified Electrician. No other appliance should be connected to the same plug outlet by a double adapter or similar plug.

## Dangerous voltage

**5036**




To indicate hazards arising from dangerous voltages.

*Note – In case of application in a warning sign the rules according to ISO 3864 shall be adhered to.*

# INSTALLATION INSTRUCTIONS

## Step 3 : PREPARING THE DISHWASHER FOR INSTALLATION

- 1 Lay the dishwasher on its back.
- 2 Adjust the legs to the required height as shown in below figure.




## Step 4 : INSTALLING THE DISHWASHER IN CUPBOARD

- 1 Before sliding the dishwasher into the cupboard opening, all necessary height and balancing adjustments should be made using a spanner.
- 2 Slide the dishwasher into the cabinet opening carefully. Make sure that the drain hose inside the cabinet is not kinked or stretched.

### ⚠ CAUTION

If the height of the cupboard is below 850mm, you should remove the top table by unscrewing the 2 screws. (Two of rear)



# INSTALLATION INSTRUCTIONS

## Step 5 : DRAIN LINE CONNECTION

- 1 If the end of drain hose does not fit to the drain line, use a rubber connector(not supplied) that is resistant to heat and detergent.
- 2 This should be available from a plumbing shop or DIY merchants.
- 3 There are two typical connections as shown in Figure A, B.

The “S” trap spigot must be drilled out cleanly and free of obstruction to its maximum internal diameter, if used for drainage.

To prevent siphoning, one of the following methods must be used:

- When the drain hose is connected to a sink “s” trap or waste disposal unit, the hose must be looped up to the underside of the bench top and secured.




Fig. A

- When the drain hose is connected to a separate standpipe, it is essential that an airtight connection be made.

Refer to Fig.B





Fig. B : Drainage connection - stand pipe.

## Drain hose Extension

Extend drain hose as shown below.



## ⚠ CAUTION

When you connect or extend drain hose, make sure that drain hose is not kinked. (Bends should have a 40 mm radius.)

# INSTALLATION INSTRUCTIONS


## Step 6 : WATER SUPPLY CONNECTION

- 1 Connect the water supply hose to the water tap as shown.(Some models consist of an inlet valve and hose.) This dishwasher may be fed with either hot or cold water. If the water can not be maintained below 65°C, the dishwasher must be connected to cold water.

- 2 When connecting, the sealant tape or sealing compound to avoid water leaks.

Make sure that the line is not kinked or sharply bent.

The new hose-sets supplied with the appliance are to be used and that old hose-sets should not be reused.



## Step 7 : FINAL CHECK AND ASSEMBLING

- 1 Securely hand tighten supply hose to the water supply.  
Plug the power supply cord into an earthed electrical point and switch on.
- 2 After installing and prior to using the dishwasher with crockery, we recommend that you use the dishwasher on 'Quick' mode to rinse through. At this stage it is useful to ensure that there are no operating problems or water leaks.

When the dishwasher is used for the first, there may be a loud noise, if this happens, turn off the power and restart the dishwasher.

## Step 8 : HOW TO LEVEL THE DISHWASHER

After installing the dishwasher, you may notice a slight sticking of the door to the dishwasher, when you open or close the door. If this does happen you need to adjust the level of the dishwasher.

### Case 1. In case the door is slanted to the right




Fig. C

- If the door slants to the right, see fig. C and follow these instructions:
  - 1) Unscrew(counter-clockwise) the left leg of the back side and correct the level.
  - 2) Check the opening of door and repeat if necessary until the door opens and closes properly.
- When the product is correctly leveled, There should be no slant , stickiness or friction sound.

### Case 2. In case the door is slanted to the left






Fig. D

- If the door slants to the left, see fig. D and follow these instructions:
  - 1) Check the opening of door if there still remains sticky or friction sound.
  - 2) Check the opening of door and repeat if necessary until the door opens and closes properly.
- When the product is correctly leveled, There should be no slant , stickiness or friction sound.



1. Control Panel
2. Door Handle
3. Front Cover
4. Lower Cover
5. Display Window
6. Power Button
7. Drain Hose
8. Inlet Hose
9. Power Cord

10. Adjustable Leg
11. Upper Rack
12. Cutlery basket
13. Detergent And Rinse Aid Dispenser
14. Vapor Vent Cover
15. Upper Spray Arm
16. Lower Spray Arm
17. Filter ASM
18. Lower Rack



### ① Process Indicator

- Indicates current program phase.
- The **Wash, Rinse** and **Dry** lamps will flash during each phase of washing process.
- The **Clean** lamp flashes for 4 minutes at the end of the cycle.

### ② Strong

- For a stronger wash action, press and hold the course button for 3 seconds. The **Strong** lamp will illuminate. (Eco50, Gentle, Quick)

### ③ Rinse Refill Indicator

- **Rinse** : Refill with rinse aid when the lamp turns on.

### ④ Half Load

- In case of small load, use upper or lower rack only to save energy.
- With each press, you can select the **Upper** or **Lower** rack only.
- In case you don't select this button, the machine always operates the vario washing, which operate upper and lower spray arm alternately.


### ⑤ Child Lock & Extra Hot Indicator



- Lamp will turn on when the Child Lock setting is on.
- Lamp will turn on when the Extra Hot setting is on.

### ⑥ Time Left

- Before starting, the display window shows the running time of the selected program.
- After starting, the display window shows the remaining time.
- If the dishwasher has an error, the error type is displayed. "OE", "FE", "IE", "EI", "HE", "CE", "LE", "tE"
- If these error letters are displayed, please refer to the trouble shooting guide page 23 and follow the guide.



### ⑦ Delay Start

- If you want to delay the start of selected program, press this button.
- Pressing this button to increase the starting time by 1 hour increments.
- The delay start time can be adjusted from 1 hour to 19 hours.

### ⑧ Program

- Press the cycle that corresponds to your desired wash cycle.

### ⑨ Extra Hot

- If you select the Extra Hot function, the operating temperature will be up to 80°C. (Dual Intensity, Auto, Eco50)

### ⑩ Beep On/Off

- The dishwasher must be switched on.
- The beep on/off function can be set by pressing the **Eco** and **Gentle** button simultaneously for a few seconds while the dishwasher is in operation.
- The beep on/off function is automatically canceled when power failure occur.

### ⑪ Child Lock

- Used to lock or unlock the control buttons to prevent all the setting from being changed during the cycle.
- To activate or release the **Child Lock** function, press the **Gentle** and **Quick** buttons simultaneously for a few seconds while the dishwasher is in operation.
- All controls will be disabled except the **Child Lock** and **Power** buttons.
- Turning off the dishwasher will not reset the **Child Lock** function. You must release the **Child Lock** before you can operate the dishwasher.

### ⑫ Power

- For operating, press this button first for power on.
- After operating, this button automatically switches off for safety and energy saving.
- In case of irregular surge disturbance to the machine, the power may be automatically turned off for safety.

# **B**EFORE USING FOR THE FIRST TIME

## **1. Adding Rinse Aid**

### **■ For filling**

To fill the Rinse Aid chamber, rotate the round cap counter clockwise and remove. Fill the container to the maximum level with a good quality Rinse Aid, then replace and lock the cap. The Rinse Aid is automatically dispensed during the final rinse cycle.

The dosage is factory set to suit most installations. If, after washing, you notice cloudy spots, streaks or water marks on your glassware, it may be necessary to increase the setting. To do this, remove the cap and rotate the indicator arrow to a higher setting then replace the cap. If the glasses are smeared or foam is present on the bottom of the glass or the bottom of the machine, select a lower setting.




# HOW TO USE AND OPERATE

## 1. Loading your Dishwasher

For better washing performance, always load the dishwasher according to the instructions. Before loading items into the dishwasher clean off large particles of food, in particular insoluble items such as bones, pips, etc.

When loading the dishwasher, please act accordingly:

- Position crockery such that water will contact all surfaces.
- Deep based items should be placed at an angle to help water run off and dry properly.
- Items with burnt on food should be soaked prior to loading in the dishwasher.




## 2. Loading the Lower Rack

The lower basket is best loaded with dinner plates, soup bowls, dishes, pots, pans, lids and even the grill tray.


Plates should be positioned upright and facing the centre of the rack and pots, pans and large dishes must be turned upside down.

### ■ How to use



Fold-down dividers at the lower rack can be lowered to improve stacking of pots and pans.

### ■ Loading examples (Energy test)



Take care not to obstruct the rotation of the spray arms and ensure that large items do not prevent the detergent dispenser lid from opening.

# HOW TO USE AND OPERATE


## 3. Using the Cutlery Basket

Cutlery should be mixed within each section of the cutlery basket to prevent nesting of similar items. Place the cutlery in the cover with the handles down. The cover can be hinged and clipped away from the basket if you choose not to use them.

Place knives in the separate rack for located in the top of the dishwasher.



**Take care when loading and unloading sharp items.**

### How to use



Slide two baskets in opposite directions, then pull them apart.

### Loading examples (Energy test)



### ⚠ WARNING

Knives and other utensils with sharp points must be loaded in the basket with their points down or placed in a horizontal position.

# HOW TO USE AND OPERATE

## 4. Loading the Upper Rack


It is best to load this with more delicate items such as, small plates, long cutlery, cups, glasses and dishwasher safe plastic items. Plates should be positioned upwards with the plate bottom facing the front of the rack.

Cups, glasses and bowls must be positioned upside down.


Extra cups or cooking utensils can be laid on the fold down cup racks, which also provides support for long stem glasses.

Take care not to obstruct the rotation of the spray arm under the upper rack.

### How to use



### Loading examples (Energy test)



### Non Dishwasher Safe Items

The combination of high water temperatures and dishwasher detergent may damage particular items, therefore we do not recommend using the dishwasher to wash the following:

- Copper or anodized aluminum
- Hand painted silver or gold leaf crockery
- Wood or bone handled utensils
- Iron or non rust proof utensils
- Plastic items that which are not dishwasher safe.

# HOW TO USE AND OPERATE

## 5. Adjusting the Upper Rack




Your upper rack can be raised or lowered to cater for different sized crockery. Before adjusting, ensure that the rack is empty.

You can change the position of the upper rack by lifting the rack upward, into the upper position, or by pulling on the two levers on either side of the rack to move it down to its lower position.

We recommend that where possible the upper rack remains level.

And when you pull the rack upward, hold the middle location of the upper rack (  marked position)

**After adjusting the rack levels, check that the spray arm is free to rotate.**



### **⚠ WARNING**

Before adjusting, ensure the rack is empty of all crockery. Otherwise crockery may be damaged or you may be injured.

## 6. Adding Detergent

- Detergent must be put into the detergent chamber before starting every program.
- Please follow the manufacturer's instructions within the manual, when determining the correct amount of detergent to use.
- If your dishes are moderately dirty, you may use slightly less detergent than recommended.
- Chambers hold 15g and 25g.
- The amount of detergent required depends on the program. Please refer to the guide table.


| PROGRAM        | AMOUNT OF DETERGENT |           |
|----------------|---------------------|-----------|
|                | Pre-Wash            | Main-Wash |
| Dual Intensity | 5g                  | 25g       |
| Auto           | 10g                 | 20g       |
| Eco50          | 5g                  | 15g       |
| Gentle         |                     | 15g       |
| Quick          |                     | 20g       |

- After the detergent is supplied, the chamber lid should be closed.
- The detergent is dispensed automatically during the operation.
- The chamber lid remains open after operation.

### **Detergent Information**

Use only the detergent intended for household dishwashers. (Ordinary hand-washing detergent should not be used, because the foam can interfere with proper operation.)

# HOW TO USE AND OPERATE



## ⚠ WARNING

The detergent used is a special Dishwasher detergent and like all household chemicals it should be treated as harmful and kept out of reach of children. After completion of the wash program, the detergent compartment should be checked and any remaining detergent removed.

## ⚠ ATTENTION

### Using combined detergent products (ex.3 in 1)

Some products integrated rinse aid work best specific programs only. You will obtain optimum rinsing and drying results by using conventional and separate salt and rinse aid. Products that replace regeneration salt can only be used within a specific water hardness range.

The use of these combined detergent products may also cause the soap dispenser to remain shut, therefore failing to dispense the soap tablet. These combined detergent products can alternatively be placed on the filter prior to starting the wash cycle. Please contact the detergent manufacturer if the drying performance is very poor or you find the white film, when you use the combined detergent products.

We do not warrant the complaints that are directly related to the use of these products.


# HOW TO USE AND OPERATE

## 7. Refilling

### ■ For refilling Rinse Aid


Depending on the dosage setting and the number of washes, the chamber may need to be topped up, approximately once a month. The rinse aid level can be checked by two methods.

- By the indicator window on the dispenser when the dishwasher door is fully open.
  - **Black indicates sufficient Rinse Aid**
  - **Clear indicates Rinse Aid required**



- By the light on the control panel, being lit, when the dishwasher is working on.

*When the lamp is lit, it means the rinse aid is almost empty. Refill the Rinse Aid chamber as soon as possible.*



## Rinse Aid Information

Rinse Aid is necessary to remove spots and streaks from dishes as well as improved drying. Using the correct amount will improve wash performance. However, using too much can produce excess foam leading to possible water leaks.

## 8. Drying

- To assist drying, we recommend that the door be partially opened after the cycle. The display will indicate "Cd"(cool dry) for a further 30 minutes after the end of the cycle time. It can be interrupted or terminated by simply opening the door.
- The use of rinse aid is recommended for optimum drying results.
- Select the "Extra Hot" option to get the best drying results.
- If the "Eco 50 + Strong Spray Level" cycle is selected, the drying performance will be compromised as this course uses very little energy and will not create the residual heat required to dry the load completely.

## 9. Energy Test(AS/NZS 2007)

- Appliance loaded in accordance with standard specifications.
  - Example of loaded dishwasher : p.13~15
  - Capacity : 14 place settings
  - Comparability course : Eco 50 and Strong (Press and hold the Eco 50 button for 3 seconds)
  - Rinse Aid setting : 3
  - Reference cleaner : 22g of detergent onto the inside surface of the door and fill 10g into the detergent dispenser.
  - Height-adjustable Rack-U must be inserted into the uppermost position.



## OPERATING SEQUENCE

### **Press the "Power" button**

### **Check there is rinse aid**

The corresponding indicator lights will illuminate if refilling is required.

### **Open the door and check the filters**

Ensure they are clean and properly positioned (See "User Maintenance Instructions").

### **Load the dishes**

Remove any excess food.  
Pull the lower rack out and arrange the dishes and cutlery.  
Pull the upper rack out and arrange the cups, glasses, etc.

#### **CAUTION**

Do not load the items in upper rack with the lower rack is pulled out and loaded.

### **Ensure the spray arms can freely rotate**

### **Measure out detergent**

Add the required amount of detergent into the dispenser and close the lid.

### **Setting and starting the program**

Press the program button to select the desired program.  
After 10 seconds, the machine will start.  
If necessary, select the option function corresponding to the desired program.  
The indicator lights of the program and all the phases of the program will come on.  
Before starting, the display window shows

the running time of the selected program. After starting, the display window shows the remaining time.

The time in the display window will start to decrease minute by minute.

If the door is opened during the program a safety device ensures that the machine stops.

Once the door is re-closed the program will start from where it was interrupted.

### **At the end of the washing program**

"End" is displayed on the digital display and a buzzer sounds.

And the dishwasher automatically switches off for safety and energy saving later.

#### **CAUTION**

Empty the lower rack first and then the upper one; this will avoid water dripping from the upper rack onto the dishes below.

#### **WARNING**

In general it is not advisable to open the door while the machine is working. If the door is opened, a safety device ensures that the machine stops. Care must be taken if the door is opened during the hot phase or immediately after a program has finished, as steam may escape.

#### **CAUTION**

That the door should not be left in the open position since this could present a tripping hazard.

- ▶ Running time may vary according to the water temperature, water pressure and voltage.
- ▶ Running time doesn't include "Cool Dry - 30min".

| Program               | Wash                                                                                              |           |           | Rinse |               | Dry | Cool Dry |
|-----------------------|---------------------------------------------------------------------------------------------------|-----------|-----------|-------|---------------|-----|----------|
|                       | Pre Wash                                                                                          | Pre Wash2 | Main Wash | Rinse | Heating Rinse |     |          |
| <b>Dual Intensity</b> |                                                                                                   | 40℃       | 65℃       |       | 70℃           |     |          |
| <b>Auto</b>           | <i>The program sequence is optimized and adapted in accordance with how dirty the dishes are.</i> |           |           |       |               |     |          |
| <b>Eco 50</b>         |                                                                                                   |           | 45℃       |       | 50℃           |     |          |
| <b>Gentle</b>         |                                                                                                   |           | 40℃       |       | 70℃           |     |          |
| <b>Quick</b>          |                                                                                                   |           | 50℃       |       | 70℃           |     |          |

## **Dual Intensity**

This cycle washes the upper and lower racks at different spray intensities. The lower rack is washed with a strong spray for hard to clean items, while the upper rack is washed with a soft spray for more delicate items.

This provides optimum cleaning performance for mixed loads, including fine china and stemware.

## **Auto Wash**

During the Auto program, the degree of soiling in the dishes is determined by the amount of clouding of the water.

According to the degree of soiling, the program automatically adjust the washing time, temperature, level of water jet, and the number of rinses.

As a result, the energy and water consumption is kept as low as possible.

The "F" on display means that the sensor is sensing the status of the dishwasher.

## **Eco 50°**

This program offers the most efficient energy and water consumption for a good washing performance.

## **Gentle**

This program is for washing delicate items like glasses.

## **Quick**

This can be used for lightly soiled recently used dishes and cutlery.

When you select "Quick" program, After finishing, "Cool Dry" function is automatically performed for the better drying result.

## **Auto Restart**


If the dishwasher is turned off by a power failure, it will restart from the position it stopped at adjusting accordingly when you press the **Power** button again.

# USER MAINTENANCE INSTRUCTIONS

*To prevent trouble and poor operating, it is important to check filters and spray arms at regular intervals.*

## Filters


- Remove the lower rack first.
- Turn the mesh filter counterclockwise.
- Take out the mesh filter, upper STS filter and outer filter.
- Clean them if necessary.
- Replace them in the reverse order.



- After each cycle, clean the filter for the better washing result.
- Before starting, check that the filter is assembled well. If the filter is not assembled correctly, you might have a poor cleaning result.


## Lower Spray Arm

- Check that the water jet holes are not blocked.
- If cleaning is required, remove the arm by pulling up.
- Clean the spray arm and replace it pulling down.



## Upper Spray Arm

- Pull the upper rack forwards.
- Check that the water jet holes are not blocked.
- If cleaning is required, remove the arm by unscrewing the nut.
- Clean the spray arm and replace it in the reverse order.



- If a problem occurs check below to see whether this can be solved.
- In the unlikely event that the problem cannot be rectified, please contact a service engineer.


| Problem                                                  | Possible Causes                                                                                                                                                                                                                                                                                                              | Solution                                                                                                                           |
|----------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| No lights come on when the power is turned on.           | <ul style="list-style-type: none"> <li>• Plug is not properly inserted into the socket.</li> <li>• Fuses blown or circuit breaker tripped.</li> <li>• The electricity of the house was cut off.</li> </ul>                                                                                                                   | <ul style="list-style-type: none"> <li>• Check the plug.</li> <li>• Check the electricity.</li> <li>• Call for service.</li> </ul> |
| The machine does not start.                              | <ul style="list-style-type: none"> <li>• Door is not fully closed.</li> <li>• The start button is not pressed.</li> </ul>                                                                                                                                                                                                    | <ul style="list-style-type: none"> <li>• Close the door.</li> <li>• Press the start button.</li> </ul>                             |
| The spray arms do not rotate smoothly.                   | <ul style="list-style-type: none"> <li>• The mounting of the spray arms is blocked by food particles.</li> </ul>                                                                                                                                                                                                             | <ul style="list-style-type: none"> <li>• Clean the holes of the spray arm.</li> </ul>                                              |
| White deposits are left on the dishwasher after washing. | <ul style="list-style-type: none"> <li>• The amount of detergent or rinse-aid set incorrectly.</li> </ul>                                                                                                                                                                                                                    | <ul style="list-style-type: none"> <li>• Check the detergent or rinse-aid.</li> </ul>                                              |
| Streaks are left on glassware.                           | <ul style="list-style-type: none"> <li>• Too little Rinse-Aid dispensed.</li> </ul>                                                                                                                                                                                                                                          | <ul style="list-style-type: none"> <li>• Fill the rinse-aid.</li> <li>• Adjust the level of rinse-aid container.</li> </ul>        |
| Dry results are not satisfactory.                        | <ul style="list-style-type: none"> <li>• Too little Rinse-Aid dispensed.</li> </ul>                                                                                                                                                                                                                                          |                                                                                                                                    |
| Washing results are not satisfactory.                    | <ul style="list-style-type: none"> <li>• Incorrect amount of detergent.</li> <li>• Utensils incorrectly arranged or overloaded.</li> <li>• Filters are clogged.</li> <li>• Water jet holes of spray arms blocked.</li> <li>• Spray arm's rotation obstructed by utensils.</li> <li>• Unsuitable program selected.</li> </ul> |                                                                                                                                    |

| Problem                                                                       | Possible Causes                                                                                                                                                              | Solution                                                                                                                                                            |
|-------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The display shows " <b>OE</b> " code. (Water is not pumped away.)             | <ul style="list-style-type: none"> <li>• The drain hose is kinked.</li> <li>• The filter is clogged.</li> <li>• Motor trouble.<br/>(Washing motor or Drain motor)</li> </ul> | <ul style="list-style-type: none"> <li>• Straighten hose(s).</li> <li>• Clean the filter.</li> <li>• If you can not solve the problem, call for service.</li> </ul> |
| The display shows " <b>IE</b> " code.                                         | <ul style="list-style-type: none"> <li>• Water is not supplied.</li> <li>• Water tap is not opened.</li> <li>• Water sensor has a trouble.</li> </ul>                        | <ul style="list-style-type: none"> <li>• Check the water tap.</li> <li>• If you can not solve the problem, call for service.</li> </ul>                             |
| The display shows " <b>EI</b> " code.<br>(Automatically Drain pump operated.) | <ul style="list-style-type: none"> <li>• Water is leaking from the hose connections.</li> <li>• Damage to the unit has been caused by a water leak.</li> </ul>               | <ul style="list-style-type: none"> <li>• Close the water tap and unplug the power plug.</li> <li>• Call for service.</li> </ul>                                     |
| The display shows " <b>FE</b> " code. (Automatically Drain pump operated.)    | <ul style="list-style-type: none"> <li>• Excessive water is supplied than the normal water level.</li> <li>• There is a problem with the inlet valve.</li> </ul>             |                                                                                                                                                                     |
| The display shows " <b>HE</b> " code.                                         | <ul style="list-style-type: none"> <li>• The water heater circuit is damaged.</li> </ul>                                                                                     |                                                                                                                                                                     |
| The display shows " <b>tE</b> " code.                                         | <ul style="list-style-type: none"> <li>• Thermistor trouble or very high inlet water temperature.</li> </ul>                                                                 |                                                                                                                                                                     |
| The display shows " <b>LE</b> " code.                                         | <ul style="list-style-type: none"> <li>• Motor trouble.</li> </ul>                                                                                                           |                                                                                                                                                                     |
| The display shows " <b>CE</b> " code.                                         | <ul style="list-style-type: none"> <li>• Motor trouble.</li> </ul>                                                                                                           |                                                                                                                                                                     |

# TROUBLE SHOOTING GUIDE

■ These are not error codes indicating a malfunction.

| Code                                     | Description                                                                                                                                                                                                                                                        |
|------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The display shows "PF" code              | This indicates there was a power failure. This function protects the dishwasher in the event the power goes out or the power to the unit is disrupted. When power is returned, and a button is pushed, this will display for 10 seconds and then go away.          |
| The display shows "Cd" code              | "Cd" means Cool-Dry. This is an additional drying cycle to assist drying performance in the 'Quick' course. This cycle runs for a further 30 minutes after the course has finished. It can be interrupted at any time by opening the door.                         |
| The display shows "CL" code              | "CL" means Child-Lock. This function is used to lock or unlock the control buttons to prevent all the setting from being changed by a child. It can only be activated during the wash cycle.                                                                       |
| The display shows "F" code               | When the unit is displaying "F", the sensor is measuring the water clarity. After 5 minutes of sensing (except draining and filling), the unit's display will then show the processing time.                                                                       |
| The display shows numbers between 1 ~ 19 | This is not an error code, but indicates the setting of the delay start. To cancel the function, turn the power off. To change the course and option, open the door and select another course and option. Countdown will then continue after door is closed again. |



|                     |                   |
|---------------------|-------------------|
| Capacity            | 14 Place settings |
| Weight              | See rating label  |
| Power Supply        | See rating label  |
| Power Consumption   | See rating label  |
| Water Feed Pressure | 0.05 ~ 0.8 MPa    |

The maximum permissible inlet water pressure,  
in megapascals

The minimum permissible inlet water pressure,  
in megapascals

(if this is necessary for the correct operation of the appliance)







You may also find user manual in video version at following link  
**[www.guidelg.com/dishwasher](http://www.guidelg.com/dishwasher)**