

BLANCO

 Performance First

EN GUIDE TO INSTALLATION
Oven

List of contents

Introduction	p.3
Steam cooking	
General remarks	p.4
Your oven, how it works	p.5
Accessories	p.6
How to install your oven	
Electrical connection	p.7
Fitting	p.8
How to use your oven	
Setting the time	p.9
Cooking immediately	p.11
Managing the water	p.13
Delayed cooking	p.14
The timer	p.15
Cooking times	p.16
How to maintain your oven	p.18
Changing the light bulb?	p.19
Troubleshooting ?	p.19

Dear Customer,

*Thank you for buying a **BLANCO oven**.*

Before we continue telling you about this oven, we cordially invite you to become part of the Blanco family by subscribing online. Please visit our website where you can easily subscribe and request such things as 'invitations to future cooking classes' and gourmet recipes. Go to www.meaappliances.com.au and fill in the subscription details.

*You will find that the clean lines and modern look of your **Blanco oven** blends in perfectly with your kitchen décor. It is easy to use and performs to a high standard.*

*Blanco also makes a range of products that will enhance your kitchen such as cooktops, rangehoods, dishwashers and microwaves, sinks and taps. There are models to complement your new **Blanco oven**.*

Of course, we make every effort to ensure that our products meet all your requirements, and our Customer Relations department is at your disposal, to answer all your questions and to listen to all your suggestions (see back cover of manual).

Please complete the warranty section of this manual and keep your receipt as proof of purchase. Retain all documents relating to the purchase of this product.

Blanco is committed to providing increasingly efficient products, that are easy to use, respect the environment, and are attractive and reliable.

BLANCO

Steam cooking

General remarks

Used in accordance with the instructions, steam cooking has many advantages over other methods. Healthy and natural, steam cooking preserves the true taste of your food. A fine sauce flavoured with aromatic herbs can make all the difference in the world.

Steam cooking is odourless. There is no need to flavour the cooking water with herbs or spices, though - fish, for example, can be flavoured by placing it on a bed of seaweed, or chicken on a bunch of rosemary or tarragon.

Meat, fish and vegetables can be cooked simultaneously.

Pasta, rice and purees can be reheated without drying out or sticking to the pan.

Cooking custards, flans, or milky rice dishes is facilitated by steam cookery. Covered in aluminium foil, the condensation will not reach the food.

There is no need to season prior to cooking, not even the cooking water.

Meat can be browned by a quick searing in hot butter on each side.

In comparison to boiling, steam cookery wins hands down.

It is quick: cooking starts immediately, whereas the cooking time of food in boiling water is only counted from the return of the water to the boil.

It is healthy: the hydro soluble vitamins and minerals are conserved because they barely dissolve in the condensed water that surrounds the food.

In addition, no fat is used in cooking.

Steam respects the food's own flavour. It adds neither flavour, nor the grilled or fried taste.

It doesn't remove any flavour either, because there is no dilution in water.

The other side of the coin: it is not worth cooking a fish that isn't fresh, or vegetables that have been forgotten at the back of the refrigerator for a week: in this way - the results will be catastrophic !

Steam does not transfer tastes or odours, so you can save both time and money by cooking - side by side but not touching - a fish and a dessert, for example.

Steam is also highly suitable for blanching, defrosting and reheating, as well as keeping warm - especially sauces.

Meats such as poultry, veal, and pork should be lightly browned in very little oil prior to cooking, to render them appetisingly golden.


Then finish their cooking by steam.

Foods will cook more quickly and evenly if they are cut into pieces than if they are left whole.


The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Your oven, how it works



The indicator panel in detail



- | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ol style="list-style-type: none"> 1. Steam cooking control 2. Defrosting button 3. Start/Stop control 4. Time and delay display or timed period 5. Steam cooking symbol 6. Cooking time symbol 7. End of cooking time symbol | <ol style="list-style-type: none"> 8. Temperature display 9. +/- controls for timer 10. Selector button : SET 11. Autonomous timer 12. Water circuit problem signal 13. Defrosting symbol 14. Display of the cooking period or delayed start time 15. Control panel locked |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Accessories

Cookware

Food dish (fig.1)

Pierced stainless steel cooking dish to prevent contact between food and condensation water.

Condensate dish (fig.2)

Dish to recover the condensation water.



When cooking place the fig.1 dish on the fig.2 dish in reverse order so that they do not fit into each other (see diagram).



When storing place the fig.1 dish on the fig.2 dish in the same order so that they fit into each other.

Grid (fig.3)

Stainless steel removable support grid: it must be placed in the oven.



The cookware may be cleaned in the dishwasher.




KITVAPIX

Steam oven double dish kit including :

- 1 x high level support grid
- 1 x food dish
- 1 x condensate dish

Removable water tank



The water tank allows for independent water supply to the oven.

Its capacity is approximately one litre (maximum level).



Using water with a low level of lime will make it easier to care for your oven.



Using demineralised water is prohibited (not for human consumption).

How to install your oven

Electrical connection

It is necessary to allow the disconnection of the appliance from the supply after installation. The disconnection may be achieved by having the plug accessible or by incorporating a switch in the fixed wiring in accordance with the wiring rules.

Use of an earthed power socket, connected in compliance with current safety standards

Your installation must be fitted with a 10 amp device for thermal protection.

Do not use the oven if the supply cord or its plug are damaged. In this case, they must be replaced by the manufacturer, its after-sales service or similarly qualified persons, to avoid any danger.

Operating voltage	220-240 V ~ 50 Hz
Total power of oven	1,77 kW

Energy consumption


-Heating to 100°C and maintaining temperature for 1 hour	0,71 kWh
----------------------------------------------------------------	----------

Inside dimensions of oven

Width	38,5 cm
Height	18,2 cm
Depth	33,5 cm

Usable volume	23,5 litres
----------------------------	-------------

Fitting



1. Place the appliance in the hole. The appliance must be horizontal. Check this position.
2. For improved stability, attach the oven to the unit using 2 screws, via the holes provided for this purpose on the side posts.
3. Carry out the electrical connection.




Make sure that the rating plate remains accessible after installation.


How to use your oven

Setting the time


The first time the oven is turned on:
Set the time.



1 The display flashes on 12.00.




2 Use the + and - buttons to adjust the time.




3 Validate with SET.


Changing the time



1 The time is displayed.



2 Press on the + and - buttons simultaneously until the time starts to flash. Adjust the time using the + and -button.



3 Validate with SET




If the time set is not validated by the SET button, it is automatically recorded after one minute.

Reducing energy consumption


After one minute of inactivity, display brightness is reduced, in order to reduce energy.

Locking the control panel


The control panel can be locked. This can only be activated when you are not using timed or delayed cooking features.



1 Hold down the START/STOP button for a few seconds.



2 A beep sounds and a "padlock" appears on the screen. From this moment, no button is live.



3 To unlock, hold down the START/STOP button for a few seconds. A beep sounds and the padlock disappears.

Cooking immediately

Operational principle

The water contained in the tank reaches the cavity via a tube. This water is transformed into steam on contact with a hot surface placed in the lower part of the cavity: the steam generator.

There is no need to add water to the cooking dish. To guarantee TRUE STEAM COOKING, your oven is supplied with a set of specially designed for cookware to perfection.

- ⚠ You MUST IMPERATIVELY fill the water tank up to the **maximum** level before starting cooking. Put the tank back in place, and push it as far as possible until it **CLICKS INTO PLACE**.
- ⚠ When cooking, the appliance gets hot. Hot steam may escape when you open the door of the appliance. Keep children out of the way.

Steam cooking

Steam cooking at 100°C.



- 1** Press the button . A time of 25 minutes is suggested.
- 2** Adjust the cooking time as necessary (minimum 5 min and maximum 60 min by pressing on + and - button
- 3** Validate with the **START** button.



- 4** The symbol comes on. When the temperature is reached, 100° becomes constant, and a beep sounds.

In order to avoid altering the results of the cooking, avoid opening the appliance door during cooking.

Defrosting

Defrosting at 60°C.



- 1** Press the button . A time of 40 minutes is suggested.
- 2** Adjust the cooking time as necessary (minimum 5 min and maximum 60 min by pressing on + and - button.
- 3** Validate with the START button.



- 4** The symbol comes on. When the temperature is reached, 60° becomes constant, and a beep sounds.

Modifying the cooking time

During cooking, you can modify the cooking time by using the + and - buttons.

Stopping the appliance during cooking

You can stop the cooking at all times by pressing on START/STOP (hold the button down for about 1 second).

If the steam production has not yet started (about 1 minute), the oven will stop immediately and the time setting will disappear.

If the steam production has already started, the time passes to 3 minutes and during this period, the steam evacuates before you open the oven.

At the end of cooking

0m00s displays. The display animation stops. Beeps are heard for a 3 minute period.

To stop the beeps, press on STOP and open the door.

You MUST IMPERATIVELY empty the tank



In order to make sure the oven is reliable, the fan continues to operate for a certain period after the end of cooking.

Advice

Freeze small portions; defrosting will be faster, more homogenous and quality will be preserved. When semi-defrosted, you can turn over the food items or spread them out (for example vegetables patties). Protect pastries with a cling wrap or keep the original packaging. Wipe fish and sausages before grilling: humidity stops them from becoming golden brown. For large pieces (roasts, etc.) proceed in steps by turning the piece over several times and adjust the time accordingly.

VEGETABLES	Patties (spinach, etc.)	placed on dish	25 min
	In blocks	placed on dish	40/45 min
	Trout (whole)	placed on dish	30 min
FISH	Salmon steak	placed on dish, turned over half way through	25 min
	Filets (protected by a cling wrap)	placed on dish	15/20 min depending on thickness
	Prawns	placed on dish	10/12 min
	Chicken thighs	placed on dish, turned over half way through	40/45 min
MEATS	Poultry breast (protected by a film)		25 min
	Sausages	placed on dish	25 min
	Chops (pork, veal, etc.)	placed on dish, protected by a cling wrap, placed on the grill	25/30 min
	Liver cubes (for skewers)	to be separated half way through	55/60 min
	Mixed berries	placed on dish	15 min
FRUIT	Stewed fruit (apple, etc.)	protected by a cling wrap	35/40 min
PASTRIES	Doughnuts	kept in packaging, placed on the grill	15 min
	Chocolate croissants	kept in packaging, placed on the grill	15 min

Reheating

You can reheat a cooked dish in your steam oven. The dish will not dry out, will not become overcooked and will not splatter or stick. Adjust steam sequence at 100°C, place the dish or plate on the grill, protect with aluminium foil or cling wrap to avoid drops of water accumulating and heat for 20 to 25 minutes depending on the dish and your preferences.

Examples:

A plate of sauerkraut: 20 min

A bowl of soup (300 ml): 20/25 min

Managing the water

In case of problems related to the water circuit during cooking, the 'no water' symbol appears and a beep sounds. This fault is specifically related to:

- an empty tank,
- a wrongly-fitted tank.



After checking these two points, the cooking will recommence automatically after the door.

Delayed cooking


Steam cooking

Steam cooking at 100°C.

You can program the cooking time so that your dish is ready at a time of your choice.

For example:

It is 10 o'clock, and you have to go out, your dish should be ready at 12 o'clock and it will take 20 minutes to cook.




1 Press the button . A time of 25 minutes is suggested.

2 Adjust the cooking time as necessary (minimum 5 min and maximum 60min) by pressing on + and - button.

3 Validate with the SET button.

For example : 20 min.



4 The time and the end of cooking time symbol display and flash. The adjustment of the end of cooking time is now possible:
Press the + or - buttons
For example : 12h00

5 Validate with the SET button.
The time and the end of cooking time become constant.
The symbol for the length of cooking time displays.



If the programming is not validated by touching SET, the recording of the program is cancelled, the time display disappears and the time is displayed again.

Modification of cooking time and the end of cooking time

You can consult or modify the length of cooking time and the end of cooking time, at all times.

To cancel the programming, press START/STOP.


How to use the timer

Timer

Your oven is fitted with an electronic timer that is independent of the operation of the oven, and allows time to be counted down.

⚠ This function is independent of your oven. It can not order the end of automatic cooking.

However, this function can be used even during operation of the oven. In this case, the display of the timer is given priority over the display of the time.



1 Hold the SET button down for a few seconds. 00m00s and the timer symbol flash.

2 Adjust to the period required (maximum 9 minutes and 50 seconds) using the + and - buttons.

After a few seconds, the timer counts down the time.

Once the time has run out, beeps will sound every few seconds. 0m00s displays and flashes.

The beeps can be stopped by holding down SET or START.

Modifying and stopping the timer

Once the countdown has started, you can modify the time remaining by holding down SET then pressing the + or - buttons.

To cancel the timer, hold SET down for a few seconds, then return the time to 0m00s.

Cooking times

VEGETABLES	TIME <small>Whatever the quantity</small>	PREPARATION	REMARKS
Artichokes (Small)	40 to 45 min .	placed upside down in the dish	<ul style="list-style-type: none"> • These times depend on the nature, size and freshness of the vegetables. Follow the instructions given in the "Preparation" column. • The cooking time is the same regardless of the quantity to be cooked. <i>For example :</i> 1 or 4 artichokes, same cooking time. • To check how well done the food is, test the thickest part of the vegetable; if it is cooked, it will not resist.
Asparagus	35 to 40 min.	for the tips, reduce the cooking time	
Broccoli	18 min.	in little flowerets	
Carrots	20 to 22 min.	in fine slices	
Celeriac	25 to 30 min.	in fine slices	
Pumpkin	15 to 20 min.	in cubes	
Mushrooms	15 min.	in fine strips	
Cabbage	30 to 35 min. 22 min. 30 to 35 min.	Brussels sprouts Flowers in little bunches Green shredded	
Courgettes	10 to 15 min.	in slices	
Chinese artichokes	20 min.	(fresh) stir during cooking (frozen) " " "	
Spinach	20 min. 35 min		
Chicory	30 min.	core removed and cut in two lengthwise	
Fennel	22 min.	cut in 2	
Green beans	30 to 35 min.	cubed	
Turnips	15 to 20 min.		
Fresh peas	20 to 25 min.	/	
Leeks	25 min.	cut in 2	
Potatoes	25 min. 40 to 45 min.	sliced whole	
SHELLFISH	TIME	PREPARATION	
Scallops	10 to 12 min.	with aromatic herbs	<ul style="list-style-type: none"> • Arrange the shellfish on a grill or glass dish, and add a few aromatic herbs • Arrange seafood on a bed of seaweed.
Mussels/Whelks	20 to 25 min.	with aromatic herbs	
Crabs/Lobster/ Dublin Bay	25 min. 30 to 35 min.	/ according to weight	
Prawns	12 to 15 min.	/	
FRUITS CUSTARDS	TIME	PREPARATION	
Apples/ pears/ peaches	10 to 15 min.	whole, peeled	Time according to ripeness
puree	25 min.	strips of fruit	
Custards	10 min.	in ramekins	

FISH	TIME	PREPARATION	REMARKS
Pike	25 to 30 min.	whole (1kg)	<ul style="list-style-type: none"> • *Steaks :slices of fish 2 or 3 cm thick (180/200g) per person. • Always insist on very fresh products • Place whole fish directly into the dish or on bay leaves, fennel or other herbs. • At the end of cooking, remove the skin which will come away easily.
Cod/hake	13 to 15 min.	steaks (180g)*	
Sea bream	20 to 25 min.	whole (1kg)	
Haddock	15 min.	fillets	
Herring	20 min.	whole (200g)	
Monkfish	15 to 20 min.	steaks (180 g)	
Lotte	15 min.	according to thickness	
Mackerel	20 min.	whole (250g)	
Whiting/cod	15 min.	fillets	
Skate	25 to 30 min.		
Mullet	15 min.	whole (200g)	
Mullets	10 min.	fillets	
Dogfish	20 min.	thick slice (6 to 10 cm long)	
Salmon	15 to 20 min.	steaks (180/200 g)	
Sole	10 to 12 min.	fillets	
Tuna	20 to 25 min.	steaks (180/200 g)	
Whole trout (1kg)	20 to 25 min.	whole (200g) 13 to 15 min.	

MEATS/ EGGS	TIME	PREPARATION	REMARKS
Beef	15 to 30 min.		<ul style="list-style-type: none"> • The brown under grill in another dish.
Pork (filet mignon)	25 min.	Joint 800 gr.: 55 to 60 min.	
Poultry (breast, fillet) (Paupiettes)	20 to 25 min.	Chicken drumsticks : 35 to 40 min.	
Sausages	25 min.	Turkey roast joint : 50 to 60 min.	
Black pudding	20 min.	Morteau 400 g piece	
	10 to 15 min.		

Eggs eggs that are very fresh and stored at room temperature	7 min.	<u>Boiled eggs</u> : Place directly on the grill.
	5 to 6 min.	<u>Fried eggs</u> : broken in an individual dish on the grill and cover with cling film
	8 min.	<u>Soft-boiled</u> : Place directly on the grill.
	10 to 12 min.	Hard / Cocotte see detailed recipes.

RICE, PASTA COUCOUS	TIME	PREPARATION	REMARKS
Place directly in a dish, covered with water or milk. The steam is not sufficiently wet to saturate these foodstuffs that swell. Place a sheet of aluminium foil over the dish to protect it from the droplets of water.			
Rice pudding	30 min.	100g of washed rice - 20 cl of milk 2 dessertspoons of sugar	<ul style="list-style-type: none"> •Separate grains with a fork at the end of the cooking.
Couscous	20 min.	200g (1/4 litre of water)	

How to maintain your oven

Maintenance

Cavity (after each use)

Wipe out the cavity with a dry cloth after the steam generator has cooled or leave the cavity to dry out with the door open.

Water supply tube (Once per month)

Remove the water supply tube by unscrewing it. Remove any scale that may have formed on the inside (using a fine, pointed object such as a skewer or knitting needle).

Steam generator tube (Once per month)


Pour half a glass of spirit vinegar onto the generator. Leave to work for a few minutes, clean and rinse with water.

Do not use sponges, abrasive powder, or descaler.

Oven door

Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.

Cleaning the channel



Dismantle this channel by pulling upwards. Wipe it and replace it, using the three notches provided for this purpose.



The oven must not be cleaned with a steam cleaner.

Changing the light bulb ?



The bulb is by the far right corner.



Always switch the oven off at the mains before changing the bulb in order to safeguard against electric shocks.

- Turn the cover slightly anti-clockwise (left).
- Unscrew the bulb the same way.

The bulb is a :

- 25 W
- 220/240 V
- Type E14 suitable up to 300°C
- Change the bulb and reassemble the unit making sure the seals are positioned correctly.
- Switch the oven back on at the mains.

Troubleshooting

IF YOU REALIZE THAT	POSSIBLE CAUSES	WHAT SHOULD YOU DO?
The display panel is not lit up.	A fault in the oven electrical supply. Electric card out of order.	- Check that the tank has been pushed in completely. - Contact the After-Sales Service.
The light doesn't work.	The bulb needs replacing. The oven is not switched on at the mains. The fuse has blown.	- Change the bulb. - Switch the oven on at the mains. - Change the fuse.
Water or steam leaking from the door during cooking.	The door is not shut correctly. The door seal is faulty.	- Contact the After-Sales Service.

In all cases, if you are unable to solve the problem yourself, please contact the After-Sales Service without delay.