
How can I dispense detergent automatically?












- * When moving the Auto Dispense unit with the content remaining, make sure the handle and knob side are upward() Other positions may cause the content to leak.
 - 2, 3 : the handle and knob side are downward
 - 4 : taking the outlet by hand

How can I dispense detergent automatically?

How can I set the detergent load?



Isn't there a quick way to access Auto Dispense?



Once you set the input amount, you can quickly activate or deactivate Auto Dispense.

- 1 Swipe down the top bar to display the Quick Settings panel.
- ② Tap to turn on or off [Auto detergent] and [Auto softener]

* If you prefer to apply detergent manually, turn off [Auto Detergent] and apply detergent to the Aqua Pebble.

Refer to the gradations on the Aqua Pebble to apply detergent as appropriate(refer to the amount recommendation of detergent manufacture), and put the Aqua Pebble in the drum on top of laundry.

