

 $\bf 60~cm~4~burner~gas~cooktop~with~battery~ignition~and~flame~failure~RRP~AUS~\499.00





Product Details

FEATURES

Flat trivet pot support design Side control White enamel finish Flame failure feature

A safety mechanism that stops the gas flow if the flame is extinguished

Enamel cooktop trivets Battery cooktop ignition 4 burners LP conversion kit included

(must be installed by licensed

tradesman)

BENEFITS

Contemporary and functional

The Chef range of cooking appliances has all the features you need in a design that you'll love

Easy to maintain

Easy clean formed hob in an enamel finish makes this hob easy to maintain

Easy to use

The flat pot support design means it is easy to move pots and pans around the cooktop

Fuss-free installation

Models with battery ignition to the hob means that no electrical connection is required making installation easy and fuss-free.



Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	gas
Materials/Colour	white enamel
Trim finish	white enamel
Knob Finish	white

DIMENSIONS

Total product height (mm)	58
Total product width (mm)	600
Total product depth (mm)	535
Cut out width (mm)	570
Cut out depth (mm)	490

CONTROLS

Controls of Cooktops	knob
Position of controls	right
Features of Cooktop	optional LP,flame failure

FEATURES

Trivets	enamel	

ELEMENTS/BURNERS

LEFT FRONT ZONE Left front zone rapid

LEFT REAR ZONE

Left rear zone	semi-rapid
Left rear number of cooking zones	1



Left front number of cooking zones

1

RIGHT FRONT ZONE

Right front zone	simmer
Right front number of cooking zones	1

RIGHT REAR ZONE

Right rear zone	semi-rapid
Right rear number of cooking zones	1

ELECTRICAL SPECIFICATIONS

Connected load KW	0
Type of connection	not required

GAS SPECIFICATIONS

T () () () () ()	05.0
Total burner output(NG)	35.2



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz