


90cm 4 zone induction cooktop with BoilProtect, FlexZone, Hob2Hood, PowerBoost and Pause function.
RRP AUS \$2,249.00



Product Details

FEATURES

BoilProtect	FlexZone	Hob2Hood	PowerBoost
Pause	QuickCook Timer	Perfect heat control	Touch slide control
Easy cleaning	Residual heat indicator	Child safety device	

BENEFITS

No more boiling over There are more exciting things to do than watching water boil. BoilProtect detects rising bubbles and automatically reduces to a low simmer. No more constant monitoring so you can focus on the flavours. Applies to stainless steel and enamelled pots filled with water only.	FlexZone gives you room to move Cater for larger pots & pans with Flex Zone. Designed with busy family kitchens in mind, Flex Zone lets you use two induction zones separately or link them together when you're cooking for a crowd.
Slide for instant temperature control Easy touch slider control allows you to choose your temperature setting instantly with the slide of a finger.	Zero to Boil in no time With PowerBoost, you can rapidly boil a pot of water or quickly heat up a frying pan. Spend less time waiting and more time creating your favourite meals.
Pause when you need to When you're cooking, those pesky interruptions wont be a bother anymore. That's because you can simply pause what you're doing. Just press the Pause icon on your cooktop and all operating zones will drop to a Keep Warm mode. And when you're ready to resume, just touch the Pause icon again.	Clear the air with Hob2Hood With Hob2Hood technology, compatible rangehoods work seamlessly with your induction cooktop to clear your kitchen of cooking smells and steam. As you start cooking, the rangehood will automatically turn on then intuitively adjust the fan speed and airflow to match your cooking. How's that for hands-free convenience?

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	Induction
Materials/Colour	black ceramic glass

DIMENSIONS

Total product height (mm)	46
Total product width (mm)	910
Total product depth (mm)	520
Cut out width (mm)	880
Cut out depth (mm)	490

CONTROLS

Controls of Cooktops	Touch and Slide controls
Position of controls	front
Functions of Cooktops	timer,Keep warm function,pause,PowerBoost,Hob2Hood,BoilProtect
Indicators/display	fault indicator,residual heat warning lamps
Features of Cooktop	safety cut off,electronic timer,safety child lock,hot surface indicator,BoilProtect,Hob2Hood,FlexZone
Timer of Cooktop	programmable 99min,countdown

ELEMENTS/BURNERS

LEFT FRONT ZONE

Left front zone	FlexZone
Left front Watts	2300
Left front boost watts	3200
Left front number of cooking zones	1
Left front diameter mm	210

CONTROLS

Readable temperature setting	No
------------------------------	----

LEFT REAR ZONE

Left rear zone	FlexZone
Left rear watts	2300
Left rear number of cooking zones	1
Left rear diameter mm	210

RIGHT REAR ZONE

Right rear zone	induction
Right rear watts	1800
Right rear diameter mm	180

SHIPPING

Shipping Weight (Kg)	15.6
----------------------	------

CENTRE FRONT ZONE

Centre front zone	induction
Centre front Watts	2300
Centre front diameter mm	240

ELECTRICAL SPECIFICATIONS

Connected load KW	7.4
Type of connection	hardwired

STUFFING QUANTITIES

20ft	136
------	-----

SHIPPING

Pack Dimensions Height (mm)	120
Pack Dimension Width (mm)	1175
Pack Dimension Depth (mm)	630

STUFFING QUANTITIES

40ft HC	306
---------	-----

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz