

A large, light blue rectangular area with a thin blue border, serving as a background for the title and introductory text.

Designed by iLuv in New York

Alarm Clock with Shaker for your iPhone or iPod

Quick Start Guide

Vibro- II / IMM155

Welcome.  Innovative Lifestyle Unquestionable Value™	CONTENTS <table> <tr> <td></td> <td>WHAT'S INCLUDED</td> <td>3</td> </tr> <tr> <td></td> <td>SETTING THE CLOCK USING TIMESYNC</td> <td>4</td> </tr> <tr> <td></td> <td>SETTING THE CLOCK MANUALLY</td> <td>5</td> </tr> <tr> <td></td> <td>SETTING THE ALARM</td> <td>6,7,8</td> </tr> <tr> <td></td> <td>SETTING YOUR IPHONE / IPOD</td> <td>9,10,11,12,13</td> </tr> <tr> <td></td> <td>WARRANTY</td> <td>14</td> </tr> </table>		WHAT'S INCLUDED	3		SETTING THE CLOCK USING TIMESYNC	4		SETTING THE CLOCK MANUALLY	5		SETTING THE ALARM	6,7,8		SETTING YOUR IPHONE / IPOD	9,10,11,12,13		WARRANTY	14
	WHAT'S INCLUDED	3																	
	SETTING THE CLOCK USING TIMESYNC	4																	
	SETTING THE CLOCK MANUALLY	5																	
	SETTING THE ALARM	6,7,8																	
	SETTING YOUR IPHONE / IPOD	9,10,11,12,13																	
	WARRANTY	14																	

CONTENTS | Alarm Clock with Shaker for your iPhone or iPod | IMM155

WHAT'S INCLUDED

- Shaker
- IMM155 Main Unit (Output: 4W)
- AC Adapter (100-240V)

SETTING THE CLOCK USING TIMESYNC

1. Dock iPhone or iPod
2. Press and Hold "TimeSync"
3. Time syncs to iPhone or iPod

NOTE: "TimeSync" can only be performed in Standby mode. TimeSync sets clock to hours and minutes ONLY. Seconds do not sync.

WHAT'S INCLUDED

SETTING THE CLOCK USING TIMESYNC

1 Dock iPhone or iPod

2 Press and Hold "TimeSync"

3 Time syncs to iPhone or iPod

NOTE: "TimeSync" can only be performed in Standby mode. TimeSync sets clock to hours and minutes **ONLY**. Seconds do not sync.

SETTING THE CLOCK MANUALLY

1. Press "Set" to enter the set time mode.
2. Press to set hour.
3. Press to confirm.
4. Repeat steps 2-3 to set Minutes.

SETTING THE ALARM

1. Press twice to set Alarm 1 (Three times for Alarm 2)
2. Press to set hour

SETTING THE ALARM

3



Press to confirm

7

SETTING THE ALARM

4 Press to set minutes

5 Press to confirm

SETTING THE ALARM


6



Press to scroll through Alarm Mode options (Scroll through twice for options WITH Shaker)

9

SETTING THE ALARM

7. Press the **SET** button to confirm.
 
8. Press the **ALARM** button to activate or deactivate Alarm 1 / Alarm 2.
 

 PLAYING YOUR IPOD / IPHONE

1 Dock iPhone or iPod



11

 PLAYING YOUR IPOD / IPHONE

- 

Press
- 

iPod icon appears on LCD

 PLAYING YOUR IPOD / IPHONE

- 4  Press to Play/Pause
- 5  Press to choose Previous or Next Track
- 6  Press to adjust volume

WARRANTY

[illegible]

iLuv®, Innovative Lifestyle Unquestionable Value® and Greetology™ trademarks are the exclusive properties of iMN Electronics Corp. and are registered with the U.S. Patent and Trademark Office, and may be registered or pending registration in other countries. All other iLuv® trademarks, service marks, and logos may be registered or pending registration in the U.S. or in other countries. All other trademarks or registered trademarks are the property of their respective owners. iPhone and iPod are trademarks of Apple Inc. registered in the U.S. and other countries. © 2011 iLuv Creative Technology.

[illegible]

 COMMENTS

QSG Sleeve