



POISON

KEEP OUT OF REACH OF CHILDREN READ SAFETY DIRECTIONS BEFORE OPENING OR USING

THERMACELL

MOSQUITO REPELLENT



Protects your outdoor areas from mosquitoes.

ACTIVE CONSTITUENT: 219.7 g/kg ALLETHRIN 20:80

MR300 REPELLER

Repels mosquitoes in an area as large as 21 square metres.

See side panel for additional precautionary statements.

DIRECTIONS FOR USE

USEFUL TIPS:

- Allow 10 to 30 minutes, depending upon the size of the area, for product to take effect This product works best in outdoor areas
- where there is minimal air movement, such as yards and outdoor campsites Provides a maximum of 4 hours mosquito
- repellency per mat.
- Mats turn from pale blue to white when mosquito repellent has been used up and
- Some visible vapor will appear during use; • Use additional mosquito repellers to cover a
- larger area Altitudes above 2300m can effect product

USE RESTRICTIONS:

Only for outdoor use as a mosquito repellent. Do Do not insert anything other than Thermacell®

mosquito repeller unattended or use in windy conditions. Do not expose mosquito repeller or mats to rain. Place mosquito repeller on a flat, stable surface with the grill facing upward. Do minutes. Clean with a damp cloth only when the Thermacell® mats and cartridges will work in

TO USE THE MOSQUITO REPELLENT



- . Remove one Thermacell® Mosquito Repellent mat from wrapper. Make sure the
- 'ON/OFF' switch on the appliance is in the 'OFF' position. Insert the mat under the appliance's black grill To change mats slide the 'ON/OFF' switch to 'OFF' and allow the appliance to cool completely. Push the used mat out by inserting a fresh one.
- . Remove the appliance cap. Remove the cap from the cartridge.
- 4. Screw the cartridge into the opening of the appliance. Make sure the cartridge is fully inserted by turning it clockwise until it stops. Replace the appliance cover. If your appliance fails to heat, it may be out of fuel. To check the fuel level, hold the appliance vertically and look through the slot on the back of the appliance. You can see the amount of butane left in the cartridge. Replace if empty.





- 5 Slide the 'ON/OFF' switch to the 'ON' position; the butane gas will begin to
- 6. Wait approximately 5 to 10 seconds then depress the start button three to five times in rapid succession.



When finished using the appliance, slide the 'ON/OFF' switch to the 'OFF' position. and allow the appliance to cool completely. Appliance is now ready for storage.

If you do not see an orange glow through view

TROUBLESHOOTING

- window 1. Repeat directions "To Turn ON"
- 2. If there is still no orange light visible, make sure the fuel cartridge is completely screwed into place. Repeat "Turn On" directions. Confirm the orange glow is visible. 3. Check the amount of fuel in the cartridge. If
- cartridge is empty or near empty, remove cartridge and replace with a new cartridge. Repeat "Turn On" directions. Confirm the orange glow is visible.

Not sure it's working

- 1. Place product upwind for maximum mosquito repellency. Windy conditions can reduce mosquito repellent effectiveness.
- 2. Check the mosquito repellent mat. Mats turn from pale blue to white when it has been used up. See directions to replace Thermacell Mosquito Repellent Mat.
- 3. Check the amount of fuel in the cartridge. If cartridge is empty or near empty, remove cartridge and replace with a new Thermacell cartridge. Repeat "Turn On" directions. Confirm the orange glow is visible.

Still have questions? Call Customer Service at 1300 360 211 or email customerservice@mayohardware.com.au

PRECAUTIONS:

KEEP OUT OF REACH OF CHILDREN AND PETS. For outdoor use as an insect repellent only.

Do not use indoors, in tents or any enclosed area. Do not touch the grill while the The grill is hot while in use. Do not insert

anything other than Thermacell mats into the appliance. Place appliance on a flat, stable surface with the grill facing upward. Do not cover with any material while in use. Clean with a damp cloth only when the appliance is cool and inactive. Wash hands after use. Cartridge contains flammable, pressurized butane. Do not use near fire or flame. Protect the butane cartridges from sunlight. Do not expose them to temperatures above 50°C. Do not pierce, break or incinerate butane cartridges, even after use. Butane cartridges other then Thermacell cartridges will not work in this appliance.

Seller will not be held responsible for damage, injury or poor performance caused by use of other butane cartridges or repellent mats. **CAUTION:** This pesticide is highly toxic to

fish. Do not apply directly to water. Drift from treated areas may be hazardous to

This pesticide poses a high risk to beneficial disperse in an area where bees are foraging; or on plants likely to be visited by bees if the plant is in open flower or part bloom, or is likely to flower within 10 days following

STORAGE AND DISPOSAL: Store in the closed, original container in a

cool, dry place out of reach of children. Do not store in direct sunlight. Store unused mats in original packaging in a cool, dry place inaccessible to children and pets. Store butane cartridges in a cool, dry place away from sources of heat. Do not reuse empty envelopes. Wrap used mats and butane cartridges and place in garbage. Do not incinerate cartridges.

SAFETY DIRECTIONS: Wash hands after use.

FIRST AID:

If poisoning occurs, contact a doctor or Poisons Information Centre (Phone Australia 13 11 26: New Zealand 0800 764766). Take appliance, label or product name and APVMA or HSNO Approval Number with you when seeking medical attention. Harmful if swallowed. For further product information contact Mayo Hardware 1300 360 211

Mayo Hardware, 71 Apollo Drive Albany 0632 Refer to www.epa.govt.nz for controls. HSNO Classifications: 2.1.1A, 6.1E, 9.1A, 9.4C

APVMA Approval No.: 54539/109998

WARNING: FLAMMABLE AEROSOL. ECOTOXIC

Batch/Date of Manufacture located on each component in the box.

