

NEFF C67P70N3GB - MULTIFUNCTION OVEN & MICROWAVE IN DETAIL



C67P70N3GB

COOKING FUNCTIONS

- ▶ Microwave, 5 power levels
- ▶ Hot air for cooking on one level
- ▶ Hot air plus for cooking on two levels
- ▶ Top/bottom heat
- ▶ Bottom heat
- ▶ Circo-roasting
- ▶ Full surface grill
- ▶ Centre area grill
- ▶ Low temperature cooking
- ▶ MicroCombi cooking - gentle and intensive
- ▶ Keep warm

DESIGN

- ▶ SilverLight display
- ▶ Stainless steel control panel with bevelled glass insert
- ▶ Fully retractable control/s

CLEANING




- ▶ Pyrolytic cleaning
- ▶ Enamel interior

STANDARD ACCESSORIES

- ▶ Enamelled deep universal pan
- ▶ Wire rack for universal pan
- ▶ Wire rack
- ▶ Glass tray

SPECIAL FEATURES

- ▶ Capacity 42L
- ▶ 3 shelf positions
- ▶ 70 automatic programmes
- ▶ Microwave power levels 90-180-360-600-1000W
- ▶ Innwave technology for even cooking results
- ▶ Microwave stirrer
- ▶ EasyClock with automatic time programmer
- ▶ Rapid heat
- ▶ 6 memory functions
- ▶ ClearText display
- ▶ Temperature display
- ▶ Temperature proposal
- ▶ Interior light
- ▶ Glass inner door
- ▶ Electronic door lock
- ▶ Automatic safety switch off
- ▶ Permanent safety lock/child safety lock
- ▶ Heating up indicator
- ▶ Residual heat indicator



The appliances may only be fitted above a ventilated oven from the same manufacturer. The appliances must not be fitted above a steamer, combination steam oven or a dishwasher.

If installing below a hob, the submerged depth of the hob must be considered and a minimum worktop depth of 40mm is recommended.

There must be a ventilation cut-out made in the intermediate floor of the base cabinet.

