

Trim kits are also available

For kitchens with limited space or if you want more counter space, Sharp offers built-in kits to securely position your Sharp microwave oven into an open area of cabinet space. Please note that for safety reasons, Sharp recommends the use of Sharp built-in kits only.

MODEL	RK-J32W	RK-J32S
COLOUR	White	Silver
CABINET DIMENSIONS REQUIRED		
W (mm)	560-564	
H (mm)	403-409	
D (mm)	489	
APPLICABLE SHARP MICROWAVE OVEN	R350LW R380LW	R350LS
APPLICABLE OVEN WEIGHT (approx.)	17 kg	
BUILT-IN KIT FRAME SIZE (external)		
W (mm)	596	
H (mm)	423.4	

MODEL	RK-J40W	RK-J40K
COLOUR	White	Black
CABINET DIMENSIONS REQUIRED		
W (mm)	560-564	
H (mm)	419	
D (mm)	455 (min.)	
APPLICABLE SHARP MICROWAVE OVEN	R480LW	R480LK
APPLICABLE OVEN WEIGHT (approx.)	19 kg	
BUILT-IN KIT FRAME SIZE (external)		
W (mm)	596	
H (mm)	446	

MODEL	RK-J40S	RK-J39S
COLOUR	Stainless steel	Stainless steel
CABINET DIMENSIONS REQUIRED		
W (mm)	560-564	600
H (mm)	419	381
D (mm)	455 (min.)	500
APPLICABLE SHARP MICROWAVE OVEN	R490NS	R395NS
APPLICABLE OVEN WEIGHT (approx.)	20 kg	17 kg
BUILT-IN KIT FRAME SIZE (external)		
W (mm)	596	596
H (mm)	445	380

MODEL	RK-J90W	RK-J90S
COLOUR	White	Stainless steel
CABINET DIMENSIONS REQUIRED		
W (mm)	714.5 – 720.5	
H (mm)	479.5 – 482	
D (mm)	511	
APPLICABLE SHARP MICROWAVE OVEN	R990KW	R990KS
APPLICABLE OVEN WEIGHT (approx.)	29 kg	29 kg
BUILT-IN KIT FRAME SIZE (external)		
W (mm)	758	
H (mm)	511	

MODEL	EB-R5000W	EB-R47ST
COLOUR	White	Stainless steel
CABINET DIMENSIONS REQUIRED		
W (mm)	560-568	
H (mm)	409	
D (mm)	550-580	
APPLICABLE SHARP MICROWAVE OVEN	R890NW	R890NS
APPLICABLE OVEN WEIGHT (approx.)	19 kg	19 kg
BUILT-IN KIT FRAME SIZE (external)		
W (mm)	595	
H (mm)	424	

Note: These dimensions are intended as a guide only; they do not include details such as chimney dimensions. For full details on cabinet dimensions please refer to built-in kit installation instructions available on www.sharp.net.au

SHARP

SHARP

Sharp Corporation of Australia Pty Ltd
ABN 40 003 039 405
1 Huntingwood Drive, Huntingwood NSW 2148
For enquiries phone 1300 13 55 30
Tel: (02) 9830 4600 Fax: (02) 9672 1208
www.sharp.net.au

This brochure is current as of September 2009.
The contents are subject to change without notice.

Wisdom

Homes

Appliancesonline

.com.au

The wise choice

Australia's largest online appliance retailer

Image on front cover taken at a Wisdom display home.



Microwave Oven Range 2010



Over 40 years in the making

Since Sharp invented the first carousel microwave oven in 1962, we have continued to innovate in style and function. Building on over forty years of experience, today Sharp brings you a diverse range of microwave ovens that offer sophisticated, yet easy-to-use technology.

Our range of microwave ovens blend into your kitchen décor, combining style with space-saving designs and practical features. They make it easy to prepare healthy meals quickly with food that looks and tastes great.

Choose the one that's best for you.

Practical features that make cooking easy

Menus developed to suit Australian tastes

At Sharp, we are firmly committed to meeting Australia's cooking preferences. All menus, food groups and recipes for Sharp microwave ovens are developed in Australia.

Express Menus

(R350LW/LS, R380LW, R398NS, R480LW/LK & R490NS)

Sharp's Express Menus offer convenience and a variety of meal options at your fingertips. Using the Express Menu function you can easily create delicious pasta, risotto and casserole dishes.

Express Cook

Cook succulent roasts using frozen or chilled meat with Sharp Express Cook, pre-programmed for your added convenience.

Express Defrost

This pre-programmed menu takes only minutes to defrost 500g fish, chicken and mince.

Express Meal

Each of the Australian-developed recipes takes less than 30 minutes. You simply place all ingredients in one dish at the same time. All you have to do is the initial preparation and stir the meal half-way through cooking.

Easy Defrost

Simply enter the weight of the frozen meat, and the oven will defrost it by calculating the defrost time and power level automatically.

Auto Cook

Pre-programmed Menus

Auto Cook allows simple, speedy cooking of a variety

of delicious foods. Select the food category, enter the weight and the oven will set the cooking time and power level automatically.

Sensor

Pre-programmed Menu

Eliminate all the guess work. Humidity sensors monitor the amount of moisture rising from the food to determine cooking and reheating times. In just one touch it automatically selects the appropriate power level and calculates the cooking time, saving you time and producing excellent results.

Instant Cook

Press the Instant Cook/Start key and the oven will cook on High for one minute. Press the button twice and the oven will cook for two minutes.

More or Less

This function allows you to tailor pre-programmed menus to your taste. Select 'Less' for a rare result or 'More' for a well-done result. Alternatively use it to add or reduce cooking time as well.

Info Display

Press the Help key for cooking tips and instructions. Info Display makes your microwave so easy to use you can throw away your cookbooks.

Auto Start

(R380LW, R890NS/NW, R990KS/KW)

Allows you to set your oven to start automatically at a programmed time.



R200LW **Compact Microwave Oven**

- 800W output power
- 272mm turntable
- 3 Instant Action Cook menus
- 4 Easy Defrost
- 3 Express Defrost
- 2 Instant Action Reheat menus
- More/Less (power level key)
- Instant Cook/Start key
- Timer
- Clock
- Alarm
- Child lock
- Demo mode



R230LS **Compact Microwave Oven**

- 800W output power
- 272mm turntable
- 3 Instant Action Cook menus
- 4 Easy Defrost
- 3 Express Defrost
- 2 Instant Action Reheat menus
- More/Less (power level key)
- Instant Cook/Start key
- Timer
- Clock
- Alarm
- Child lock
- Demo mode



R290NS **Compact Microwave Oven with Stainless Steel Fascia**

- 800W output power
- 272mm turntable
- 4 Instant Action Cook menus
- 4 Easy Defrost
- 3 Express Defrost
- 2 Instant Action Reheat menus
- Instant Cook/Start Key
- More/Less (power level key)
- Timer
- Clock
- Alarm
- Child lock
- Demo mode





R330JW
Midsize Microwave Oven

- 1,100W output power
- 320mm turntable
- 4 Instant Action Cook menus
- 4 Easy Defrost
- 3 Express Defrost
- 4 Instant Action Reheat menus
- Backlit 4 digit LCD display
- Instant Cook/Start key
- More/Less (power level key)
- Timer
- Clock
- Alarm
- Child lock
- Demo mode
- Also available in silver (R330JS)



R330NR
Midsize Microwave Oven

- 1,100W output power
- 320mm turntable
- 4 Instant Action Cook menus
- 4 Easy Defrost
- 3 Express Defrost
- 4 Instant Action Reheat menus
- Backlit 4 digit LCD display
- Instant Cook/Start key
- More/Less (power level key)
- Timer
- Clock
- Alarm
- Child lock
- Demo mode



R350LS
Midsize Sensor Microwave Oven

- 1,100W output power
- 320mm turntable
- Healthy meals: 5 low fat and 5 vegetarian options
- 16 Sensor Cook menus
- 6 Sensor Reheat menus
- 6 Easy Defrost
- 3 Express Defrost
- 6 Express Cook menus
- 3 Express Meal menus
- 6 Quick & Easy menus
- More/Less
- Instant Cook/Start key
- Timer
- Clock
- Alarm
- Child lock
- Demo mode
- Also available in white (R350LW)



R380LW
Midsize Sensor Microwave Oven

- 1,200W output power
- 320mm turntable
- 2 line Info Display
- Healthy meals: 5 low fat and 5 vegetarian options
- 16 Sensor Cook menus
- 6 Sensor Reheat menus
- 6 Easy Defrost
- 3 Express Defrost
- 6 Express Cook menus
- 3 Express Meal menus
- 6 Quick & Easy menus
- More/Less
- Instant Cook/Start key
- Timer
- Clock
- Alarm
- Child lock
- Demo mode



R395NS
Midsize Microwave Oven with Stainless Steel Fascia

- 1,100W output power
- 320mm turntable
- 4 Instant Action Cook menus
- 4 Instant Action Reheat menus
- 4 Easy Defrost
- 3 Express Defrost
- More/Less (power level key)
- Instant Cook/Start key
- Timer
- Clock
- Alarm
- Child lock
- Demo mode



R480LW
Large Sensor Microwave Oven

- 1,100W output power
- 360mm turntable
- Healthy Meals: 5 low fat and 5 vegetarian options
- 16 Sensor Cook menus
- 6 Sensor Reheat menus
- 6 Easy Defrost
- 3 Express Defrost
- 6 Express Cook menus
- 3 Express Meal menus
- 6 Quick & Easy menus
- More/Less
- Instant Cook/Start key
- Timer
- Clock
- Alarm
- Child lock
- Demo mode
- Also available in black (R480LK)



R398NS
Midsize Sensor Microwave Oven with Stainless Steel Fascia

- 1,100W output power
- 320mm turntable
- Healthy Meals: 5 low fat and 5 vegetarian options
- 16 Sensor Cook menus
- 6 Sensor Reheat menus
- 6 Easy Defrost
- 3 Express Defrost
- 6 Express Cook menus
- 3 Express Meal menus
- 6 Quick & Easy menus
- More/Less
- Instant Cook/Start key
- Timer
- Clock
- Alarm
- Child lock
- Demo mode



R490NS
Large Sensor Microwave Oven with Stainless Steel Fascia

- 1,100W output power
- 360mm turntable
- Healthy Meals: 5 low fat and 5 vegetarian options
- 16 Sensor Cook menus
- 6 Sensor Reheat menus
- 6 Easy Defrost
- 3 Express Defrost
- 6 Express Cook menus
- 3 Express Meal menus
- 6 Quick & Easy menus
- Instant Cook/Start key
- More/Less
- Backlit LCD
- Timer
- Clock
- Alarm
- Child lock



Chilli and Tomato Spaghetti

350g spaghetti, snapped in half
 1 ½ litres hot water
 1 birdseye chilli, finely chopped
 1 Spanish onion, finely chopped
 2 cloves garlic, finely chopped
 4 large roma tomatoes, diced
 3 tablespoons extra virgin olive oil
 salt and pepper to taste
 1 cup continental parsley, finely chopped

- In a large microwave safe glass bowl combine the spaghetti and hot water. Cook for 10-12 minutes on HIGH (100%), stirring after 5-6 minutes. Drain and set aside.
- In a medium microwave safe glass bowl add the oil, onion and chilli. Cook for 2 minutes on HIGH (100%).
- Add garlic, cook for 1 minute on HIGH (100%).
- Add tomatoes, salt and pepper, cook for 4 minutes on HIGH (100%), stirring half way through.
- Place spaghetti in serving dish, add parsley and sauce. Stir until well combined.
- Serve with freshly grated parmesan cheese.

Serves 4.



Chocolate Mousse

200g cooking chocolate
 2 tablespoons water
 2 tablespoons rum
 ¼ cup caster sugar
 3 egg whites
 300ml thickened cream
 extra cream, for decoration
 30g milk chocolate, grated

- In a large microwave safe glass bowl, combine the cooking chocolate, water and rum. Heat for 30-60 seconds on HIGH (100%), until the chocolate is melted, stirring once during cooking.
- Stir in the sugar. Allow to cool.
- When cool, whip the mixture until aerated. Set aside.
- Beat the egg whites until soft peaks form. Set aside.
- Whip the cream until it is thick but not stiff.
- Fold the cream and the egg white into the chocolate mixture.
- Divide the mousse evenly between four dessert glasses. Refrigerate until set. Serve decorated with the extra cream and chocolate shavings.

Serves 4.

Cooking with
a Convection
Microwave

Sharp convection microwave ovens combine the speed and simplicity of microwave cooking with the browning and crisping of fan-forced heat to produce conventional results in a fraction of the time. Convection microwave ovens offer four types of cooking:



R890NW
Compact Double Grill Convection Microwave Oven

- 1,200W top and 650W bottom grills can be used separately or simultaneously
- 900W Microwave output power
- Top and Bottom heater with convection fan
- Combination grill and microwave cooking
- 325mm turntable
- 6 Instant Action menus
- 6 Multi-cook menus
- 6 Convenience/Pizza menus
- 5 Easy Defrost
- More/Less (power level key)
- Mix Cooking key
- Grill Cook
- Convection Cook
- Preheat key
- Enamel tray
- Stainless Steel Interior
- High and Low racks
- Energy Save Mode
- Help Key
- Alarm
- Child Lock
- Demo mode
- Also available in Stainless Steel (R890NS)

TYPE OF COOKING	BENEFIT	SUITABLE FOR
MICROWAVE	Fast and efficient	Vegetables, rice and pasta
CONVECTION	Fan-forced heat to produce crisp brown exterior	Biscuits, pastries and bread
MIX COOKING	Combination of microwave and convection cooking	Cakes, slices and roast meats
FAN-FORCED GRILLING	The oven pre-heats automatically to 250 °C, circulating air to cook both sides for a grilled effect	Steak, chops and chicken pieces



R990KS
Large Sensor Convection Microwave Oven

- 900W microwave output power
- 1,500W convection power
- 390mm turntable
- 6 Sensor Instant Action menus
- 3 Sensor Reheat menus
- Low Mix Cook
- High Mix Cook
- 6 Multi-Cook menus
- Grill Cook
- Convection Cook
- Power level key
- Preheat key
- 5 Easy Defrost
- More/Less
- Instant Cook/Start key
- Clock
- Memory key
- Help key
- Alarm
- Child lock
- Demo mode
- Also available in white (R990KW)



R1900J
Commercial Microwave Oven with Dual Magnetron

- 1,900W output power
- Compact design and large capacity
- Twin Touch Control Panels
- 100 user programmable memories
- Double/Triple Quantity keys
- Repeat Cooking function
- Express Defrost function
- 11 Multiple Cooking sequences
- 15 amp plug, no additional wiring required
- Counter check
- Dual Magnetrons & stirrer fans for even cooking
- Solid, Stainless Steel, cabinet and cavity
- Demo mode
- Stacking option
- Service Door
- Program lock
- Custom settings
- Outside dimensions (WxHxD): 445 x 346 x 573mm
- Weight: Approx. 33.5kg



R2197J
Commercial Stainless Steel Microwave Oven

- 1,000W output power
- Stirrer fan for even cooking
- Stainless steel cabinet, durable and easy to maintain
- Express defrost
- Double quantity facility
- Multiple cooking sequences
- 11 power levels
- 20 user programmable memory
- 10 amp plug, no additional wiring required
- Demo mode
- Outside dimensions (WxHxD): 520 x 309 x 424mm
- Weight: Approx. 17kg



R2398JA
Commercial Microwave Oven with Dual Magnetron

- 1,500W output power
- Twin stirrer fans for even cooking
- Stainless steel cabinet and cavity
- 20 memory settings
- Double quantity facility
- Express defrost
- 11 variable cooking controls
- 10 amp plug, no additional wiring required
- Stacking option
- Outside dimensions (WxHxD): 510 x 335 x 470mm
- Weight: Approx. 35kg

How do I know the real size of my Sharp microwave oven?


Measuring interior cavity capacity

An easy way to understand how big a microwave oven is on the inside is to know the size of the turntable tray. This is measured as the diameter of a circle which is the length of a straight line starting at the left of the tray, running through the centre and ending on the right of the tray.


Knowing the size of the turntable tray makes it easy to know if your cookware will fit comfortably on the turntable and still have enough room to turn freely, without touching the sides of the oven.

See aerial view (cutaway)
Front view diagram below

AERIAL VIEW (CUTAWAY)



FRONT VIEW



Cavity size

Different manufacturers have created ovens with different interior cavity sizes. While some ovens are lower and wider, Sharp microwave ovens are higher and more compact. This makes it possible to put a tall bowl into the oven and still have the oven achieve maximum microwave reflection for even cooking.

Rotating turntable

Sharp Carousel microwave ovens have been designed with rotating turntables so that the food moves through the microwaves and helps to cook it more evenly.

How a microwave oven works

The best cooking results are achieved when food is heated evenly so that no one part of the meal is warmer or cooler than any other.

When you press the 'Start' button on your microwave oven, the magnetron is turned on.

In Sharp microwave ovens, the magnetron is located at either the back or the side of the oven.

The magnetron (see diagram below) produces microwave energy that moves down the waveguide and enters the interior cavity of the oven.

See the typical construction of a microwave oven illustration below.

The microwaves reflect and bounce off the interior cavity walls. This process causes the water molecules within the food or beverage to vibrate. As the water molecules vibrate, they become hot, cooking the food. This is why a dish is sometimes cool to touch when you remove it from the oven. Microwave-safe dishes become warm from the heat of the food, not from the microwaves.

Expert engineering

Sharp microwave ovens are strategically designed and engineered to maximise microwave reflection so that the microwaves are evenly distributed across the turntable area to assist in even cooking. If you look inside your Sharp microwave oven, you will see it is


not just square, but has curved shapes and indentations on the interior surface. These shapes help to distribute the microwaves efficiently. When you press the 'Stop' button or open the oven door, the magnetron is turned off. Just like turning off a light switch, the magnetron stops producing microwaves and the microwave energy in the oven cavity disappears.

Output power

Generally speaking, the greater the output power, the faster food will cook. For example, a 1,200 watt IEC-rated oven will cook food twice as fast as a 600 watt IEC-rated oven. This is not to say that you should always operate your oven at maximum power as some foods, such as dairy products, are best heated on low power settings.

As you can see, the size of the cavity is not what counts if you want even, efficient microwave cooking. Rather, it is the combination of the inside shape of the oven, the movement of microwave energy and food through the oven, and the output power that will help you get the best results from your Sharp microwave oven.

THE CONSTRUCTION OF A MICROWAVE OVEN



MODEL NO.		R200L(W)	R230L(S)	R290N(S)	R330J(W)/(S)	R330N(R)	R350L(W)/(S)	R380L(W)	R395N(S)/(BK)	R398N(S)	R480L(W)/(K)	R490N(S)	R890N(S)/(W)	R990K(S)/(W)
COLOUR		white	silver	stainless	white/silver	red	white/silver	white	stainless/black stainless	stainless	white/black	stainless	white/silver	stainless/white
OUTPUT POWER	(MICROWAVE/IEC)	800W	800W	800W	1100W	1100W	1100W	1200W	1100W	1100W	1100W	1100W	900W	900W
	(GRILL)	-	-	-	-	-	-	-	-	-	-	-	1100-1200W(Top) 600-650W(Bottom) 1700-1850W(Top&Bottom)	-
	(CONVECTION)	-	-	-	-	-	-	-	-	-	-	-	1700-1850W	1500W
POWER REQUIRED	(MICROWAVE)	1.22kW	1.22kW	1.22kW	1.60kW	1.60kW	1.60kW	1.67kW	1.60kW	1.60kW	1.60kW	1.60kW	1.50kW	1.60kW
	(GRILL)	-	-	-	-	-	-	-	-	-	-	-	1.76-1.91kW	-
	(CONVECTION)	-	-	-	-	-	-	-	-	-	-	-	1.76-1.91kW	1.60kW
CONVECTION		-	-	-	-	-	-	-	-	-	-	-	YES	YES
MIX (CONVECTION/MICROWAVE)		-	-	-	-	-	-	-	-	-	-	-	YES(HIGH/LOW)	YES(HIGH/LOW)
GRILL (CONVECTION 250°C)		-	-	-	-	-	-	-	-	-	-	-	YES	YES
PREHEAT		-	-	-	-	-	-	-	-	-	-	-	YES	YES
POWER LEVEL (MICROWAVE)		5	5	5	5	5	5	5	5	5	5	5	5	5
CONTROL PANEL		T/C	T/C	T/C	T/C	T/C	T/C	T/C	T/C	T/C	T/C	T/C	T/C	T/C
INFO DISPLAY		-	-	-	-	-	-	YES	-	-	-	-	-	YES
SENSOR		-	-	-	-	-	YES(AH)	YES(AH)	-	YES(AH)	YES(AH)	YES(AH)	-	YES(AH)
AUTOMATIC OPERATION		12MENUS	12MENUS	13MENUS	15MENUS	15MENUS	56MENUS	56MENUS	15MENUS	56MENUS	56MENUS	56MENUS	23MENUS	20MENUS
	INSTANT ACTION	Yes(5)	Yes(5)	Yes(6)	Yes(8)	Yes(8)	-	-	Yes(8)	-	-	-	Yes(6)	Yes(6)
	REHEAT	Yes(2)	Yes(2)	Yes(2)	Yes(4)	Yes(4)	-	-	Yes(4)	-	-	-	Yes(1)	-
	COOKING	Yes(3)	Yes(3)	Yes(4)	Yes(4)	Yes(4)	-	-	Yes(4)	-	-	-	Yes(5)	-
	SENSOR	-	-	-	-	-	-	-	-	-	-	-	-	Yes(6)
	HEALTHY MENU	-	-	-	-	-	Yes(10)	Yes(10)	-	Yes(10)	Yes(10)	Yes(10)	-	-
	LOW FAT	-	-	-	-	-	Yes(5)	Yes(5)	-	Yes(5)	Yes(5)	Yes(5)	-	-
	VEGETARIAN	-	-	-	-	-	Yes(5)	Yes(5)	-	Yes(5)	Yes(5)	Yes(5)	-	-
	SENSOR COOK	-	-	-	-	-	Yes(22)	Yes(22)	-	Yes(22)	Yes(22)	Yes(22)	-	Yes(3)
	REHEAT	-	-	-	-	-	Yes(6)	Yes(6)	-	Yes(6)	Yes(6)	Yes(6)	-	Yes(3)
	VEGETABLES	-	-	-	-	-	Yes(5)	Yes(5)	-	Yes(5)	Yes(5)	Yes(5)	-	-
	RICE/PASTA	-	-	-	-	-	Yes(6)	Yes(6)	-	Yes(6)	Yes(6)	Yes(6)	-	-
	DESSERTS	-	-	-	-	-	Yes(5)	Yes(5)	-	Yes(5)	Yes(5)	Yes(5)	-	-
QUICK AND EASY		-	-	-	-	-	Yes(6)	Yes(6)	-	Yes(6)	Yes(6)	Yes(6)	-	-
EASY DEFROST		Yes(4)	Yes(4)	Yes(4)	Yes(4)	Yes(4)	Yes(6)	Yes(6)	Yes(4)	Yes(6)	Yes(6)	Yes(6)	Yes(5)	Yes(5)
MULTI COOK		-	-	-	-	-	-	-	-	-	-	-	Yes(6)	Yes(6)
CONVENIENCE/PIZZA		-	-	-	-	-	-	-	-	-	-	-	Yes(6)	-
EXPRESS COOK		-	-	-	-	-	Yes(6)	Yes(6)	-	Yes(6)	Yes(6)	Yes(6)	-	-
EXPRESS MEAL		-	-	-	-	-	Yes(3)	Yes(3)	-	Yes(3)	Yes(3)	Yes(3)	-	-
EXPRESS DEFROST		Yes(3)	Yes(3)	Yes(3)	Yes(3)	Yes(3)	Yes(3)	Yes(3)	Yes(3)	Yes(3)	Yes(3)	Yes(3)	-	-
MORE/LESS		YES (POWER LEVEL key)	YES (POWER LEVEL key)	YES (POWER LEVEL key)	YES (POWER LEVEL key)	YES (POWER LEVEL key)	YES	YES	YES (POWER LEVEL key)	YES	YES	YES	YES	YES
INSTANT COOK/START KEY		YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES
TIMER		YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	-	-
CLOCK		YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES
MEMORY KEY		-	-	-	-	-	-	-	-	-	-	-	-	YES(1)
ALARM		YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES
HELP KEY		-	-	-	-	-	-	YES	-	-	-	-	YES	YES
AUTO START		-	-	-	-	-	-	YES(in HELP)	-	-	-	-	YES(in HELP)	YES(in HELP)
CHILD LOCK		YES	YES	YES	YES	YES	YES	YES(in HELP)	YES	YES	YES	YES	YES(in HELP)	YES(in HELP)
DEMO MODE		YES	YES	YES	YES	YES	YES	YES(in HELP)	YES	YES	YES	YES	YES(in HELP)	YES(in HELP)
INFO ON PADS		-	-	-	-	-	-	YES(in HELP)	-	-	-	-	YES(in HELP)	YES(in HELP)
GUIDE ON/OFF		-	-	-	-	-	-	-	-	-	-	-	-	YES(in HELP)
INFORMATION GUIDE ON/OFF		-	-	-	-	-	-	YES(in HELP)	-	-	-	-	YES(in HELP)	YES(in HELP)
COOKING STAGE		3	3	3	3	3	3	3	3	3	3	3	4	4
PICTORIAL KEY		-	-	-	YES	YES	-	-	-	-	-	-	-	-
DISPLAY		LCD(4)	LCD(4)	LCD(4)	LCD(4)	LCD(4)	NEW 1-line LCD(7)	2-line LCD(8+8) Dot	LCD(5)	NEW 1-line LCD(7)	NEW 1-line LCD(7)	NEW 1-line LCD(7)	1-line LCD(7)	DIGITRON(7)
OVEN INTERIOR		PAINTED	PAINTED	PAINTED	PAINTED	PAINTED	PAINTED	PAINTED	PAINTED	PAINTED	PAINTED	PAINTED	STAINLESS	STAINLESS
TURNTABLE DIAMETER		272mm	272mm	272mm	320mm	320mm	320mm	320mm	320mm	320mm	360mm	360mm	325mm	390mm
OUTSIDE DIMENSIONS	(W)	460mm	460mm	460mm	520mm	520mm	520mm	520mm	520mm	520mm	550mm	550mm	520mm	627mm
	(H)	275mm	275mm	275mm	310mm	310mm	310mm	310mm	310mm	310mm	315mm	315mm	309mm	378mm
	(D)	368mm	368mm	368mm	459mm	448mm	448mm	440mm	442mm	442mm	446mm	446mm	486mm	492mm
WEIGHT (Approx.)		12kg	12kg	12kg	16kg	17kg	17kg	17kg	17kg	17kg	18kg	18kg	19kg	29kg
DOOR OPEN		PUSH OPEN	PUSH OPEN	PUSH OPEN	PUSH OPEN	PUSH OPEN	PUSH OPEN	PUSH OPEN	PUSH OPEN	PUSH OPEN	PUSH OPEN	PUSH OPEN	PUSH OPEN	PUSH OPEN