



DISHWASHERS

DWIFABNE4SMEG BUILT-IN DISHWASHER, RETRO DESIGN







EAN 8017709357726

Size 598mmW x 600mmD x 850mmH

Capacity 14 place settings

Finish Black

Display LED indicators
Programs 10 +1 programs

End of cycle indicator On display, with acoustic signal

Baskets 2 Levels + cutlery basket

Wash system Orbital wash system

Water softener Yes

Temperatures 7 - 38°, 45°, 50°, 55°, 65°, 70°, 75°C

Features Special programs
Acquatest turbidity sensor

½ load FlexiZone

Upper basket adjustable in three levels on telescopic guides

Water softener Self balancing hinges

Water connection Cold or hot water connection (60°C max)

Timer Up to 9 hours, with automatic soak

Filtration Stainless steel 5 stage filteration

Drying Natural condenser drying, with Dry Assist + automatic door opening system at the end of the

cycle

Safety Total Acquastop anti flood protection system

Child safety system (control lock)

Noise 46 dB(A) re 1pW

Energy consumption 230 kWh per year using ECO program

Water consumption 11.3 litres per wash cycle using ECO program

Power 1800 W

220-240V /50 Hz/10 amp

Warranty Five years parts and labour

ORBITAL WASH SYSTEM

Smeg's orbital wash system has a major spray arm and satellite spray arm which spins ten times for every single revolution of the major spray arm to ensure water is thoroughly distributed in-between every piece in the wash for exceptional results.



HYGIENE 99.9%

High-temperature washing programme. The 75° rinse guarantees the removal of 99.9% of germs and bacteria, making it ideal for sanitising cutting boards and baby's bottles.

DRY ASSIST + AUTO DOOR OPENING

In addition to saving energy, it ensures perfect drying of the dishes by opening the door automatically at the end of the wash cycle

FULL EXPRESS 60'

The Full Express 60' program is designed to wash and dry a full load of crockery and glassware in 1 hour, making it ideal for everyday use.

AOUATEST - TURBIDITY SENSOR

The Auto wash program uses a turbidity sensor to measure the particles suspended in the water throughout the wash cycle. Based on the level of soiling detected, the program adjusts the temperature, duration, and water usage to optimise cleaning efficiency.

DELAY TIMER

Every Smeg dishwasher has a delay start option, which allows you to operate the machine during periods of off-peak or lower energy tariffs. The combination of excellent water and energy savings combined with time of use can ensure much lower running costs.





DISHWASHERS

Wash programs













Additional functions











Special wash programs















