

**90cm electric ceramic cooktop with variable zones, easy clean ceramic glass surface and QuickCook timer (TM) function.**

RRP AUS \$1,699.00



## Product Details

### FEATURES

---

<b>Pause</b> Pause and restart cooking at the touch of a button	<b>QuickCook Timer</b> Cook steaks and quick meals to perfection every time with the QuickCook count down timer.	<b>Touch on glass controls</b> Easy-clean touch on glass controls make it simple to control heat.	<b>Frameless ceramic glass</b> is stylish and so easy to clean.
<b>Residual heat indicators</b> For added safety, residual heat indicators show activated hotplates and hotplates still cooling down.	<b>Easy clean ceramic surface</b>	<b>Child lock</b>	

---

### BENEFITS

---

<b>More versatility with variable zones</b> Every recipe is different and so is every cook. That's why we designed not only four cooking positions, but also one hotplate as a triple zone. This gives you the unrivalled flexibility of having three variable zones in one, so you'll be ready for any sized pot.	<b>Pause when you need to</b> When you're cooking, those pesky interruptions wont be a bother anymore. That's because you can simply pause what you're doing. Just press the Pause icon on your cooktop and all operating zones will drop to a Keep Warm mode. And when you're ready to resume, touch the Pause icon again and all zones will return to their previous setting.
<b>QuickCook Timer</b> Now even when things get busy in the kitchen, you'll never lose track when you're cooking. This nifty timer counts down and even turns the zone off. Now you can cook the perfect steak or boiled eggs or any other meal exactly to your liking. You'll never ruin a quick family meal again!	<b>Stylish touch-on-glass controls</b> Styled to suit any kitchen, the flat touch-on-glass controls not only look great, but with no buttons, they're also really easy to wipe clean. What's more with a handy child lock, you wont have to worry about the kids playing with the oven or cook top controls.
<b>Easy clean ceramic surface</b> Not only aesthetically pleasing, the durable glass surface is easy to clean and maintain ensuring your kitchen is always looking at its best.	<b>Residual heat indicator</b> For added safety, residual heat indicators show activated hotplates and hotplates still cooling down.

---

## Specifications

### PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	ceramic
Materials/Colour	black ceramic glass
Removable trim (for cleaning)	No

### CONTROLS

Controls of Cooktops	touch
Position of controls	front
Functions of Cooktops	timer,Keep warm function,pause
Indicators/display	fault indicator,residual heat warning lamps
Features of Cooktop	safety cut off,electronic timer,safety child lock,hot surface indicator,sound off
Timer of Cooktop	programmable 99min,countdown

### DIMENSIONS

Total product height (mm)	46
Total product width (mm)	900
Total product depth (mm)	410
Cut out width (mm)	825
Cut out depth (mm)	360

### ELEMENTS/BURNERS

#### LEFT FRONT ZONE

Left front zone	ceramic triple
Left front Watts	2300
Left front number of cooking zones	3

## CONTROLS

Readable temperature setting	No
------------------------------	----

## CENTRE FRONT ZONE

Centre front zone	ceramic
Centre front Watts	1200
Centre front number of cooking zones	1

## RIGHT FRONT ZONE

Right front zone	ceramic
Right front Watts	1800
Right front number of cooking zones	1

## ELECTRICAL SPECIFICATIONS

Connected load KW	5.3
Type of connection	hardwired

# Terms and Conditions

## IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

## PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

## WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

### ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: [customercare@electrolux.com.au](mailto:customercare@electrolux.com.au)

web: [www.electrolux.com.au](http://www.electrolux.com.au)

### ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: [customercare@electrolux.co.nz](mailto:customercare@electrolux.co.nz)

web: [www.electrolux.co.nz](http://www.electrolux.co.nz)