

LIGHTING INSTRUCTIONS

- 1. Ensure appliance control knob is OFF. Open the gas cylinder valve.
- Push in control knob and turn anti-clockwise to IGNITE, hold knob in, whilst simultaneously pressing the igniter button, a pulsating sound will be heard. Watch for pilot to light.
- 3. With the pilot alight, keep control knob depressed for 15 seconds.
- 4. For maximum heat push in and turn the control knob to HIGH.
- 5. For minimum heat turn the control knob to LOW.
- 5. To turn heater off turn the control knob to OFF.

Warning: Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.



USE OUTDOORS ONLY

KEEP THIS HEATER AWAY FROM COMBUSTIBLE MATERIALS
MINIMUM CLEARANCES

REAR 650mm - SIDE 650mm - TOP 800mm

USE ONLY AS RECOMMENDED

KEEP CHILDREN AWAY FROM THIS APPLIANCE

INDOOR USE MAY CAUSE DEATH

TURN GAS OFF AT CYLINDER VALVE AFTER USE

THIS HEATER MUST BE PROTECTED FROM EXPOSURE TO RAIN

DISCONNECT AND REMOVE CYLINDER BEFORE STORING THIS HEATER INDOORS

DO NOT OPERATE IN AN UNVENTILATED AREA

DO NOT OPERATE INDOORS

DO NOT PLACE ARTICLES ON OR AGAINST THIS APPLIANCE

DO NOT OPERATE THIS APPLIANCE BEFORE READING THE INSTRUCTION BOOKLET

DO NOT STORE CHEMICALS OR FLAMMABLE MATERIALS, OR SPRAY AEROSOLS NEAR THIS APPLIANCE

DO NOT OPERATE WITH PANELS, COVERS OR GUARDS REMOVED FROM THIS APPLIANCE

DO NOT OPERATE THIS APPLIANCE BEFORE LEAK CHECKING HOSES AND GAS CYLINDER CONNECTION

OUTDOOR HEATER

MODEL	GAS CONSUMPTION	PRESSURE kPa	INJECTOR ORIFICE	GAS TYPE	Approval
PH08OS PH08-19-OS	30 MJ/h	2.75 kPa	1.6mm	PROPANE	GMK10492

Exim International (Australia) Pty Ltd 24 Newheath Drive, Arundel Industrial Park, Arundel, QLD, Australia, 4214 FOR CORRECT OPERATION REFER TO INSTRUCTIONS PROVIDED





D.O.M.

FILE NAME: LightingWarningData_Label

SIZE: 95mm wide x 210mm high

COLOURS: ■ Red ■ Yellow ■ Black

STOCK: Sticker