


60cm 3 zone black ceramic induction cooktop with PowerBoost function, Pause option, touch on glass control and QuickCook™ timer.

RRP AUS \$1,299.00



Product Details

FEATURES

Induction Enjoy the safety, speed and efficiency of induction cooking.	Boost Boost up power to cooking zones by more than 25%.	Pause Pause and restart cooking at the touch of a button	Touch on glass controls
QuickCook Timer Cook steaks and quick meals to perfection every time with the QuickCook count down timer.	Perfect heat control	Child safety device	Residual heat indicators For added safety, residual heat indicators show activated hotplates and hotplates still cooling down.

BENEFITS

Transition to Induction cooking with ease Make the easy upgrade to induction cooking from your ceramic or electric solid cooktop. With the standard 6.5kW of power required, there's no fuss needed to change your power supply over. So get instant control with our induction cooktop today.	PowerBoost - for faster boiling Increase the power of your cooktop with PowerBoost to boil water rapidly, or quickly heat up your pan.
Pause when you need to When you're cooking, those pesky interruptions wont be a bother anymore. That's because you can simply pause what you're doing. Just press the Pause icon on your cooktop and all operating zones will drop to a Keep Warm mode. And when you're ready to resume, touch the Pause icon again and all zones will return to their previous setting.	Touch on glass controls With flat easy-clean touch on glass controls at your fingertips, you can easily control the heat. So all you need to do is concentrate on preparing the perfect meal.
QuickCook Timer Now even when things get busy in the kitchen, you'll never lose track when you're cooking. This nifty timer counts down and even turns the zone off. Now you can cook the perfect steak or boiled eggs or any other meal exactly to your liking. You'll never ruin a quick family meal again!	

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	Induction
Materials/Colour	black ceramic glass
Removable trim (for cleaning)	No

CONTROLS

Controls of Cooktops	touch
Position of controls	front
Functions of Cooktops	timer,Keep warm function,pause,power booster
Indicators/display	fault indicator,residual heat warning lamps
Features of Cooktop	safety cut off,electronic timer,safety child lock,hot surface indicator
Timer of Cooktop	programmable 99min,countdown

DIMENSIONS

Total product height (mm)	46
Total product width (mm)	590
Total product depth (mm)	520
Cut out width (mm)	560
Cut out depth (mm)	490

ELEMENTS/BURNERS

LEFT FRONT ZONE

Left front zone	induction
Left front Watts	1400
Left front boost watts	2500
Left front number of cooking zones	1
Left front diameter	140

CONTROLS

Readable temperature setting	No
------------------------------	----

LEFT REAR ZONE

Left rear zone	induction
Left rear watts	1800
Left rear number of cooking zones	1
Left rear diameter	180

RIGHT FRONT ZONE

Right front zone	induction
Right front Watts	3600
Right front number of cooking zones	1
Right front diameter	280

ELECTRICAL SPECIFICATIONS

Connected load KW	6.5
Type of connection	hardwired

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz