
Crest Smart Lock

HEAVY DUTY

PADLOCK SHFHDP











IP64 Water Resistant










Know your Lock:

- 1. Lock Shackle
- 2. LED Indicators
- 3. Fingerprint Reader
- 4. Micro-USB Charging Port
- 5. Keyhole for Supplied Key
- 6. Lock Body



Note:

You must set up the master fingerprint via the App, if not, the lock will remain in display/factory mode and will be able to be unlocked with any fingerprint

Understand your Lock Status:

LED Indicator	Beep Sound	Status / Notifications
BATTERY STATUS INDICATION		
Flashing Red (after unlocked)		Low Power Alert
On Red (Solid)		Charging
Lights Off		Charging
WORKING STATUS INDICATION		
 Flashing Green 	Single Beep	Unlocked
 Flashing Red 	Single Beep	Unlock Failed
WHEN ADDING FINGERPRINTS		
On Blue	Single Beep	Waiting for Press
 Flashing Green 	Single Beep	Recognized
	Long Single Beep	Fingerprint Registered

Specifications:

Fingerprint Resolution: 120 x 120 DPI

Fingerprint Storage: 10 Sets

Rechargeable Battery: 300mAh Capacity

Input Voltage: 5V DC

Shackle: 10mm Stainless-steel

Low Power Alert:

The indicator LED light on the lock will flash red when the battery is low. Please recharge using a Micro-USB Cable and a 5V DC USB Charger.


Warning on Water Resistance:

Ensure the lock in not submerged in liquid. A Product with an IP64 Rating is protected against dust and is completely protected against solid objects. It is also protected from water splashing from any angle





More Functions:



Alarm Logs: Wrong fingerprint attempted alarm, battery low power alarm Users: Add/manage/remove family members, friends or visitors

(by adding their App Account) to your lock so they will have access to your lock at a designated time period

Unlock Logs: A list of unlock records

Linkage Setting: You can set "if this then that" linkage on this function

Download the Mobile App:

You can search Crest Smart in the iOS App Store (Apple) or Google Play Store (Android), or scan the QR code to download Crest Smart App









Connect your Lock with App:

Step 1: Open the App, register an account

Step 2: Press the fingerprint reader to unlock

for initial set up, updates and for normal operation

Step 3: Tap + on the App Step 4: Tap "Go to add"





Step 5: Tap NEXT

Step 6: Press and hold at to test lock to App connection





Add your Fingerprints:

Step 1: Tap 000 on the bottom-right corner

Step 2: Tap 🧥

Step 3: Tap +

Step 4: Select User





Step 5: Tap > after selecting a user





Step 7: Press the fingerprint reader (of your lock) several times at slightly different angles until fingerprint is successfully recorded

Step 8: Name the fingerprint you've just added





Disconnect (Reset to Factory Mode):

Step 1: Tap on the lock's homepage (top-right)

Step 2: Tap "Remove Device"

Step 3: Tap "Disconnect and wipe data"

NOTE!

All fingerprints previously set will be deleted if you choose "disconnect and wipe data".

Step 4: Tap "Confirm" to disconnect the lock from your App account, the lock is now reset to the display/factory mode and will be able to be unlocked with any fingerprint



PO Box 5658 Brendsle QLD Australia 4500 Customer Support 1800 812 261 www.crest.com.au AUSTRALIAN OWNED



Please note, not all options within the App maybe be available for the lock due to future App and product software updates