

# 70cm Ceran Touch Electric COOKTOP

PRODUCT CODE: **ECT70C6**



## FEATURES:

- + Smooth Ceran glass electric cooktop
- + 6 hi-lite elements
- + Front sensor touch control operation
- + Residual heat indicator
- + 99 minute timer function
- + 9 power stage settings
- + Auto switch off safety
- + Fits into a 60cm cutout
- + Child lock
- + "On" indicator light
- + Square edge design

## RESIDUAL HEAT INDICATOR

To ensure that you know which electric hotplate is in use, this cooktop is equipped with a heating level indicator. After cooking, there will be some residual heat remaining & the letter "H" will appear to warn you to keep away from burner until it cools down.

## CHILD SAFETY LOCK

The child safety lock acts as protection to ensure that your desired temperature cannot be altered without unlocking the cooktop.

## SENSOR TOUCH CONTROL

The ECT70C6 cooktop is equipped with a stylish touch sensor control panel, adding a touch of style and elegance to your kitchen.

## 6 HILITE ELEMENTS

This cooktop is fitted with 6 hi-lite elements to ensure rapid heat up.

## SMOOTH CERAN GLASS COOKTOP

A high-grade Ceran glass is used for this cooktop to ensure easy cleaning of the smooth Ceran surface.

## SPECIFICATIONS:

<b>Electrical Requirements</b>	40 amp dedicated circuit from cooktop to main switchboard
<b>Voltage</b>	220V-240V
<b>Frequency</b>	50Hz
<b>Total Rated Load:</b>	6600W
<b>Cooking Zones:</b>	
- Front Left Element	1100W/2000W
- Rear Left Element	1200W
- Rear Right Element	1000W/2200W
- Front Right Element	1200W
<b>Weight</b>	11.0kg (Gross)/ 9.2kg (Net)
<b>Product Dimensions</b>	W700mm x D520mm



eurocooking

**3**  
YEARS

Warranty

## CLEANING AND MAINTENANCE

- Cleaning operations must only be carried out when the appliance is completely cool.
- Clean the appliance regularly, preferably after each use
- Abrasive cleaners or sharp objects will damage the appliance surface; you should clean it using water and a little washing up liquid

## TIPS FOR BETTER USE

- Always use pans with a flat base to ensure even contact with the hotplate
- The correct size of pan should be used so that the whole of the element is covered

## INSTALLATION DIAGRAM

