

Manual for Ice Crusher



1. Operation instructions

(1) Check whether the power voltage conforms to that on the designation plate and the power should connect to the reliable ground wire.

(2) Raise ice crushing handle to the upper stop, connect to the power, turn on the master switch and place the ice basin on the underframe with the ice cubes put into the ice crushing barrel. (Note: Quantity of the ice cubes should not exceed the ice crushing barrel level). Then press down the ice pressing handle to make the protective switch automatically turned on and crush the ice. After finishing, please raise the ice crushing handle to the upper stop again and repeat the above mentioned operation process.

2. Keep clean

After using the ice crusher, the switch should be turned off. Disconnect the power plug and wipe dry the body, then place the machine in the dry place.

3. Cautions

When using, the outlet of ice cubes cannot be jammed or the cutter head may get stuck and the motor may be burnt out. If the abovementioned conditions appear, please find out the reasons immediately, cut off the power and raise the handle.

Note: in order to continuously improve our products, our company has a right to modify the above mentioned technical parameters without giving notifying.

4. Technical parameters

Model	SIS-300B	SIS-300D	SIS-300F
Voltage	200~240V		
Power	280W	300W	300W
Frequency	50Hz~60Hz		
Weight	5.1KGS	5.2KGS	6.0KGS
Revolution	2000R/M		
Crushing weight	65kg per hour		