

A white, universal rangehood with inter-locking push button controls, 900mm in width, with a 3 speed dual centrifugal fan.

RRP AUS \$429.00





# **Product Details**

#### **FEATURES**

Auto thermal cutout safety switch	Push button controls	3 x filters	Washable filters
3 fan speeds	Optional carbon filter(s)	Front re-circulating option	Top and rear duct hole options

Two halogen lights

#### **BENEFITS**

Easy installation

The rangehood is easily installed either partially behind cupboard doors or simply under cabinetry.

Easy to clean

Removable filters for easy cleaning, and the rest of the rangehood is easy to maintain - simply wipe down.

Recirculation

The rangehood can recirculate into the kitchen if it is not possible to duct to the exterior. Carbon filters are recommended for recirculation.

Simple operation

Simple to use push button controls with 3 power settings to provide flexible air movement to manage diverse cooking demands.



# **Specifications**

## PRODUCT PROFILE

Domestic warranty details (yrs)	2
Type of Rangehood	fixed
Nominal width	900
Finish of Rangehood	white

## MOTOR/FAN

Number of fans	2
Number of fans speeds	3
Type of motor	centrifugal
Maximum airflow M3/Hr	360
Noise level dB high	70
Noise level dB low	62

## **DIMENSIONS**

Total product height (mm)	160
Total product width (mm)	898
Total product depth (mm)	500
Diameter of ducting (mm)	120
Minimum installation height from cooking surface Gas (mm)	650

## CONTROLS

Control panel	push button



## **DIMENSIONS**

Minimum installation height from cooking surface Electric (mm) 600

## **FILTERS**

Number of filters	3
Type of filter	multilayer aluminum micromesh filters
Dishwasher safe	Yes

## **LIGHTS**

Number of lights	2
Wattage of light	28
Type of light	halogen

## **DUCTING / RECIRCULATION**

Ducting	yes
Top or rear duct hole	both
Recirculation option	Yes
Recirculation kit	optional accessory
Front recirculating option	Yes

## **SHIPPING**

Pack Dimensions Height (mm)	260
Pack Dimension Width (mm)	980
Pack Dimension Depth (mm)	590



# **Terms and Conditions**

#### **IMPORTANT**

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

#### PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

#### WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

#### **ELECTROLUX HOME PRODUCTS AUSTRALIA**

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

**ELECTROLUX HOME PRODUCTS NEW ZEALAND** 

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz