

# **AIRFLO®**

## **INSTRUCTION MANUAL**




**Bagless Vacuum Cleaner**  
**Model:AFV 717**

### **Safety directions:**

1. For the first operation, it is advisable to read the manual carefully beforehand and keep it for future use.
2. Before the first operation, make sure the dust barrel is properly installed.
3. Make sure the power supply is 220-240V, 50/60Hz
4. Do not vacuum water and inflammable material.
5. Do not vacuum burning material and ashes.
6. Do not use the machine without a motor protection filter filled.
7. Do not let the machine become overheated. Store in a cool, dry place.
8. This appliance is not intended for use by person (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
9. Do not allow children to operate the appliance or use as a toy.
10. If abnormal noise, smell, smoke or any other failure or breakage is found during operation, turn off the switch and unplug it. Contact the service center for repair. Do not repair by yourself.
11. If the supply cord is damaged, it must be replaced by the manufacturer of its service agent or a similarly qualified person in order to avoid a hazard.

### **Parts:**



## Operation methods:

1. Connect the hose accessories: insert the hose end into the hose socket and then press and clip it (Fig 1)
2. Connect the hose elbow to the rod. (Fig 2)
3. Connect the different vacuum cleaner tools to the plastic rod for different cleaning purposes: Floor brush for carpet or hard floor (Fig 3); Combined brush and nozzle for sofa, wall surface, curtains, corners or spaces between furnitures, etc. (Fig 4)
4. Your machine is ready to operate. (Fig 5)
5. To rewind cord: pull the plug out of the socket and then press the cord rewinding button. (Fig 6)



1



2



3



4



5



6

## **Cleaning and Maintenance:**

### **1. Empty out the dust cup.**

- Press the dust cup release (Fig 1)
- Empty out the dust cup. (Fig 2)
- To remove the filter, take out the dust cup and open up the cover by unlocking the twist lock. (Fig 3)
- Remove the HEPA filter (Fig 4)

### **2. Clean the outlet filter.**

- Remove the air outlet grill cover by hand. (Fig 5)
- Wash filter with water. Let dry. (Fig 6)



1



2



3



4



5



6