


CI604DTB2

60cm 4 Zone Touch&Slide Induction Cooktop

Traditionally we cook by generating heat from one source, such as a flame, and conducting it to another.


The Fisher & Paykel Induction Cooktops work on a different principle. The cooktop itself produces electromagnetic vibrations, which induce the pot or pan to generate its own heat. The results are shorter heat-up times, greater precision and a safer cooking surface.

Frameless glass



Dimensions

Depth	A	530mm
Height		50mm
Width	B	600mm



Specifications

Cleaning	
Flat easy clean glass surface	•
Controls	
Auto cut-off timer for each zone	•
Individual cooking zone controls	•
Minute timer	•
Soft-touch electronic controls	•
Touch&Slide controls	•

Performance	
Auto heat reduce	•
Dual colour display	•
GentleHeat	•
Heat settings	9
Induction cooking technology	•
PowerBoost	•
SmartZone	•
Zone bridging	•
Power requirement	
AMP draw	30 A
Supply voltage	220-240V
Safety	
Key lock	•
Pan detection system	•
Safety time out	•
Spillage auto off	•
Surface hot indicators	•
Warranty	
Warranty	2 year parts & labor
vialiancy	warranty
Zone ratings	
Left front zone (PowerBoost set)	2100W (3700W)
Left rear zone (PowerBoost set)	2100W (3700W)
Right front zone (PowerBoost set)	2100W (3700W)
Right rear zone (PowerBoost set)	2100W (3700W)

SKU 80849

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. © Fisher & Paykel Appliances Ltd 2016

Other product downloads available at fisherpaykel.com

fisherpaykel.com



Data Sheet