

User guide Billi B-1000



Contents

warnings & important information	_
General Maintenance	3
Features and Modes	3
Filtration Information	+
Changing the filter	+
Service Support 5	5

Warnings & Important information

- For continued safety of this appliance it must be installed, operated and maintained in accordance with the manufacturer's instructions.
- Your appliance should be installed by a suitably qualified tradesperson.
- For correct operation of this appliance it is essential to observe the instructions as outlined in this booklet.
- Do not use this appliance with water that is microbiologically unsafe or with water of unknown quality without adequate disinfection before or after the system. Systems certified for cyst reduction may be used on disinfected water that may contain filterable cysts.
- Filter replacement must be performed at intervals of not more than 12 months.
- Use this appliance only as directed in these instructions and only for its designed purpose.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid creation of a hazard.
- New hose sets supplied with the appliance are to be used. Old hose sets should not be re-used.

General Maintenance

Your Billi B-1000 has been designed to require minimal maintenance other than replacement of filter cartridges. During each filter change, check all water connection fittings for signs of leakage. Check all tubing for any signs of damage. Check the cupboard area around the base of unit for any signs of moisture.

Cleaning the dispenser

Your B-1000 Dispenser is fabricated from robust metal with a tough protect chrome plating. Care of dispenser is as with any chrome plated tapware. Avoid using abrasive cleaners. Wipe clean using a damp cloth. Use of a non-solvent, non-smearing cleaner such as Windex is recommended. Do not pour water over dispenser.

Unit operation

Slimline Dispenser

To dispense filtered water, the dispenser tap lever will need to be rotated. The lever will automatically return to the off position. The spout can be swivelled to suit your installation.

Billi Filter Cartridges

The B-1000 features the Billi dual stage filtration system. It is fitted with single dual stage filter incorporating sediment and chemical removal elements. All B-1000 filters are manufactured using bacteria and biofilm resistant materials for improved water quality.

Premium filters provide a better tasting water due to the high quality, carbon chemical removal filter. Sub-micron rated, these filters have excellent chemical absorption, removing or reducing chlorine, volatile organic compounds (VOCs), chemicals, tastes and odours. All drinking water filtration systems should be flushed after a period of non-use.

There are 2 types of filter cartridge sets offered.

994001 5.0 micron replacement filter 994002 0.2 micron replacement filter

Use only genuine Billi Filter Cartridges as designed for this system.

If the system has not been used for a period of 3 days or more, lift the dispenser lever and flush the system for at least 1 minute.

Filter Cartridges Service Interval

Periodic replacement of your Billi B-1000 filter cartridge is necessary to maintain the sparkling freshness of your drinking water.

Your Billi Representative will advise you of an appropriate service interval. As a guide, the filters should be serviced twice yearly. In areas where water supply has a high level of sediment, more frequent replacement of filter cartridges may be necessary. This will become evident when a significant drop in delivery flow rate occurs.

Filter Cartridge Replacement

When you receive your replacement cartridges, follow the procedure as outlined below:

- 1. Turn off water supply to unit.
- 2. Remove front panel to unit.
- 3. Turn temperature control to OFF
- 4. Open tap to release any pressure.
- 5. Close tap.
- Grasp the bottom of the filter and pull towards yourself slowly. The top of the filter is in a hinged cradle assembly. It should stop after approximately 30 degrees of travel.
- 7. The filter can now be released from the holding cradle by pulling down on the filter.
- 8. Take care not to spill water in the base of the tray. If so wipe gently with blotting paper.
- 9. Install new filter into the same location by pushing up into the cradle all the way.
- 10. Push filter forward until upright and locked in place.
- 11. Turn water supply to unit on.
- 12. Open tap again.
- 13. Run water for 2-3 minutes to flush all air out and condition the filter.
- 14. Close tap.
- 15. Check for any leaks from around the filter, hosing or pipe work.
- 16. Turn temp control to ON & set temperature to desired level.
- 17. Close front cover.

Thank you for choosing to install a Billi B-1000 Drinking Water Appliance. Your B-1000 is manufactured to exacting standards using high quality materials and with proper maintenance and care, should function for many years.

For information on our filtration and service contract please contact Billi Head Office on 1800 812 321 or email us at service@billi.com.au.

For technical support please call 1800 812 321 and speak to one of Billi's experienced technician's.

To book a service call out request a filter change or please contact the Billi Service Centre on 1800 812 321 or book online at www.billi.com.au

Filter cartridges are also available for purchase online at www.billi.com.au



Billi Pty Ltd

42 Lucknow Crescent, Thomastown Victoria 3074 Australia

Telephone +61 3 9469 0400 Facsimile +61 3 9469 0499

www.billi.com.au

Designed and manufactured in Australia.

As Billi Pty Ltd has a policy of continual improvement, all details are subject to change without notice. All goods are sold subject to our published terms and conditions. Billi is a registered trademark. 0217