

# **nutribullet**

JUICER™



# **User guide.**

**⚠ WARNING!** To reduce the risk of serious injury, read this User Guide before operating your nutribullet Juicer™. Save these instructions. Be sure anyone who uses the nutribullet® knows how to do so safely.

# Important safeguards.

**Warning! To avoid the risk of serious injury, carefully read all instructions before operating your nutribullet Juicer™. When using any electrical appliance, basic safety precautions should always be observed, including the following important information.**

## PERSONAL SAFETY

**WARNING!** This juicer system has sharp blades and moving parts, and is **NOT** intended for use by children who lack experience and knowledge of its safe operation. They require close supervision and thorough instruction on its proper use and safe operation.

Keep the appliance and its cord out of reach of children. Children shall not play with the appliance. To eliminate a choking hazard for young children, remove and safely discard the protective cover fitted to the power plug of this juicer.

### **AVOID CONTACT WITH MOVING PARTS.**

Keep hands, fingers, hair, clothing as well as spatulas and other utensils away from the appliance during operation. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and

knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

### **SIEVE AND BLADES ARE SHARP! HANDLE WITH EXTREME CARE!**

Do not touch the small cutting blades/teeth on the bottom/base of the sieve. Keep fingers away from the sharp blade in the feed chute.

Do not leave the appliance unattended when in use.

Hard fruits and vegetables will put excess strain onto the motor if a low speed is selected.

**If there is a spill under, around or onto the juicer itself, disconnect the unit from the power source. Clean with a cloth and allow unit to dry completely before operating.**

Do not push food into the feed chute with your fingers or utensils. Only use the food pusher provided. Do not place your hand or fingers into the feed chute when it is attached to the juicer. If food becomes

lodged in the feed chute, use the food pusher provided or another piece of fruit or vegetable to push it down. Turn the motor off and ensure that all moving parts have stopped before disassembling the juicer to remove the remaining pulp.

Do not operate this or any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

**Always ensure the juicer is turned OFF after each use. Before disassembling, make sure the sieve has stopped rotating and the motor has completely stopped.**

## PRODUCT SAFETY

**This juicer is only designed to juice fruits and vegetables. Please refer to the juicing guide to determine the correct speed for the fruits and vegetables selected for juicing. Do not use any frozen fruits or vegetables.**

Do not use the juicer without the pulp basin and basin lid attached to the motor base. Please see assembly instructions for proper placement.

**Remove and safely discard any packaging material or**

**promotional labels before using the juicer for the first time.**

**Ensure that the surface where the appliance operates is stable, level, clean, and dry.**

**Remove rind from all citrus fruits before juicing.**

Do not juice stone fruit unless pits of the seed stone has been removed.

Always make sure the pulp basin cover is clamped securely in place (with locking handle) before the motor is turned on. Do not unfasten the clamps (locking handle) while the juicer is in operation.

When using this juicer, make sure there is adequate air space around and under it for proper air circulation.

The use of attachments not recommended or sold by nutribullet® may cause fire, electric shock or injury. This juicer is for household use only. Do not use this juicer for anything other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors. Misuse may cause injury.

If no speed is selected after 10 minutes, the unit will power off.

If the motor stops for any reason, unplug the power base and let it cool for at least 15 minutes.

Turn the juicer **OFF**, then unplug from the outlet when not in

use, before assembling or disassembling parts and before cleaning. To unplug, grasp the plug and pull from the outlet. Never pull from the power cord.

Do not let the power cord hang over the edge of a table or counter-top.

Do not let the power cord touch hot surfaces, such as a stove or let it become tangled or knotted.

Regularly inspect the power cord, plug and the actual juicer for any damage.

To protect against fire, electrical shock and injury to persons, do not immerse the juicer, Motor Base, cord or plug in water or any other liquid.

The cleaning brush and sieve are consumable components. Over time, if the unit starts to get louder or make unusual noises or vibration, it indicates that this consumable part may need replacing. The continued use of worn parts may result in part failure and/or personal injury.

Do not use the juicer if the rotating sieve is damaged; if the filter mesh is torn, crinkled or deformed in anyway. For high use users, we recommend replacing your sieve every 12 months or as needed for optimal performance. You can purchase both the sieve and the cleaning brush at **www.bulletbrands.com.au / www.bulletbrands.co.nz** or contact customer service.

Keep the juicer clean. Refer to care and cleaning section for further information.

**WARNING!** Vibration can occur during normal operation.

If extreme vibration occurs, discontinue use and call Customer Service.

Any maintenance other than cleaning should be performed by an authorized electrician. Do not attempt to repair or service the juicer, contact Customer Service for assistance at **www.bulletbrands.com.au / www.bulletbrands.co.nz**

# ! Save these instructions!

## FOR HOUSEHOLD USE ONLY

# Contents.




<b>03</b>	<b>Important safeguards</b>
<b>08</b>	<b>What's included</b>
<b>09</b>	<b>Assembly guide</b>
<b>10</b>	<b>Assembly &amp; use</b>
12	Usage instructions
15	Control dial
16	Juicing tips
<b>20</b>	<b>Disassembly</b>
<b>22</b>	<b>Care instructions</b>
23	Replacement parts
23	How to store
<b>24</b>	<b>nutribullet Juicer™</b>
	<b>one-year limited warranty</b>
<b>27</b>	<b>Product registration</b>

Thank you for purchasing the nutribullet Juicer™.

# What's included.




800 WATT MOTOR  
BASE WITH  
LOCKING HANDLE



PULP BASIN COVER  
WITH 76 MM  
FEED CHUTE



FOOD PUSHER



1.5L PULP BASIN WITH  
NO-DRIP SPOUT



STAINLESS STEEL SIEVE



800 ML JUICE PITCHER




JUICE PITCHER LID  
WITH FROTH SEPARATOR



CLEANING BRUSH

# Assembly guide.



food pusher

76 mm feed chute

basin cover

stainless steel  
sieve (inside basin)

1.5L pulp basin

locking handle

no-drip spout

juice pitcher lid

dual-speed  
control dial

motor base

800 ml juice  
pitcher


# Assembly.



- 1 Place the **Motor Base** on a dry, level counter top. Ensure the **Power Button**, in the center of the dial, is in the **"OFF"** position, and the unit is unplugged.



- 3 Align the **Sieve** with the motor drive coupling, carefully holding it by the rim to avoid touching the sharp teeth at the base. Push down until it clicks into place, ensuring it's securely seated in the **Pulp Basin**.




- 5 Secure the **Locking Handle** into the "ears" on either side of the **Basin Cover**. The handle will click into place when locked.


**NOTE:** The juicer will not power on if the **Locking Handle** is not properly secured.




- 7 Place the **Juice Pitcher Lid** on top of the **Juice Pitcher** and open the flip-top portion of the **Juice Pitcher Lid**.



- 2 Place the **Pulp Basin** on top of the **Motor Base**. Align the **Pulp Basin** with the **Motor Base** so that the **No-Drip Spout** is aligned with the dimpled side of the **Motor Base**.



- 4 Place the **Basin Cover** over the **Sieve** and **Pulp Basin**. The side "ears" on the **Basin Cover** should align with the "ears" on the sides of the **Pulp Basin**.



- 6 Ensure the **No-Drip Spout** opening is facing down for proper juice flow.



- 8 Secure the **Juice Pitcher** by angling it slightly so the **No-Drip Spout** fits into the flip-top opening. Then, set the **Juice Pitcher** flat on the surface, ensuring the **No-Drip Spout** sits snugly inside.


# Usage instructions.



- 1** Gather all of your desired ingredients and wash them. Prepare the ingredients to be juiced by cutting, skinning, or removing the rind, stems, or stone seeds.



- 2** Once the juicer is assembled, plug the power cord into an outlet. Use the **Dual-Speed Control Dial** to select a speed, then press the **Power Button** to begin juicing. You can switch between speeds as needed based on the type of produce (refer to the chart on page 16 for recommendations).




- 3** Start the motor **FIRST** before inserting ingredients. With the motor running, use the **Food Pusher** to gently guide ingredients down the **Feed Chute**.

**NOTE:** When pushing ingredients through the **Feed Chute**, avoid using excessive force or speed, as this can reduce juice yield.

**! WARNING! DO NOT use excessive force when pushing ingredients through the Feed Chute, as this can reduce juice yield and may damage the unit.**


**! WARNING! Never use hands/fingers or other tools to push food down the Feed Chute into the Sieve. Only the Food Pusher should be used to push down ingredients.**



- 4** Juice will flow from the **No-Drip Spout** into the **Juice Pitcher**, while pulp is separated and stored in the **Pulp Basin**. Ensure the **No-Drip Spout** is facing down for proper juice flow.



- 5** If the **Pulp Basin** becomes too full during juicing, you will need to empty it before continuing juicing. See Disassembly Instructions on page 20.



- 7** Remove the **Juice Pitcher** by tilting it forward at a slight angle to create separation between the flip-top opening and the **No-Drip Spout**, then slide it out. You can store juice in the **Juice Pitcher** if desired.



- 6** Turn the juicer off by pushing the **Power Button**. Unplug the unit. Wait until the **Sieve** comes to a complete stop spinning before proceeding to remove the **Juice Pitcher**.




- 8** Immediately turn the **No-Drip Spout** upward to prevent any residual drips onto the unit or surface below.

**TIP:** Use your left hand to pull the **Juice Pitcher** away while using your right hand to turn the **No-Drip Spout**.


# Control dial.

## DUAL-SPEED CONTROL DIAL & JUICING SETTINGS




### OFF:

Off is the default position for your juicer. When the unit is off, the center **Power Button** is flush with the **Dial Ring** and the green indicator ring is not visible.



### LOW SPEED (I):

For low speed, align the single-line on the **Dial Ring** with the white dot above. Press the **Power Button**. The green indicator ring will be visible and the machine will start juicing. Use this speed for softer fruits and vegetables.



### HIGH SPEED (II):

For high speed, align the double-line on the **Dial Ring** with the white dot above. Press the **Power Button**. The green indicator ring will be visible and the machine will start juicing. Use this speed for harder ingredients like carrots and beets.




# Juicing tips.


## JUICING SPEED SELECTION GUIDE

INGREDIENTS	SPEEDS	SEASONS
Apple	High	All Year
Beets	High	Summer / Fall / Winter
Blueberry	High	Summer
Broccoli	High	Fall / Spring
Brussels Sprouts	High	Fall / Winter
Cabbage	Low	Fall / Winter / Spring
Carrots	High	All Year
Cauliflower	High	Fall
Celery	High	All Year
Cucumber	Low	Summer
Fennel	High	All Year
Ginger	High	Fall
Grapes	Low	Fall
Grapefruit	Low	Winter
Kale	High	Fall / Winter / Spring
Kiwi	Low	Fall / Winter / Spring
Lemon	Low	All Year
Lime	Low	All Year
Melons (all)	Low	Summer
Orange	High	Winter
Peaches	Low	Summer
Pears	High	Fall / Winter
Pineapple	High	Fall / Winter / Spring
Plums	High	Summer
Raspberries	Low	Summer / Fall
Spinach	Low	Fall / Spring
Sweet Potato (raw)	High	Fall / Winter
Tomatoes	Low	Summer

## VITAMINS / NUTRIENTS

source of quercetin
excellent source of folate
good source of vitamin C
high in vitamin C, high in folate, good source of potassium
high in vitamin C, good source of folate
high in vitamin C
excellent source of vitamin A, good source of vitamin C
high in vitamin C, good source of folate
good source of vitamin C, good source of vitamin A
good source of vitamin C
good source of vitamin C and potassium
contains vitamin C, magnesium, and potassium
good source of vitamin K
high in vitamin A, high in vitamin C
excellent source of vitamin A and vitamin C, good source of calcium and potassium
high in vitamin C, good source of potassium and vitamin E
high in vitamin C
high in vitamin C
high in vitamin A, high in vitamin C
high in vitamin C
good source of vitamin C
good source of vitamin C
high in vitamin C
good source of vitamin C
high in vitamin C
high in vitamin A, vitamin C, iron, and folate, good source of magnesium
good source of potassium, high in vitamin A and vitamin C
high in vitamin A, high in vitamin C, good source of potassium

 **WARNING! DO NOT attempt to juice ingredients with very little water content, such as avocados, coconut, rhubarb, and bananas. These are generally not suitable for juicing because they lack the necessary liquid for the juicer to function properly, and may cause the unit to clog.**

 **WARNING! Apples can be juiced, but you should remove the seeds first. Apple seeds contain amygdalin, which can be poisonous when metabolized.**

## PROPER PRODUCE PREP

**Prepare fruit and veggies before inserting them into the juicer:**

- Properly clean produce (rinse with lukewarm water, produce wash, or water and apple cider vinegar).
- Peel or remove skin as needed, and chop food items down to the right size – just small enough to fit easily into the Feed Chute, without having to force the pieces down with the Food Pusher.
- Remove rind from all citrus fruits before juicing.
- Remove large pits and seeds from stone fruits before juicing.

## FEED CHUTE

- Never place your hand or fingers into the Feed Chute when it is attached to the appliance.
- Always start the juicer before adding food to the Feed Chute. The juicer must be running when items enter it.
- Do not overload the Feed Chute. Items must be added gradually, at a pace the juicer can keep up with.
- Use only the provided Food Pusher to push food into the Feed Chute. Never use fingers, utensils, or any other apparatus.
- Never use excessive force to push items into the Feed Chute.
- When juicing, ensure all produce has moved through the Feed Chute and into the Sieve before adding more.

- If any food gets stuck in the Feed Chute, use the Food Pusher to move it down the chute and into the Sieve.
- **IMPORTANT TIP:** Always start the motor first before inserting ingredients into the Feed Chute. Overfilling the Feed Chute before starting may overheat the motor. Also, do not use excessive force when pushing ingredients through the Feed Chute as it may strain the motor and cause it to overheat.

## CONSUMING JUICE & PULP

Instead of composting or throwing away the pulp left over after juicing, you can choose to consume it. Check out our recipe section on **nutribullet.com** for some fun tips on what to do with leftover pulp. By using these creative ideas, you can enjoy pulp in a variety of delicious (and healthy) ways.

- Whether you prefer sweet or savory, you can use pulp to create some tasty treats!
- For best taste, consume fresh juice and pulp within 48 hours of juicing.

## NO-GO FOODS

**Foods that should NEVER be used in this juicer:**

- Foods that do not contain juice to extract (for example, bananas or avocados).
- Frozen fruits or vegetables.
- Stone fruits that have large pits or seeds that have not been removed. Stone fruits may be used only if the seed or pit has been removed.


## OVERHEATING

- If the motor overheats, the juicer will turn off.
- If the juicer stops working, unplug it and allow it to cool down for at least fifteen minutes before attempting to use again.


# Disassembly.



- 1 Ensure the unit is powered off and unplugged.




- 3 Unlock the **Locking Handle** from the **Basin Cover** by pulling the handle backward out of the "ears" on either side of the **Basin Cover**. Move the handle down.




- 2 Remove the **Juice Pitcher** from under the **No-Drip Spout**. To prevent drips, turn the **No-Drip Spout** upwards.


**NOTE:** The **No-Drip Spout** can be removed. Wash and rinse with water. **DO NOT** wash **No-Drip Spout** in dishwasher



- 4 Remove the **Pulp Basin** from the **Motor Base** by pulling upwards with the **Basin Cover** and **Sieve** still in place. Take it directly to your sink.




- 5 Remove the **Food Pusher** by lifting it out of the **Feed Chute**.




- 7 Gently lift the **Sieve** vertically out of the center of the **Pulp Basin**. Clean the **Sieve** right away (see care instructions).

**WARNING!** The **Sieve** contains sharp blades. Do not touch the blades. Use the **Cleaning Brush**.




- 6 Lift the **Basin Cover** vertically off of the **Pulp Basin** and remove any pulp from the inside of the cover. You may use the flat end of the **Cleaning Brush** to scrape pulp off of the cover.



- 8 Empty the **Pulp Basin**. Use the flat end of the **Cleaning Brush** to scrape out the pulp, setting it aside for use in other recipes or composting. You can also empty the pulp directly into your waste bin or compost.

# Care instructions.

- 1 Always ensure the **Motor Base** is unplugged before you begin assembly, disassembly, cleaning or storage of the unit.
- 2 Once the **Pulp Basin** is emptied, rinse all parts under running water.
- 3 Use the **Cleaning Brush** to scrub the **Sieve** under running water. Be sure to properly clean the **Sieve** every time you juice. Residue from fruits and vegetables can cause buildup in the **Sieve** which can clog the holes and may prohibit maximum juice extraction.


 **WARNING! Always use precaution when cleaning the Sieve, as it contains sharp blade teeth on the flat disc part.**

**TIP:** Clean the **Sieve** immediately after juicing with the **Cleaning Brush** to prevent pulp from drying and clogging the holes. If buildup occurs, soak the **Sieve** in hot water for 30 minutes before scrubbing.

- 4 All of the components except the **Food Pusher**, **Motor Base**, and **No-Drip Spout** are dishwasher safe. You may also hand wash all pieces with warm soapy water.

**TIP:** Do not use the Sterilize cycle on your dishwasher to clean your juicer, as high temperatures may deform parts.

- 5 Wipe down the **Motor Base** with a clean, damp cloth.

 **WARNING! Never submerge Motor Base into water or other liquid.**

## Replacement parts.

Periodically inspect your nutribullet Juicer™ for damage or wear that may impair proper function or present a danger or safety hazard. Discontinue use if you detect cracking or damage. Never operate your nutribullet Juicer™ with damaged parts or components.

Always use genuine nutribullet® parts and accessories. Use of incompatible or aftermarket parts may result in damage to your nutribullet Juicer™ or create safety hazards that may cause personal injury or damage.

To order additional parts and accessories, please visit our website at [bulletbrands.com.au](http://bulletbrands.com.au) / [bulletbrands.co.nz](http://bulletbrands.co.nz).

## How to store.

Store the Juice Pitcher upright with the Pitcher Lid secured on top. Do not place anything on top of the Pitcher Lid. Store remaining pieces in a safe place where they will not be damaged and won't cause harm, as some of the pieces are sharp.

# CDB GOLDAIR

## one (1) year limited replacement warranty statement.

**If your product becomes defective due to faulty material or workmanship within a period of 1 year from the date of purchase, we warrant to do the following:**

- **For New Zealand Consumers:**  
We will replace the product with a new product, free of charge, or repair the product at our cost, at our discretion.
- **For Australian Consumers:**  
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

### **YOUR WARRANTY IS SUBJECT TO THE FOLLOWING CONDITIONS:**

- **DO NOT** operate the appliance with a damaged plug or cord, or if the unit has been dropped, damaged or dropped in water. To avoid the risk of electric shock, do not disassemble or attempt to repair the appliance on your own. If the supply cord is damaged, it must be replaced by a qualified electrician in order to avoid a hazard. Incorrect re-assembly or repair can cause a risk of electric shock or injury to persons when the appliance is used.
- The item has not been misused, abused, neglected, altered, modified or repaired by anyone.
- The item has been subjected to fair wear and tear.
- The item has not been used for trade, professional or hire purposes.

- The item has not sustained damage through foreign objects, substances or accident.

### **YOUR WARRANTY DOES NOT COVER:**

- Components that are subject to natural wear and tear caused by normal use in accordance with operating instructions.
- Unauthorised/improper maintenance/handling or overload is excluded from this warranty.
- For guarantee claims, you will need to submit a proof of purchase in the form of a valid receipt that displays date and place of purchase.

**This warranty does not replace but is in addition to your statutory rights.**

**This warranty does not apply to accessories supplied with the item.**

**This warranty applies only to the original purchaser and may not be transferred.**

**Replacement items will be covered by the limited warranty for the balance of the warranty period from the date of the original purchase.**

### **PLEASE NOTE:**

Only the defective product or parts returned to place of purchase will be replaced under this warranty.

---

## CDB GOLDAIR

**NEW ZEALAND**  
PO Box 100-707  
NSMC  
Auckland 0745  
0800 232633  
bulletbrands.co.nz

**AUSTRALIA**  
PO Box 574  
South Morang  
Victoria 3752  
1300 285538  
bulletbrands.com.au

Capital Brands Distribution, LLC | All rights reserved.  
NutriBullet and the NutriBullet logo are trademarks of  
CapBran Holdings, LLC registered in the U.S.A. and worldwide.

**220-240VAC 50-60Hz 800W**

Illustrations may differ from the actual product. We are constantly striving to improve our products, therefore the specifications contained herein are subject to change without notice.

**250417\_NBJ07150**