

*Sunbeam*

# AutoGrinder II

## Automatic coffee grinder

Instruction Booklet  
EM0420

Please read these instructions carefully  
and retain for future reference.



# Contents

<b>Sunbeam's Safety Precautions</b>	<b>1</b>
<b>Features of your Sunbeam AutoGrinder II</b>	<b>2</b>
<b>Handy hints for grinding coffee beans with the Sunbeam AutoGrinder II</b>	<b>4</b>
<b>Using your Sunbeam AutoGrinder II</b>	<b>5</b>
<b>Care and Cleaning of your Sunbeam AutoGrinder II</b>	<b>6</b>

## Important instructions – retain for future use.

تأكد من تفهم احتياطات السلامة المذكورة اعلاه

請務必理解上述的安全預防措施。

Assurez-vous que les précautions ci-dessus relatives à la sécurité sont bien comprises

Versichern Sie sich, dass die obenstehenden Sicherheitsmaßnahmen verstanden werden

Βεβαιώνετε πως οι παραπάνω προφυλάξεις ασφαλείας γίνονται κατανοητές

Pastikan bahwa tindakan-tindakan keselamatan seperti di atas dimengerti anda

Accertatevi che le suddette norme di sicurezza siano comprese a dovere

上記の注意事項をよくお読みになり、安全を御確認ください

Уверете се дека погоре споменатите мерки на претпазливост се добро разбрани

Asegúrese de que las precauciones de seguridad precedentes sean bien comprendidas

کاری ٻکنید کہ احتیاطهای بالا حتماً درک بشوند

ต้องแน่ใจว่า ข้อควรระวังเรื่องความปลอดภัยข้างต้น เป็นที่เข้าใจกันดี

Yukarda belirtilen güvenlik önlemlerinin anlaşıldığından emin olunuz

Xin kiểm chắc rằng những biện pháp làm an toàn kể trên được hiểu rõ

# Sunbeam's Safety Precautions

## SAFETY PRECAUTIONS FOR YOUR SUNBEAM AUTO GRINDER II.

- Always place the unit on a flat, level surface.

- The grinder cannot operate without the lid in position.
- Switch off and unplug at power point before cleaning.

---

**Sunbeam is very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:**

- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The temperature of accessible surfaces may be high when the appliance is operating.
- Never leave an appliance unattended while in use.
- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven.
- Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been damaged in any manner. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection, Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying power to your appliances.
- Do not immerse the appliance in water or any other liquid unless recommended.
- Appliances are not intended to be operated by means of an external timer or separate remote control system.
- This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.

If you have any concerns regarding the performance and use of your appliance, please visit [www.sunbeam.com.au](http://www.sunbeam.com.au) or contact the Sunbeam Consumer Service Line.

Ensure the above safety precautions are understood.

# Features of your AutoGrinder

## Transparent cover

For ease of use the cover of the AutoGrinder II also doubles as a measuring cup and being transparent the user is able to observe the coffee beans being ground.

## Removable grinding bowl



A convenient removable grinding bowl for easy grind removal and cleaning.


## One touch power button

Easy to operate, simply press the power button and your work is done, the grinder will automatically stop when the selected grind is achieved.

## Cleaning brush

For easy cleaning use the small brush to remove stubborn coffee grinds quickly and with no fuss to ensure quality, fresh grinding results every time.





### **Grind selector**

The AutoGrinder II gives you 5 choices of grind; coarse for plunger coffee through to fine for espresso coffee.

### **Sliding cup selector**

Adjustable cup setting from 4 to 15 cups.

### **Cord storage**

Convenient and clever cord storage.

# Handy hints for grinding coffee beans with the Sunbeam AutoGrinder II

- For a good cup of coffee only grind the amount you need for immediate use, as ground coffee quickly loses its flavour and aroma.
- With the Sunbeam AutoGrinder II coffee beans can be ground from a range of coarse to a very fine grind. The required coffee grind will be determined by the brewing method used or style of coffee desired. The different brewing methods include;
- Do not leave coffee beans or grounds in the open air, for best flavour always store them in an airtight container.
- When grinding more than 12 scoops of coffee beans, pour beans into cover, then turn the grinder upside down and lock onto the cover. Be sure to align the arrow on the lid/cover with the ‘unlock’ graphic on the rear of the grinder and turn the cover to the left/lock position.


BREWING METHOD	GRIND
Espresso Machines	Fine grind
Stove top Espresso	Medium grind
Drip Filtered	Medium grind
Plunger or Percolator	Coarse grind

# Using your Sunbeam AutoGrinder II


Before using your Sunbeam AutoGrinder II, wipe the grinding bowl and blades clean with a damp cloth and wash the transparent cover in warm soapy water. Dry thoroughly.

**Note:** Allow to dry completely before using.


1. Place the AutoGrinder on a dry, level surface.
2. Remove the cover of the AutoGrinder II by turning it to the right/unlock position, then lift straight up.




3. Using the measurements on the cover, fill with the desired amount of coffee beans and pour into the grinding bowl. Alternatively scoop the beans directly into grinding bowl.
4. Replace and lock the cover onto the AutoGrinder II. Align the arrow on the lid/cover with the 'unlock' graphic, on the rear of the grinder, and turn the cover to the left/lock position.



5. Plug the power cord into a 230-240V AC power outlet and turn the power 'ON'.
6. Rotate the grind selector to the required grind setting.




Set the cup selector to the number of cups to be ground.



7. Press the 'Grind' button to commence grinding and then remove finger. The Sunbeam AutoGrinder II will stop automatically when the selected grind is achieved. To stop the grind cycle at anytime, push the 'Grind' button. When the 'Grind' button is pressed again, the grinder will start from the beginning of the timed cycle.

**Important:** Do not remove the cover before the blades have stopped moving.

## Using your Sunbeam AutoGrinder II continued



8. Once the blades have stopped rotating unplug the cord from the power outlet and remove the cover. Rotate the removable bowl anti-clockwise to release and lift to remove. Invert the removable bowl and gently tap the base to loosen and remove the freshly ground coffee.

**Note:** The AutoGrinder II will only operate when the cover is in the locked position.



# Care and Cleaning

**Do not immerse the motor base of the AutoGrinder in water.**

**Do not place the AutoGrinder in the dishwasher.**

1. When you have finished grinding, unplug your AutoGrinder II from the power outlet.
2. Use the soft cleaning brush to clean around the blades. Carefully wipe the grinding bowl with a soft, damp cloth.

**Important:** Use care around sharp blades.

3. Wash the cover in warm soapy water. Rinse and dry thoroughly. Wipe the exterior of the AutoGrinder with a damp cloth.
4. To store the power cord, pull down the base and wrap the cord around the AutoGrinder II.

# Notes

# 12 Month Warranty

This Sunbeam product is covered by a 12 month replacement or repair warranty, which is in addition to your rights under the Australian Consumer Law (if your product was purchased in Australia) or New Zealand Consumer Guarantees Act (if your product was purchased in New Zealand).

Should you experience any difficulties with your product during the warranty period, please contact our customer service line for advice on 1300 881 861 in Australia, or 0800 786 232 in New Zealand.

Alternatively, you can send a written claim to Sunbeam to:

## Australia

Units 5 & 6, 13 Lord Street  
Botany NSW 2019 Australia

## New Zealand

Level 6, Building 5, Central Park,  
660-670 Great South Road,  
Greenlane, Auckland

Upon receipt of your claim, Sunbeam will seek to resolve your difficulties or, if the product is defective, advise you on how to obtain a replacement or refund.

To assist us in managing warranty claims, we recommend you register your product as soon as practicable after purchase by creating a MySunbeam account on our website and send a copy of your original receipt to Sunbeam.

In order to make a claim under our warranty, you must have the original proof of purchase documentation for the product and present it when requested.

Should your product develop any defect within 12 months of purchase because of faulty materials or workmanship, we will replace or repair it, at our discretion, free of charge. A product presented for repair may be replaced by a refurbished product of the same type rather than being repaired. Refurbished parts may be used to repair the product.

Our replacement or repair warranty only applies where a defect arises as a result of faulty material or workmanship during the warranty period. Your warranty does not cover misuse or negligent handling (including damage caused by failing to use the product in accordance with this instruction booklet), accidental damage, or normal wear and tear.

Your warranty does not:

- cover freight or any other costs incurred in making a claim, consumable items, accessories that by their nature and limited lifespan require periodic renewal (such as filters and seals) or any consequential loss or damage; or
- cover damage caused by:
  - power surges, power dips, voltage supply problems, or use of the product on incorrect voltage;
  - servicing or modification of the product other than by Sunbeam or an authorised Sunbeam service centre;
  - use of the product with other accessories, attachments, product supplies, parts or devices that do not conform to Sunbeam specifications; or
  - exposure of the product to abnormally corrosive conditions; or
- extend beyond 3 months if the product is used in commercial, industrial, educational or rental applications.

**The benefits given to you by our warranty are in addition to other rights and remedies under law in relation to the product.**

**In Australia our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.**

**Our goods also come with guarantees that cannot be excluded under the New Zealand Consumer Guarantees Act.**

If your warranty claim is not accepted, we will inform you and if requested to do so by you, repair the product provided you pay the usual charges for such repair. You will also be responsible for all freight and other costs.

Should your product require repair or service after the warranty period, contact your nearest Sunbeam service centre. For a complete list of Sunbeam's service centres, visit our website or call our customer service line for advice on 1300 881 861 in Australia, or 0800 786 232 in New Zealand.

## Need help with your appliance?

Contact our customer service team or visit our website for information and tips on getting the most from your appliance.

### In Australia

Visit [www.sunbeam.com.au](http://www.sunbeam.com.au)

Or call 1300 881 861

### In New Zealand

Visit [www.sunbeam.co.nz](http://www.sunbeam.co.nz)

Or call 0800 786 232



is a registered trademark.

Made in China.

Due to minor changes in design or otherwise, the product may differ from the one shown in this leaflet.

© Copyright. Sunbeam Corporation Limited 2013.

ABN 45 000 006 771

Units 5 & 6, 13 Lord Street

Botany NSW 2019 Australia

Level 6, Building 5, Central Park

660-670 Great South Road

Greenlane, Auckland

New Zealand

Sunbeam Corporation is a division of GUD Holdings Ltd.