

morphy richards®



Slow Juicer

Please read and keep these instructions



AUS



www.morphyrichards.com



Health and Safety

The use of any electrical appliance requires the following common sense safety rules.

Please read these instructions carefully before using the product.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children unless they are older than 8 years and supervised.
- Keep the appliance and its cord out of reach of children less than 8 years.
- Switch off the appliance and disconnect from power supply before changing accessories or approaching parts that move in use.

The use of any electrical appliance requires the following common sense safety rules.

WARNING: Danger to the person!

IMPORTANT: Damage to the appliance!

In addition, we offer the following safety advice.

Location

- This appliance is intended to be used in household and similar applications such as:
farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.
It is not suitable for use in staff kitchen areas in shops, offices and other working environments.

Mains cable

- Do not let the cable run across a cooker or hot area which might damage the cable.
- If the supply cable is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Other safety considerations

- This appliance is not intended to be operated by means of an external timer or separate remote control system.
- Only use for intended purpose.
- Do not pre-operate before inputting materials.

Personal safety

- Do watch your appliance during use.
- **WARNING: Do not touch the top of the appliance or other hot parts during or after use, use handles or knobs.**
- **WARNING: Do not wrap the cable around the main body of the appliance during or after use.**
- **WARNING: Do not insert oversize foods, metal, foil packages or utensils into the toaster.**
- **WARNING: Do not attempt to dislodge food when the appliance is plugged in and never insert cooking utensils into the slots.**
- **IMPORTANT: Do not place bread or other items on top of the slots as this may damage the appliance and creates a fire hazard.**

1

1



2




3



4



5



8



9

AUS



10



11



12



2




3



4




5



6





13

Order to disassemble



14



15





Getting the best from your new juicer...

Congratulations on becoming a Morphy Richards Slow Juicer owner. The Slow Juicer actually extracts juice faster than most typical juicers and expels a much higher yield with much drier pulp.

The method of extractions is masticating and pressing, using the screw-like auger like a mortar and pestle. The action tears open the food's cell membranes and releases its deep-seated nutrients and enzymes. It also breaks up more of the phytonutrients, resulting in a richer coloured juice that retains more vitamins and minerals. The slow RPM ensures that the cellular structure of fruits and vegetables is kept intact, eliminating oxidations and separation. Thus, it preserves the precious enzymes and nutrients that are closest to their natural form, even from wheatgrass, soy, and leafy greens.

For better use and optimal results, please follow the instructions carefully. Please refer to the instruction manual if you are having technical difficulties or are unsure of usage of the appliance.

Do not exceed 15 minutes of continuous operation.

Features

- (1) Hopper
- (2) Squeezing screw
- (3) GE Ultem Strainer
- (4) Spinning Brush
- (5) Bowl
- (6) Pulp outlet
- (7) Juice outlet
- (8) Base w/ Handle
- (9) Cleaning Brush
- (10) Pusher
- (11) Containers (x2)
- (12) Safety Feature

1

As shown, the hopper edge must point to "close" sign on the base in order for the machine to operate properly.

Assembly instructions

- 2** Place the strainer into the spinning brush.
- 3** Place the strainer + spinning brush into the bowl.
Be sure to align the white dot on top of the strainer and the white dot on top of the bowl.

When two dots are properly aligned, strainer should lock into the bowl preventing it from moving around.
- 4** Place squeezing screw inside the strainer and rotate until it falls into place.
- 5** Assemble the hopper onto the bowl.
Be sure to align the arrow on the Hopper to the white dot on top of the strainer and bowl, and twist to close so that the arrow is pointing to the "Close" position.
- 6** Assemble the entire Top Set onto the base.

As shown, once the Top Set is put on the base, twist the whole Top Set so that the hopper edge is pointing to the "Close" sign on the base.

AUS

Assembly Instructions

- 7** Plug in the unit.
- 8** Place containers under both the Juice & pulp ejectors

Underneath the bowl, there is a yellow rubber pad called the Extraction Packing which allows all of the juice to only discharge from the juice outlet. Before juicing, please make sure the Extraction Packing is plugged in completely to prevent any leakage.

How to use

- 9** The slow juicer has three settings.
 - 1 "On" starts motor/makes juice.
 - 2 "Rev" reverses motor and is to be used only when food is stuck
 - 3 "Off" stops motor/turns off unit
- 10** Inputting food into the slow juicer:
 - a Rinse food thoroughly before juicing.
 - b Be sure to cut food into pieces no larger than 2 inches for optimal extraction, and remove any large, hard seeds.
 - c Turning "On" the slow juicer, drop food into feeding tube. Do not push, force or over stuff. The pusher provided is only to be used when food becomes stuck. Insert food at a slow pace, allowing all the pulp to extract.
- 11** Turn "Off" when done.
 - Ensure that hands are completely dry before touching the switch.
 - Do not operate with an empty bowl.
 - Left over juice should be immediately refrigerated or frozen.

Juicing tips

This is a SLOW juicer and has different operating instructions than typical high-speed juicers. Make sure to read the instruction manual carefully and follow these simple steps below.

For best results

- Cut food items into pieces no larger than 2 inches for optimal extraction.
- Do not input frozen fruit or ice.
- Drop food into feeding tube. Do not push or force down. The pusher provided is only to use if food becomes stuck.
- Insert food at a slow pace, allowing all the pulp to extract. For maximum efficiency, do not overcrowd or rush.
- When juicing leafy greens, it is suggested that you mix it with fruits for optimal results.
- Juice nuts only with other foods such as soaked soy beans or liquids. Check the recipe section for ideas.

How to Disassemble & Clean

Turn the machine "Off"

- 12** Twist the Top Set to the right and lift to remove it from the base.

- 13** Order to disassemble.

- 1 Hopper
- 2 Squeezing Screw
- 3 Strainer
- 4 Spinning Brush
- 5 Bowl

- 14** Use the brush to clean thoroughly after operating.

- Do not use metal sponge or scouring powders to clean. They can damage the machine.
- Do not use dishwasher to clean.

- 15** Do not submerge the base in water. Use a damp or dry to towel clean.

- Please dry the attachments after cleaning.

Cleaning tips

- Carefully clean the spinning brush periodically by removing the silicone "brushes" to prevent staining or mold.
- Thoroughly rinse and clean after each use to minimize staining.
- For best cleaning results, use warm water and a mild detergent.
- Do not use rough abrasives or harsh chemicals as they can scratch or damage the plastic.
- Make sure Extraction Packing is pulled out completely when cleaning. Plug back in securely after cleaning to prevent leaks.

Contact us

Helpline

If you are having a problem with your appliance, please call our Helpline, as we are more likely to be able to help than the store you purchased the item from.

Please have the product name, model number and serial number to hand when you call to help us deal with your enquiry quicker.

UK Helpline: 0344 871 0910

IRE Helpline: 1800 409 119

Spares: 0344 873 0710

Talk To Us

If you have any questions or comments, or want some great tips or recipe ideas to help you get the most out of your products, join us online:

: www.morphyrichards.co.uk/blog

Facebook: www.facebook.com/morphyrichardsuk

Twitter: @loveyourmorphy

Website: www.morphyrichards.com

RECIPES

Strawberry, Apple & Lime Zing

300g Strawberries	Hulled (large fruit halved)
1 ½ Limes	Cut into quarters
3 Red Apples	Cored and cut into 5cm pieces

Orange & Mango

1 Mango	Peeled and cut into 5cm pieces
3 Oranges	Peeled and cut into 5cm pieces
½ Lime	Cut into quarters

Grapefruit and Mint

3 Ruby Grapefruit	Peeled and cut into 5cm pieces
10 Mint Leaves	

Summer Crush

150g Raspberries	
150g Strawberries	Hulled (large fruit halved)
100g Blueberries	
1 Apple	Cored and cut into 5cm pieces

Health in Glass

4 Sticks Celery	Cut into 5cm pieces
1 green Apple	Cored and cut into 5cm pieces
1 Lime	Cut into quarters
10 Mint Leaves	

Trouble shooting

Problem	Possible Reasons	Solution
1 Bowl is stuck and does not detach from the base.	Excessive food in the bowl. Unknown substance in the bowl.	Press reverse button 3-5 seconds. Repeat process 2-3 times. Then, push bowl upward while turning.
2 Hopper/lid is stuck.	Excessive food in the bowl. Unknown substance in the bowl.	Press reverse button 3-5 seconds. Repeat process 2-3 times. Then, press down on top of lid while turning.
3 Motor is stuck or has stopped.	Excessive food in the bowl. Safety feature: automatic shutoff due to overheating.	Press reverse button 3-5 seconds. Repeat process 2-3 times. If motor has stopped, let cool down before trying again.
4 Leaking from underneath the bowl.	Extraction packing not plugged in correctly.	Be sure to plug in extraction packing tightly after cleaning.
5 Squeaking noise when juicing.	Friction between the squeezing screw and bowl or food.	Squeaking sound is perfectly normal. Do not run the juicer without any food.
6 The unit vibrates.	Sign of motor working properly.	Vibration is perfectly normal. However, severe shaking which causes imbalance of the unit should be checked for a defective screw.
7 Water mark or scratch on the squeezing screw.	Molding marks during manufacturing process.	These marks and lines on the squeezing screw are perfectly normal.
8 Colour stain on the bowl, strainer, spinning brush.	Natural dye from food.	The Slow Juicer is BPA-free and chemical-free on all attachments, therefore natural dye from food when juicing is perfectly normal. To reduce staining, rinse and clean immediately after each use. Diluted vinegar or bleach can also be used.
9 Mold in silicone part of spinning brush.	Poor cleaning.	Be sure to clean thoroughly by detaching the silicone brushes from the spinning brush. Don't forget to plug it back in before juicing.
10 Strainer damage.	Ice, frozen foods, large hard seeds or pits, unknown substance, or excess food in bowl.	Refer to Instruction Manual for proper usage and juicing tips. Remember not to overcrowd food or force foods in.
11 Deformation of attachments.	Exposed to heat or abrasive materials.	Do not clean any attachments in dishwasher or use hard cleaners. Plastics tend to deform when exposed to high heat.
12 Too much pulp coming out.	Excess food in bowl clogging up the strainer or food not cut into small pieces.	Cut food, especially fibrous foods, into smaller pieces to avoid the fibres wrapping around the screw. Also input food at a slow pace allowing all the pulp to eject before adding more food.

AUS

THIS SECTION IS ONLY APPLICABLE FOR CUSTOMERS IN UK AND IRELAND

REGISTERING YOUR TWO YEAR GUARANTEE

Your standard one year guarantee is extended for an additional 12 months when you register the product within 28 days of purchase with Morphy Richards. If you do not register the product with Morphy Richards within 28 days, your product is guaranteed for 1 year. To validate your 2 year guarantee register with us online at www.morphyrichards.co.uk

N.B. Each qualifying product needs to be registered with Morphy Richards individually. Please refer to the one year guarantee for more information.

YOUR ONE YEAR GUARANTEE

It is important to retain the retailer's receipt as proof of purchase. Staple your receipt to this back cover for future reference. Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no.
Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase, it should be returned to the place of purchase for it to be replaced. If the fault develops after 28 days and within 12 months of original purchase, you should contact the Helpline number quoting Model number and Serial number on the product, or write to Morphy Richards at the address shown. You may be asked to return a copy of proof of purchase. Subject to the exclusions set out below (see Exclusions), the faulty appliance will then be repaired or replaced and dispatched usually within 7 working days of receipt. If, for any reason, this item is replaced during the 1 year guarantee period, the guarantee on the new item will be calculated from original purchase date. Therefore it is vital to retain your original till receipt or invoice to indicate the date of initial purchase. To qualify for the 1 year guarantee, the appliance must have been used according to the instructions supplied. For example, crumb trays should have been emptied regularly.

EXCLUSIONS

Morphy Richards shall not be liable to replace or repair the goods under the terms of the guarantee where:

- 1 The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturer's recommendations or where the fault has been caused by power surges or damage caused in transit.
- 2 The appliance has been used on a voltage supply other than that stamped on the products.
- 3 Repairs have been attempted by persons other than our service staff (or authorised dealer).
- 4 The appliance has been used for hire purposes or non domestic use.
- 5 The appliance is second hand.

- 6 Morphy Richards are not liable to carry out any type of servicing work, under the guarantee.
- 7 Plastic filters for all Morphy Richards kettles and coffee makers are not covered by the guarantee.
- 8 Batteries and damage from leakage are not covered by the guarantee.
- 9 The filters have not be cleaned and replaced as instructed.

This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer.

YOUR INTERNATIONAL TWO YEAR GUARANTEE

This appliance is covered by two-year repair or replacement warranty.

It is important to retain the retailers receipt as proof of purchase. Staple your receipt to this back cover for future reference.

Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no.
Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase it should be returned to the place of purchase for it to be replaced.

If the fault develops after 28 days and within 24 months of original purchase, you should contact your local distributor quoting Model number and Serial number on the product, or write to your local distributor at the addresses shown.

You will be asked to return the product (in secure, adequate packaging) to the address below along with a copy of proof of purchase.

Subject to the exclusions set out below (1-9) the faulty appliance will then be repaired or replaced and dispatched usually within 7 working days of receipt.

If for any reason this item is replaced during the 2-year guarantee period, the guarantee on the new item will be calculated from original purchase date. Therefore it is vital to retain your original till receipt or invoice to indicate the date of initial purchase.

To qualify for the 2-year guarantee the appliance must have been used according to the manufacturers instructions. For example, appliances must have been descaled and filters must have been kept clean as instructed.

The local distributor shall not be liable to replace or repair the goods under the terms of the guarantee where:

- 1 The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturers recommendations or where the fault has been caused by power surges or damage caused in transit.

- 2 The appliance has been used on a voltage supply other than that stamped on the products.
- 3 Repairs have been attempted by persons other than our service staff (or authorised dealer).
- 4 Where the appliance has been used for hire purposes or non domestic use.
- 5 The appliance is second hand.
- 6 The local distributor are not liable to carry out any type of servicing work, under the guarantee.
- 7 The guarantee excludes consumables such as bags, filters and glass carafes.
- 8 Batteries and damage from leakage are not covered by the guarantee.
- 9 The filters have not been cleaned and replaced as instructed.

This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer.

AUSTRALIAN WARRANTY

This appliance is guaranteed for 2 years against faulty material, components and workmanship.

This warranty is in addition and does not affect your statutory rights.

Proof of purchase must be produced for any warranty benefit.

In the unlikely event of any appliance proving to be faulty, securely pack and return the item to the place of purchase accompanied by the original receipt or invoice.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

NOT COVERED BY THIS WARRANTY

(Australian only)

- If the appliance has not been used in accordance with the manufacturers' recommendations or Instructions.
- If the fault is deemed to be caused by abuse, misuse, neglect, modifications or in proper use and or care
Eg: Kettles: Excessive build up of scale.
Toasters: Excessive build up of crumbs or foreign matter etc.
- Connection to incorrect voltage to that stamped on the product.
- Unauthorised repairs.
- Appliance used other than for domestic purposes.
- Excluding bags, filters, glass, carafes, and cutting blades.
- Freight and insurance costs.

If for any reason this item is replaced during the 2 year guarantee period, the guarantee on the new item will be calculated from original purchase date. Therefore it is vital to retain your original receipt or invoice to indicate the date of original purchase.

Morphy Richards's policy is to continually improve quality design and product quality. The company therefore reserves the right to change any specifications or to carry out modifications as deemed worthy at any time.

The Australian supplier reserves the right to repair, modify, exchange or replace the faulty appliance with the same or similar model or product of equivalent value.

AUS

- Morphy Richards products are intended for household use only.
See usage limitations within the location sub-heading in the important safety instructions.
Morphy Richards has a policy of continuous improvement in product quality and design.
The Company, therefore, reserves the right to change the specification of its models at any time.

The After Sales Division,

Morphy Richards Ltd, Mexborough, South Yorkshire, England, S64 8AJ
Helpline (office hours) UK 0845 871 0960 Republic of Ireland 1800 409119

● **Glen Dimplex New Zealand**

38 Harris Road, East Tamaki, Auckland, New Zealand
T : 09 2748265
E : sales@glendimplex.co.nz

● **Glen Dimplex Malaysia**

Sdn Bhd Unit 1001, Level 10, Menara PJ,
Pusat Perdagangan Amcorp no18,
Persiaran Barat, 46050 Petaling Jaya,
Selangor, Malaysia

T : +603 7960 1314
F : +603 7932 1315

morphy richards®

FP404000MAUS Rev 4 07/15

www.morphyrichards.com