



LIGHTING INSTRUCTIONS

1. Open the gas cylinder valve.
2. Push in control knob and turn anti-clockwise to HIGH whilst simultaneously pushing the ignitor button. If burner does not ignite immediately, allow 30 seconds between ignition attempts for gas to dissipate.
Failure to follow this lighting procedure may result in flame roll out beyond the emitter grid.
3. With the burner alight, keep control knob depressed for 15 seconds.
4. For minimum heat turn the control knob to LOW.
5. To turn heater off turn the control knob to OFF.

Warning: Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.



DANGER



Triangle to print as per art

USE OUTDOORS ONLY

KEEP THIS HEATER AWAY FROM COMBUSTIBLE MATERIALS
MINIMUM CLEARANCES

REAR 500mm - SIDE 500mm - TOP 500mm

TURN GAS OFF AT CYLINDER VALVE AFTER USE

DISCONNECT AND REMOVE CYLINDER BEFORE
STORING THIS HEATER INDOORS

- DO NOT OPERATE IN AN ENCLOSED AREA
DO NOT OPERATE IN AN UNVENTILATED AREA
DO NOT OPERATE INDOORS
DO NOT PLACE ARTICLES ON OR AGAINST THIS APPLIANCE
DO NOT OPERATE THIS APPLIANCE BEFORE READING THE INSTRUCTION BOOKLET
DO NOT STORE CHEMICALS OR FLAMMABLE MATERIALS, OR SPRAY AEROSOLS NEAR THIS APPLIANCE
DO NOT OPERATE WITH PANELS, COVERS OR GUARDS REMOVED FROM THIS APPLIANCE



OUTDOOR HEATER

MODEL	GAS CONSUMPTION	PRESSURE kPa	INJECTOR ORIFICE	GAS TYPE	IAPMO
PH07-S	40 MJ/h	2.75kPa	1.9mm	PROPANE	GMK 10261

Exim International (Australia) Pty Ltd
24 Newheath Drive, Arundel Industrial Park,
Arundel, QLD, Australia, 4214
FOR CORRECT OPERATION REFER
TO INSTRUCTIONS PROVIDED



D.O.M.
00/00

INSERT Date of Manufacture

FILE NAME: PH2160_PH2165_PH2169_LightingWarningData

JOB No: 03366

SIZE: 95mm wide x 215mm high

DATE: 10/15

COLOURS: ■ Red ■ Yellow ■ Black

STOCK: Sticker