

Operation manual for Schmick Extra-Cold Bar Fridge

HUS-EX46




Not to be used for preservation of Fresh Foods, this is a drinks fridge.

Bar Fridge Basic Instructions

Models: HUS-EX46

1. Unit is ready to plug in
2. Thermostat temperature control is located on front touch panel display.



1. Temperature Control Up/Down
2. System Set Button
3. Electronic Display
4. Fridge Cooling Indicator
5. Display Lock Screen Button

- When power supply is connected all area's on display light up for 1 second.
- The Up/Down buttons are used to adjust your temperature, each increment is 1oC.
- The lowest you can set the unit is -5oC (minus 5) and maximum you can set is 10oC.
- When you use Up/Down buttons, take to desired setting and leave for 5seconds, unit will now 'SET'.
- When the small 'thermometer' symbol is ON it means unit is cooling to your SET temperature.
- To LOCK your control press and hold UP/DOWN for 2 seconds, unit BEEPS and lock indicator flashes.
- To UNLOCK complete the same process, lock indicator will turn off.

3. There are different shelving positions available.
4. For Warranty enquiries and claims call 1300 170640, 9:00AM > 4:30PM Mon-Fri
5. Things you need to know;
 - a. Unit is Tropical rated, so it can work in high ambient temperatures.
 - b. Unit will turn off to defrost ice built up when compressor runs for 8 hours total.
 - c. Unit is compressor driven and you will hear this running if near the fridge.
 - d. Do not place in direct sunlight or build in behind a cupboard door.

Specifications


Model	HUS-EX46
Climatic class	T (Tropical Rated)
Storage Temperature (°C)	-5oC > 10oC (38oC Ambient)
Anti-shock protection class	I
Capacity (L)	38Litre
Rated Voltage (V)	AC220/240V
Rated Frequency (Hz)	50/60Hz
Input Current	1 Amp
Defrost Power	80 Watt
Power Watts	110
Refrigerant/Charging (g)	R600a / 15g

Set up and Positioning

- After unpacking dispose of rubbish sensibly
- When moving the fridge avoid hard jolts and bumps
- Don't carry fridge holding the door, always carry using body of fridge or use trolley
- Upon setting up fridge into your position ensure it is square and level, use feet adjustments where needed
- Do not position near sources of heat, like ovens and dishwashers
- Do not position in direct sunlight
- Do not move or tilt while in operation
- Allow as much ventilation wherever and whenever you can, the more ventilation the more economical the fridge will run and the longer the compressor life you will get
- Ensure your electrical lead hasn't been damaged, if you see any fault or cut in the power lead refer to electrician before plugging in
- Once in position allow 30minutes and turn "ON"

Safety

- Do not pull plug directly from socket without turning 'OFF' first
- Do not try to access unit electrics unless authorized to do so and unless unit is "OFF" and "UNPLUGGED"
- Do not have items near unit that could be damaged by heat, the condenser coils are located in the walls so these get quite hot during normal operation
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- Do not rest heavy items (including the fridge) on the electrical lead
- Queensland** installation/servicing requirement: Needs a Gas Repair Job (hydrocarbon refrigerants) if the appliance gas system is being opened or charged.



Not to be used for preservation of Fresh Foods, this is a drinks fridge

Storage inside the cabinet

- It is not recommended to store blood or special pharmaceuticals in the fridge
- Always let warm food cool before placing into fridge for storage
- Keep drinks at least 1cm away from walls to allow air flow and to stop bottles freezing on back wall close to cold-plate.

Trouble Shooting / Basic Info

There are basic things you need to look and check before trying to initiate a technician call out for warranty circumstances.

Noise

If your unit has become noisy, please check the following;

- Can you ascertain exactly where the noise is coming from? It may be a loose screw or part of the fridge that is now vibrating and is easy to fix.
- Is the compressor / fridge level, a compressor not level will make a 'clunking' noise on start-up and shut down.
- Does the fan sound noisy? It may be as simple as needing slight adjustment or could be ICED up.

Warranty: Contact 1300 170640 with Serial Number, Invoice No and fridge model details for warranty queries. Hours 9:00am > 4:30M Mon-Fri.

Not Cooling

So all of a sudden unit has stopped cooling.

- Does the compressor run? Make sure compressor is running, if it is running and you have a warm fridge then there is a gas problem and technician will be needed.
- Check fan inside unit (if applicable). If fan inside unit is not working then air won't be being distributed evenly, a lot of areas will not be as cold as some, and rear plate may ice up (hidden).
- Is your door sealing properly, check all the way around door seal to make sure it is seating correct on fridge body, small gaps won't affect cooling.

Freezing Product.

- The units are not freezers but there is a possibility of freezing drinks, especially if unit is set on the lowest subzero setting and unit is not being used over time. The thermostat cycles high/low and keeps drinks cold even though cycles fluctuate a lot.
- If you are experiencing rapid ice buildup on inside walls of unit the thermostat is likely to be faulty, technician is needed.

Maintenance

- Clean door seal every 6 months, use eucalyptus oil and a soft cloth
- Clean inside unit every 6 months as water parts and food can cause mold and bacteria may form
- Clean underneath unit periodically