

CLI~MATE™
improve your environment

Air Washer



Approved by the
National Asthma Council
Australia's Sensitive Choice® Program

CLI-AW200L | Installation & Operating Instructions



Congratulations on your purchase of a Cli~Mate Air Washer.

The Cli~Mate Air Washer reduces indoor air pollutants by drawing in air that is then cleansed by the cyclonic action of the fan and water drawn from the reservoir. It then releases clean and fresh air back into the room.

Note: Please read through the instructions carefully before using or installing the product and ensure that the manual is kept in a safe place for future reference.

The system must be properly installed and located in accordance with the installation instructions before it is used.

**During the set up of this product if you have any questions / comments / issues DO NOT RETURN TO STORE.
FOR SERVICE AND TECHNICAL ADVICE ON THIS PRODUCT, FREE CALL 1300 764 325.**

CUSTOMER CARE: 1300 764 325

Register your warranty online at
www.cli-mate.com.au/warranty-and-registration

Aquaport Corporation Pty Ltd
66-70 Hardys Road, Torrensville SA 5031
Telephone: 08 8354 0711
Web: www.cli-mate.com.au
Social: [f/climatebrand](https://www.facebook.com/climatebrand) [@climatebrand](https://twitter.com/climatebrand)



Electrical Requirements:
Australia / New Zealand 220-240V 50/60Hz
Due to manufacturing alterations product may vary slightly from the pictured.

SAFETY PRECAUTIONS

Read all instructions carefully.

- All components need to be installed in accordance with the user manual instructions for correct performance of unit.
- This appliance should be used in conjunction with a safety switch.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep the air outlet free from air blocking materials such as clothing, plastic bags or papers.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use appliance for other than intended use.
- Ensure appliance is on a flat, even surface.
- To protect against fire, electric shock and personal injury, do not immerse cord, plugs, or appliance in water or other liquid.

- Unplug from outlet when not in use and before cleaning.
- Do not use outdoors.
- Do not place on or near a hot gas, electric burner, heating appliance or in a heated oven.
- Place unit in a flat well-ventilated location at least 30cm from wall or other Appliances.
- Do not immerse base in water or try to disassemble.
- Check voltage to be sure that the voltage indicated on the nameplate agrees with your voltage.
- Do not remove lid of the unit when it is in operation.

PRODUCT SPECIFICATIONS

Air Washer Specifications

System Specifications	Air Washer
Model	CLI-AW200L
Product Dimensions	L 200 x W 200 x H 205 mm
Net Weight	1.16 kg
Coverage Area	up to 10m ²
Water Tank Capacity (Up to MAX line)	600ml

OPERATION INSTRUCTIONS

1. Locate a flat stable location with close access to a power point. Make sure there is at least 30 cm between unit and wall or other appliances.
2. Lift off lid of the air washer and fill water bowl with clean tap water to the MAX line.
3. Add 2-3 drops of aroma oil into the water bowl (optional) and place the lid back on.

Warning: It is recommended that asthma sufferers or those sensitive to fragrances should avoid adding aroma oils to the water as it may act as an irritant. Some fragrances may cause allergic responses in some people.

4. Plug power adapter into the unit and appropriate electrical outlet and place the Air Washer on the silicon pad provided.
5. Press power button to turn on. The LED light will illuminate, the water in the water bowl will begin to swirl and the unit will start to clean the air.

Note: The LED light will slowly transition into different colours.

6. During the LED colour transition, if it reaches a colour that you wish to 'lock in' press the Power button. The light will now stay the selected colour and will not change. Press Power button again to turn off the LED light and again to turn off the air washer.
7. When the water inside the bowl becomes dirty, turn off the unit and replace with clean tap water.

During the set up of this product if you have any questions / comments / issues DO NOT RETURN TO STORE FOR SERVICE AND TECHNICAL ADVICE ON THIS PRODUCT FREE CALL 1300 764 325

CLEANING AND MAINTENANCE


Before carrying out any maintenance or cleaning of the unit, make sure that the power to the unit is turned off and the power cord is removed from the unit and power socket.

External cleaning of the unit:


- Do not clean unit with any abrasive cleaning agents or solvents.
- Only use a soft clean cloth for all external cleaning purposes.
- Do not submerge the unit in water.
- Only use a soft clean cloth for all cleaning purposes.

Cleaning the Axle

1. Turn off unit and pull off rotating fan. (Fig 1)
2. Twist to remove axle from rotating fan. (Fig 2)
3. Use cleaning brush to remove dirt. (Fig 3)
4. Ensure all components are firmly re-attached after cleaning.



COMPONENT IDENTIFICATION AND CHECK LIST



TROUBLE SHOOTING

BEFORE YOU CALL FOR SERVICE PLEASE REVIEW THE TROUBLE SHOOTING TIPS FIRST.

Problem	Possible Causes	What To Do
No Power	1. Unit is not plugged into wall socket.	1. Check connection to wall socket and unit .
Water is dirty	1. Unit has removed pollutants in the air.	1. Turn unit off and replace water
Unit overheating	1. Air ventilation around unit not sufficient 2. Air inlet or air outlet is being obstructed or blocked by foreign objects 3. Internal malfunction	1. There must be at least 30cm between unit and wall or other appliances 2. Ensure there are no object obstructing the air inlet or air outlet 3. Return unit to service agent. Call customer care

Your Aquaport 12 Month Repair or Replacement Warranty

Aquaport warrants this appliance to the first purchaser and subject to the stated conditions:

Warranty covers any defects in material or workmanship in the manufactured product within the first twelve months from the date of purchase.

To make a warranty claim you must call Aquaport on toll free number 1300 764 325 for instructions. If a product is found to be faulty there is a 90 day return policy from the date of purchase.

For warranty claims outside of 90 days from date of purchase, product will be repaired or replaced at our discretion. Repair or replacement costs of the product will be covered under warranty by Aquaport.

Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods.

The benefits given to you by this warranty are in addition to other rights and remedies of the consumer law in relation to the goods or services to which this warranty relates.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure.

Conditions of this Warranty:

1. This product has been fully installed in accordance with the user manual installation instructions.
2. The warranty extends only to repairing or replacing any component that proves to be defective in material or workmanship.
3. The warranty does not cover defects occasioned by misuse, alterations, accidents, or used for other than the intended purpose.
4. The warranty does not cover damage to the product caused by accident, fire, or floods.
5. Proof of purchase is required for warranty claims.

Please keep purchase receipt in a safe place.

To enable us to register your warranty and provide service should a problem occur, we recommend you register your warranty online at:

www.cli-mate.com.au/warranty-and-registration

Aquaport Corporation Pty Ltd

66-70 Hardys Road, Torrensville SA 5031

Customer Care 1300 764 325



CUSTOMER CARE: 1300 764 325

Aquaport Corporation Pty Ltd
66-70 Hardys Road, Torrensville SA 5031
Telephone: 08 8354 0711
Facsimile: 08 8354 0722
Email: aquaport@aquaport.com.au
Web: www.cli-mate.com.au
Social: [f](https://www.facebook.com/climatebrand)/climatebrand [t](https://www.twitter.com/climatebrand)@climatebrand