

Homedics®

salt-n-soak pro
foot spa with heat boost



INSTRUCTION MANUAL AND WARRANTY INFORMATION

1-year limited warranty

FB-630H-AU

IMPORTANT SAFETY INSTRUCTIONS

WHEN USING ELECTRICAL APPLIANCES, BASIC PRECAUTIONS NEED TO BE FOLLOWED AT ALL TIMES TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK AND INJURY. READ THE HANDBOOK PRIOR TO USING THE APPLIANCE.

DANGER

To reduce the risk of electric Shock

- Always unplug this appliance from the electrical outlet immediately after using and before cleaning.
- **DO NOT** reach for a product that has fallen into water. Unplug immediately.
- **DO NOT** place or store appliance where it can fall or be pulled into a tub or sink.
- **DO NOT** place in or drop into water or other liquid.

WARNING

To reduce the risk of burns, electric Shock, fire, or injury to persons

- An appliance should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.
- If water leaks from the appliance, the appliance should no longer be used.
- Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Homedics; specifically, any attachments not provided with the unit.
- **NEVER** operate the appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a Homedics Service Center for examination and repair.
- Keep the cord away from heated surfaces.
- **NEVER** drop or insert any object into any opening.
- **DO NOT** operate where aerosol (spray) products are being used or where oxygen is being administered.
- **DO NOT** operate under a blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- **DO NOT** carry this appliance by supply cord or use cord as a handle.
- To disconnect, turn all controls to the off position, then remove plug from outlet.
- **DO NOT** use outdoors.

- **NEVER** operate the appliance with the air openings blocked. Keep the air openings free of lint, hair, and the like.
- **DO NOT** stand on or in appliance. Use only while seated.
- Use heated surfaces carefully. May cause serious burns. Do not use over insensitive skin areas or in the presence of poor circulation. The unattended use of heat by children or incapacitated persons may be dangerous.
- **DO NOT** handle plug with wet hands.
- This product should **NEVER** be used by any individual suffering from any physical ailment that would limit the user's capacity to operate the controls, or who has sensory deficiencies.
- Always unplug the unit when filling or moving the unit.
- Ensure that your hands are dry when operating the controls or removing the plug.

CAUTION

All servicing of this foot spa must be performed by authorised Homedics service personnel only.

SAVE THESE INSTRUCTIONS

CAUTION: PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE OPERATING.

- This item is not a medical device. It is only intended to provide a luxurious massage.
- Consult your doctor prior to using this product, if:
 - You are pregnant
 - You have a pacemaker
 - You have any concerns regarding your health
- **NOT** recommended for use by diabetics.
- **DO NOT** attempt to plug or unplug unit while feet are in the water.
- Use appliance on a sturdy or level surface.
- **DO NOT** use this product for more than 30 minutes at a time.
- Extensive use could lead to the product's excessive heating and shorter life. Should this occur, discontinue use and allow the unit to cool before operating.
- Never use any foot spa on open wounds, discolored areas, or any area of the body that is swollen, burned, inflamed, or where skin eruptions or sores are present.
- If you experience pain in a muscle or joint for a prolonged period of time, discontinue use and consult a doctor. Persistent pain could be a symptom of a more serious condition.
- **DO NOT** use while sleepy or drowsy.
- Use of this product should be pleasant and comfortable. Should pain or discomfort result, discontinue use and consult your doctor.
- This product is intended for household use only.

INSTRUCTIONS FOR USE

1. Ensure that the unit is unplugged before filling with water. Fill with water to the max fill line located on the inside of the tub. For a quicker heat boost, fill with warm water. Once water reaches selected temperature, it will stay at this temperature for as long as the heat function is selected.

Caution: Do not fill water over the max fill line.

2. Plug the unit into a 220-240 V a.c. household outlet.
3. Press power (⏻) button once to turn the unit on (Fig. 1). The unit is on when the number 0 is displayed on the control screen.
4. While seated, place your feet in the foot spa.
5. Enjoy a deep soothing massage by rolling your feet back and forth over the manual rollers on the foot spa floor or over the center massage node (Fig. 2). Enjoy a dry foot massage by sliding feet back and forth over the center massage node (Fig. 2).
6. To enjoy a foot spa with Epsom salt, unscrew the Epsom salt dispenser lid, fill the container with Epsom salt, and screw the lid back on (Fig. 2).
7. To turn the bubble function on, press the bubble (🌀) button once. The button will turn blue when it is on. Press the bubble (🌀) button again to turn off (Fig. 3).
8. To turn the heat function on, press the heat (🔥) button. Press the heat (🔥) button again to toggle between the three temperature levels. Press the button for the fourth time to turn the heat function off (Fig. 3).

NOTE: The heat will only turn on if the bubbles are on.

9. When finished, press the power (⏻) button again to turn the unit off.
10. To empty, unplug the unit. Tip the unit, allowing water to pour out along the rear corner of the foot spa. **DO NOT** pour water over the power (⏻) button. Use the convenient carry handle to move the foot spa (Fig. 4).

FIG. 1



FIG. 2




FIG. 3



FIG. 4



CAUTION

- To avoid injury and irreparable damage, always remain seated when using this foot spa. Never stand on or in the unit.
- This unit can only run with water in it. Do not use without water.

MAINTENANCE

TO CLEAN

- Unplug the unit and allow it to cool before cleaning. Clean only with a soft, damp cloth and mild cleansing agent.
- After cleaning, wipe surfaces with a dry cloth.
- Never use strong abrasives, detergents, or cleansing agents.
- Periodically straighten cord if it becomes twisted.

TO STORE

- Unplug the appliance from the outlet and allow to cool and dry.
- Store in its box or a clean, dry place.
- To avoid breakage, do not wrap the power cord around the unit.
- Do not hang the unit by the power cord.
- This appliance is designed for household use only.

We or **us** means Homedics Australia Pty Ltd ACN 31 103 985 717 and our contact details are set out at the end of this warranty;

You means the purchaser or the original end-user of the Goods. You may be a domestic user or a professional user;

Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia and New Zealand; and

Goods means the product or equipment which was accompanied by this warranty and purchased in Australia and New Zealand.

For Australia:

Our Goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled, subject to the provisions of the Australian Consumer Law, to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled, subject to the provisions of the Australian Consumer Law, to have the Goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This is not a complete statement of your legal rights as a consumer.

For New Zealand:

Our Goods come with guarantees that cannot be excluded under the Consumer Guarantees Act 1993. This guarantee applies in addition to the conditions and guarantees implied by that legislation.

The Warranty

Homedics sells its products with the intent that they are free of defects in manufacture and workmanship under normal use and service. In the unlikely event that your Homedics product proves to be faulty within 1 year from the date of purchase due to workmanship or materials only, we will replace it at our own expense, subject to the terms and conditions of this guarantee. The warranty period is limited to 3 months from the date of purchase for products used commercially/professionally.

Terms and Conditions:

In addition to the rights and remedies that you have under the Australian Consumer Law, Consumer Guarantees Act of New Zealand or any other applicable law and without excluding such rights and remedies warranty against defects: The Goods are designed to withstand the rigors of normal household use and are manufactured to the highest standards using the highest quality components. Whilst unlikely, if, during the first 12 months (3 months commercial use) from their date of purchase from the Supplier (Warranty Period), the Goods prove defective by reason of improper workmanship or materials and none of your statutory rights or remedies apply, we will replace the Goods, subject to the terms and conditions of this warranty.

We do not have to replace the Goods under this Additional Warranty if the Goods have been damaged due to misuse or abuse, accident, the

DISTRIBUTED BY

AUSTRALIA: Homedics Australia Pty Ltd, 14 Kingsley Close,

Rowville, VIC 3178 | Phone: (03) 8756 6500

NEW ZEALAND: CDB Media Ltd, 4 Lovell Court, Albany,

Auckland, New Zealand 0800 232 633

attachment of any unauthorised accessory, alteration to the product, improper installation, unauthorised repairs or modifications, improper use of electrical/power supply, loss of power, malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance, transportation damage, theft, neglect, vandalism, environmental conditions or any other conditions whatsoever that are beyond the control of Homedics.

This Warranty does not extend to the purchase of used, repaired or second-hand products or to products not imported or supplied by Homedics Australia Pty Ltd, including but not limited to those sold on offshore internet auction sites.

This Warranty extends only to consumers and does not extend to Suppliers.

Even when we do not have to replace the Goods, we may decide to do so anyway. In some cases, we may decide to substitute the Goods with a similar alternative product of our choosing. All such decisions are at our absolute discretion.

All such replaced or substituted Goods continue to receive the benefit of this Additional Warranty for the time remaining on the original Warranty Period (or three months, whichever is the longest).

This Additional Warranty does not cover items damaged by normal wear and tear including but not limited to chips, scratches, abrasions,

discolouration and other minor defects, where the damage has negligible effect on the operation or performance of the Goods.

This Additional Warranty is limited to replacement or substitution only. As far as the law permits, we will not be liable for any loss or damage caused to property or persons arising from any cause whatsoever and shall have no liability for any incidental, consequential, or special damages.

This warranty is only valid and enforceable in Australia and New Zealand.

Making a Claim:

In order to claim under this Warranty, you must return the Goods to the Supplier (place of purchase) for replacement. If this is not possible, please contact our Customer Service department by email:

cservice@homedics.com.au or at the address below.

All returned Goods must be accompanied by satisfactory proof of purchase which clearly indicates the name and address of the Supplier, the date and place of purchase and identifies product. It is best to provide an original, legible, and unmodified receipt or sales invoice.

You must bear any expense for return of the Goods or otherwise associated with making your claim under this Additional Warranty.

Contact Homedics Customer Service at:
Email: cservice@homedics.com.au



DISTRIBUTED BY

**AUSTRALIA: Homedics Australia Pty Ltd, 14 Kingsley Close,
Rowville, VIC 3178 | Phone: (03) 8756 6500**

**NEW ZEALAND: CDB Media Ltd, 4 Lovell Court, Albany,
Auckland, New Zealand 0800 232 633**